OPERATING MANUAL

FOR

Mazak

MAZATROL CAM T-2

. **©** .



Introduction

This manual has been prepared for operators of the MAZATROL CAM T-2.

Initially, the manual provides an understanding of the functions of switches and other components on the operating panel, then it describes the procedures for operating in both manual and automatic operation modes.

First-time operators of NC lathes as well as those already experienced should acquaint themselves with the correct handling methods and procedures to permit full use to be made of the machine.

Observe the safety cautions for preventing injuries and accidents, machine breakdowns and other damage.

The MAZATROL CAM T-2 was developed by updating the advanced electronics of and introducing certain advanced machining know-how to the MAZATROL CAM T-1.

This fully electro-mechanical machine can be operated simply by push buttons.

Even an unskilled person may easily learn to program so that the time required for programming can be reduced to a minimum.

In addition, only simple preparations are required to make the machine ready to operate.

* Discrepancies may arise occasionally between the present
Operating Manual and the actual machine because the latter may
have been modified without notice.

φ.



CONTENTS

	•		Page
Intr	oduction		
1.	HANDI.ING	PRECAUTIONS	1-1
- •		ating Precautions	1-1
	-	autions when lubricating after a long shutdown	1-3
		autions for cutting fluids	
		autions when the READY light is off	1-3
		-up	
	1 3		1 70
2.	OPERATING	PANEL	2-1
	2-1 Fron	t View	2-1
	2-2 CRT	Screen	2-1
	2-2-0	A word	2-3
	2-2-1	POSITION Picture	2-4
	2-2-2	COMMAND Picture	2-7
	2-2-3	TRACE Picture	2-10
	2-2-4	WORK PROGRAM Picture	2-12
	2-2-5	SHAPE CHECK Picture	2-13
	2-2-6	PROGRAM FILE Picture	2-15
	2-2-7	DATA IN OUT (CMT) Picture: Optional	2-17
	2-2-8	DATA IN OUT (BUBBLE) Picture: Optional	2-19
-	2-2-9	DATA IN OUT (TAPE) Picture: Optional	2-21
	2-2-10	DATA IN OUT (DNC) Picture: Optional	2-23
	2-2-11	CHUCK JAW DATA Picture	2-25
	2-2-12	LAYOUT Picture	2-27
	2-2-13	CHECK Picture	2-29
	2-2-14	SIMULATION Picture	2-31
	2-2-15	TOOL DATA Picture	2-33
	2-2-16	TOOL SET Picture	2 - 36
	2-2-17	TOOL FILE Picture	2-38
	2-2-18	TOOL OFFSET Picture (only for model with EIA/ISO	
		specifications): Optional	2-40
	2-2-19	CUTTING CONDITION NO. 1 Picture	2-42

Mazak —

		•	Page
	2-2	-20 USER PARAMETER Picture	2-45
	2-2	-21 DIAGNOSIS Picture	2-48
	2-2	-22 MEASURE Picture: Optional	2-51
	2-3	Functions of Operation Panel Buttons	2-54
3.	FOR C	PERATION BEGINNERS	3-1
4.	MANUA	L OPERATION	4-1
	4-1	Stop of Machine Operation	4-1
	4-2	Zero-Point Return	4-4
	4-3	Rapid Feed	4-7
	4-4	Jog Feed	4-8
	4-5	Manual Pulse Feed	4-9
	4-6	Stroke End Cancel	4-11
	4-7	Spindle Gear Selection	4-13
	4-8	Spindle Start	4-14
	4-9	Spindle Stop	4-16
	4-10	Spindle Inching	4-17
	4-11	Turret Unclamp	4-18
	4-12	Tool Swing	4-19
	4-13	Machine Protection	4-21
	4-14	Tail Stock Move	4-22
	4-15	Lighting	4-25
	4-16	Coolant	4-26
•	4-17	Machine Lock	4-27
5.	DISPL	AY DATA	5-1
	5-1	TOOL FILE Picture	5-2
	5-2	TOOL DATA Picture	5-11
	5-3	CHUCK JAW DATA Picture	5-20
	5-4	TOOL SET Picture	5-23
	5 - 5	PROGRAM FILE Picture	5-29
	5-6	WORK PROGRAM Picture	5-38
	5-7	SHAPE CHECK Picture	5-39

Mazak —

			Page			
•	5-8	LAYOUT Picture	5-41			
	5-9	CHECK Picture	5 - 46			
	5-10	SIMULATION Picture	5 - 50			
6.	HAND	LING FOR AUTOMATIC OPERATION	6-1			
	6-1	What is Automatic Operation?	6-1			
	6-2	Program Operation - AUTO Mode	6-2			
	6-3	RESTART Mode	6-8			
	6-4	SINGLE PROCESS Mode	6-12			
	6 - 5	Stop of Automatic Operation	6-14			
7.	חדכם:	I AV IN AUTOMATIC ODERATION	_			
/ •	7 - 1	LAY IN AUTOMATIC OPERATION	7-1			
	7-1 7-2	POSITION Picture	7-1			
		COMMAND Picture	7-4			
	7-3	TRACE Picture	7–6			
8.	AUTO	MATIC OPERATION HANDLING MODES	8-1			
	8-1	Machining Condition Changes	8-1			
	8-2	VFC Function	8-1			
	8-3	TPS Function	8-5			
	8-4	Manual Handle Interrupt Function	8-11			
	8-5	Background Program (Optional)	8-14			
	8-6	Picture Erasing Function	8-14			
	8-7	Data for Rewriting in Automatic Operation	8 - 15E			
9.	SUPPLEMENT					
	9-1	Counter Setting Function	9-1			
	9-2	Parts Count Setting	9-2			
	9-3	Time Display Setting	9-4			
	9-4	Write-inhibit Conditons	9 - 5E			
10.	PARAI	METERS	10-1			
11.	ALARM					

•

1. HANDLING PRECAUTIONS

This machine is provided with safety devices to prevent operators and itself from sustaining accidental damage. However, the operator should not rely too much on these but should read the following safety precautions before operating the machine.

1-1 Operating Precautions

- (1) Before turning on the power
 - 1) Clear the area and machine surfaces
 - 2) Close oprating and control panel doors
 - 3) Check smooth operation of levers, switches, etc.

(2) Power

- 1) Turn on the power by the main breaker and the operating panel switch in that order. When switching off, turn off the operating panel and main breaker in that order.
- 2) Check that the READY light comes on when the power button on operating panel is pressed.
- 3) If the power should fail, immediately turn off the main breaker.
- 4) Always switch off the main breaker when leaving machine after operating.

(3) Lubrication

Check that lubricant is provided at all supply poits.
 (Oil supply points, oil types and quantities are given on the name plate.)

(4) Operation

 Check all operation controls for proper function according to the Operating Manual.



2) Check all readings.

(5) Stopping

Press the following switches when stopping the machining operation.

a) EMERGENCY STOP button



- b) RESET key 1/
- c) FEED HOLD key
- d) Key for manual operation mode
- e) Power off key O

(6) Operating safety precautions

- 1) Always wear safety shoes, working cap, safety glasses, etc.
- 2) Always use only the recommended operating fluids and lubricating oils or equivalents.
- 3) Securely chuck the work.
- 4) Always use the safety covers (cutting chip cover, chuck cover, etc.)
- 5) Be sure to close front door before operating.
- 6) Perform a trial operation after setting the tool.
- 7) Never handle cutting chips, tool tips, etc. with the bare hands.
- 8) Do not remove cutting chips or touch anything that is turning with the bare hands or anything else when operating the machine.
- 9) Do not wear gloves when pressing push button switches.
- 10) Put tools in order and constantly secure foothold and passage.
- 11) Keep the machine clean.
- 12) Be careful of high voltage.
- 13) Do not touch switches with wet hands.
- 14) Use only the prescribed fuses.

- 15) Turn off the main breaker when replacing a fuse.
- 16) Electrical failures must be repaired by a qualified electrical maintenance person.

(7) Safety devices

The machine is equipped with the following safety devices.

- 1) Front cover, back cover
- 2) X- and Z-axis overtravel limit switches
- 3) Chuck, tail and tool barriers
- 4) Stored stroke limit
- 5) Emergency stop push button switch

1-2 Precautions when lubricating after a long shutdown

During the first operation after unpacking the machine or after long periods of disuse, be sure to pull the handle of slideway lubrication pump sevral times and see that oil comes out onto the slideway.

Note: Do not push the plunger.

1-3 Precautions for cutting fluids

- (1) Clean the oil pan or subtank filter at least once a week.
- (2) Replace cutting fluids at proper intervals.
- (3) Check the levels of the cutting fluids before operating.

1-4 Precautions when the READY light is off

Positioning is incorrect when the move command is given before the READY light comes on. Deviations can occur in the rapid feed, jog feed, handle feed and zero return. Perform the zero return carefully particularly after turning on the power or after correcting an emergency or overtravel limit stop.

Mazak-

1-5 Warm-up

Abnormal machine wear or trouble such as inaccurate work can occur due for example to insufficient oil on the slideway or due to the thermal expansion of machine sections such as when machining operations are begun immediately after long stoppages. Warm-up prevents trouble such as abnormal slideway wear and stock slippage. Adequate warm-up stabilizes thermal expansion and insures the high-accuracy manufacture of uniform work.

Be sure to warm-up the machine before starting the operation each day. Special care is necessary in low-temperature areas.

Warm-up Specifications:

(1) Time: about 15 min.

(2) Spindle rpms: 500 rpm \rightarrow 1000 rpm \rightarrow , ax.

(3) Move stroke: full for all axes


(4) Command is given for turret swing operation, etc. also.

Note: Check the motion of various sections, their lubricating condition during warm-up.

Mazak

- 2. OPERATING PANEL
- 2-1 Front View

 For the drawing, see the folded leaf at the end of this manual.
- 2-2 CRT Screen



- Data display
 Display of set data and data title.
- (2) Picture title The selected picture title.
- (3) Data setting message

 Questions to induce the data to be set appear here.
- (4) Data setting

 The data induced by a message appear here.




- (5) Alarm message The contents of alarm are indicated. They are indicated at the upper left of screen on the DIAGNOSIS picture.
- (6) Menu

 The message to select a picture or a function appears here.



2-2-0 A word

Familialize yourself with the respective names of the pictures in use and their relations before entering into detail.




Mazak —

2-2-1 POSITION Picture

Functions

- (1) To display operating conditions
- (2) To start up the automatic operation
- (3) To reset the parts counter and workpiece coodinates
- (4) To change the gear



Note: Nos. in ____ are correspondent to display data Nos. on the following pages.



Display data of POSITION picture

No.	Data Designation	Unit	Description
1	Х, Z	mm (inch)	Current position of tool tip in the turret in the workpiece coordinate system
2		·	
3	P	_	Running machining process number
4	T	-	Indexing tool number and compensation number
5	W	-	Running workpiece number
6	FR	mm/rev (inch/rev)	Command feedrate
	X/Z	mm/rev (inch/rev)	(X, Z composite speed)
7	SPINDLE	rpm	Spindle speed
8			Selected gear number
9		m/min (ft/min)	Surface speed (=0 when revolutions are commanded)
10			
11		-	Selected gear number
12	PROCESS	-	Machining processes in execution and scheduled to be executed, machining part, and selection of rough/finish machining
13			
14			
15	COUNTER	-	Number of workpieces already machined and set number
16	(LOAD METER) SPINDLE	%	Main spindle drive motor load capacity, with 30 minutes' rating equivalent to 100%
	(LOAD METER) X-AXIS	%	X axis servo motor load capacity, with 30 minutes' rating equivalent to 100%
-			



No.	Data Designation	Unit	Description
	(LOAD METER) Z-AXIS	%	Z-axis servo motor load capacity, with 30 minutes' rating equivalent to 100%
17	MAZATROL EIA/ISO	-	Distinction of coding system of the program being executed, MAZATROL or EIA/ISO

* 1 ATC specification only.


Mazak-


2-2-2 COMMAND Picture

Functions

This picture has the following functions in addition to those of the POSITION picture:

- (1) To display operating conditions in detail
 - (2) To notify the tip position of the tailstock and
 - (3) To reset an accumulated run-hour meter.





Note: Nos. in ____ are correspondent to display data Nos. on the following pages.



Display data of COMMAND picture

No.	Data Designation	Unit	Decemination
1			Description
	WNO.	-	Same as W on the POSITION picture
2	PROCESS NO.	-	Same as P on the POSITION picture
3	TOOL NO.	-	Same as T on the POSITION picture
4	BLOCK NO.	-	Running block number
5	POSITION X	mm (inch)	Same as X on the POSITION picture
	POSITION Z	mm (inch)	Same as Z on the POSITION picture
6	POSITION G	.	G code currently executed
7	BUFFER U	mm (inch)	X-axis traval in the block to be executed next (incremental)
	BUFFER W	mm (inch)	X-axis travel in the block to be executed next (incremental)
8	BUFFER G	-	G code to be executed in the next block
9	MACHINE X	mm (inch)	Actual position of tool in the machine coordinate system
	MACHINE Z	mm (inch)	Actual position of tool in the machine coordinate system
10	REMAIN U	mm (inch)	Remaining distance of axis movement command presently executed
	REMAIN W	mm (inch)	Remaining distance of axis movement command presently executed
11	TAIL STOCK	mm (inch)	Tailstock reference position from reference program zero
	6 7 8 9	POSITION Z 6 POSITION G 7 BUFFER U BUFFER W 8 BUFFER G 9 MACHINE X MACHINE Z 10 REMAIN U REMAIN W	POSITION Z mm (inch) 6 POSITION G - 7 BUFFER U mm (inch) BUFFER W mm (inch) 8 BUFFER G - 9 MACHINE X mm (inch) MACHINE Z mm (inch) 10 REMAIN U mm (inch) REMAIN W mm (inch)



No.	Data Designation	Unit	Description
12	сниск-х	mm (inch)	Chuck reference position X from reference program zero
	CHUCK-Z	mm (inch)	Check reference position Z from reference program zero
13	POWER ON	hr/min/ sec.	Accumulated power on time
	AUTO OPR	hr/min/ sec.	Accumulated automatic operation mode time
	AUTO CUT	hr/min/ sec.	Accumulated cycle operation time (CYCLE START light on) (Note 2)
	TOTAL CUT	hr/min/ sec.	Accumulated cutting time (G01, G02, G03, G32)

Note 1: A series of minimum units that can be executed with the single step operation is defined as "one block". M code, etc., which does not appear externally, is also treated as "one block".


Note 2: The time during feed hold stop or single step stop is not counted.


Mazak —

2-2-3 TRACE Picture

Functions

- (1) To provide a synchronous display of operating conditions
- (2) To determine the automatic operation hours
- (3) To start the automatic operation





Note: Nos. in are correspondent to display data Nos. on the next page.



Display data of TRACE picture


No.	Data Designation	Unit	Description
1	(Chuck)		Chuck shape
	(Blank)		To be displayed depending on a change in the shape with machining in progress
	(Shape)		Machining shape defined in program
-	(Tool)		Position changes according to the move of Turrets 1 and 2.
	(Program zero point)	-	Display pattern zero point (program zero point)
	(Tailstock)		Tailstock shape/position
2	WNO.	_	Running workpiece number
3	P	-	Running machining process number
4	N	_	Running block number
5	T	-	Indexing tool number and compensation number
6	X, Z	mm (inch)	Current position of a tool in the work- piece coordinate system (diameter value for X)
7			
8	S	rpm	Spindle speed
. 9	CUT TIME	hr/min/ sec	Automatic machining time
10		mm (inch)	Value of scale in a display pattern
11		mm (inch)	Display limit value
12	MAZATROL \$\displaystyle{\pi}\$ EIA/ISO	-	Distinction of coding system of the program being executed, MAZATROL or EIA/ISO.

Mazak -


2-2-4 WORK PROGRAM Picture

Function

(1) To prepare and edit source programs



Note: The figures on the picture indicate the maximum values of the setting range (unit: mm).





Mazak -

2-2-5 SHAPE CHECK Picture

Function

(1) To show the shape of a graphic being selected on the ${\tt PROGRAM}$ picture.





Note: Nos. in are correspondent to display data Nos. on the next page.



Display data of SHAPE CHECK picture


T			
No.	Data Designation	Unit	Description
1	WNO.		Workpiece number of the program to be checked
2	(Blank)		Shape of a blank
	(Shape)		Machining shape defined in a program
	(Program zero point)		Graphic zero point (program zero point)
3		mm (inch)	Scale value of a graphic displayed
4		mm (inch)	Limit value displayed

Mazak -

2-2-6 PROGRAM FILE Picture


Functions

- (1) To display a list of programs stored in memory
- (2) To display the registration capacity
- (3) To display and set a zero point offset in relation to a reference workpiece
- (4) To display and set a chuck barrier reference point



Note: 1. The figures on the picture indicate the maximum values of the setting range (unit: mm).

- 2. ABCDEFGHIJK indicate the maximum number of characters.
- 3. M is an abbreviation of MAZATROL program while E is an abbreviation of EIA/ISO program.



Note:

Nos. in ____ are correspondent to display data Nos. on the next page.



Diaplay data of PROGRAM FILE picture


		•	
No.	Data Designation	Unit	Description
- 1	WNO.	-	A separate number (1 thru 9999) given to each program
2	BLOCK		Progrm size applicable to each program
3	Z-OFFSET	mm (inch)	Z-axis difference of zero point between reference workpiece and program
4	СНИСК-Х	mm (inch)	Positon -X of chuck jaw reference point, with workpiece in the chuck
5	CHUCK-Z	mm (inch)	Position -Z of jaw reference point, with workpiece in the chuck
6	JAW NO.	-	Working jaw number (with jaws controlled on the CHUCK JAW DATA picture)
7	TAILSTOCK	mm (inch)	Tailstock spindle projection amount
8	NAME	-	When not in use, keep setting at 0. A character string or code arbitrarily defined by the operator to facilitate program identification
9	USED	Block	Total number of blocks in programs registered (Fixed character 500 represents the limit of blocks registered.)




2-2-7 DATA IN OUT (CMT) Picture: Optional

Function

- (1) To sure and load following information to and from cassette tape.
 - Programs stored in memory
 - Data necessary for execution and reproduction of programs



Note: The fitures on the picture indicate the maximum values of the setting range.



Note: Nos. in ___ are correspondent to display data Nos. on the next page.



Display data of DATA IN OUT (CMT) picture


No.	Data Designation	Unit	Description
1	WNO.	_	Individual numbers from 1 to 999999 may be given to programs
. 2	BLOCK	-	Program size employed in each program
3	NAME	<u>-</u>	Names assigned to individual programs
4	MODE	·- <u></u>	Data transfer method
5	SOURCE PROGR	-	Workpiece number of the program to be transferred Number of programs entered: 16
6	TOOL DATA	-	Are the data on each of TOOL SET, TOOL DATA, TOOL FILE and TOOL OFFSET DATA pictures to be transferred? (1: YES and 0: No)
7	C-COND	-	Are the data on the CUTTING CONDITION picture to be transferred? (1: YES and 0: NO)
8	PARAM	- -	Are the data on four PARAMETER pictures to be transferred? (1: YES and 0: NO)
9	CHUCK DATA	-	Are the data on the CHUCK JAW DATA picture to be transferred? (1: YES and 0: NO)

Mazak

2-2-8 DATA IN OUT (BUBBLE) Picture: Optional

Functions


- (1) To display the programs stored in the bubble memory.
- (2) To erase any or all programs in the bubble memory.



Note: The figures on the picture indicate the maximum values of the setting range.

M means a program prepared by MAZATROL.

* 1 : Subject to change depending on the bubble capacity.



Note: Nos. in ____ are correspondent to display data Nos on the next page.



Display data of DATA IN OUT (BUBBLE) picture

No.	Data Designation	Unit	Description
. 1	wno.	-	Workpiece numbers for programs stored in the ordinary memory
2	BLOCK	-	Program size employed in each program
3	wno.	-	Workpiece numbers for the programs stored in the bubble memory
4	RECORD	-	Record number of the bubble memory employed in each program
5	BUBBLE	-	Working condition of bubble memory Working capacity Maximum capacity
6	PAGE (Note 1)	_	Display page number


Note 1: The picture has two pages. To display the other page, select the menu PAGE.

Mazak


2-2-9 DATA IN OUT (TAPE) Picture: Optional

Function

(1) Storing in and takeout from the paper tape of EIA/ISO program which is being registered.



Note: The figures on the picture indicate the maximum values of the setting range.



Note: Nos. in ____ are correspondent to display data Nos. on the next page.




Display data of DATA IN OUT (TAPE) picture


No.	Data Designation	Unit	Description
1	WNO.	-	Individual numbers given to programs
2	BLOCK	-	Program size employed in each program
3	NAME	_	Names assigned to individual programs
4	MDOE	- -	Data transfer method
5	SOURCE PROGR	_	Workpiece number of the program to be transferred. Sixteen programs can be set.

Mazak -

2-2-10 DATA IN OUT (DNC) Picture: Optional



Note: The figures on the picture indicate the maximum values of the setting range.



Note: Nos. in ____ are correspondent to display data Nos. on the next page.



Display data of DATA IN OUT (DNC) picture


	Die to e		·
No.	Data Designation	Unit	Description
1	WNO.	_	Individual numbers given to programs
2	BLOCK	-	Program size employed in each program
3 .	NAME	_	Names assigned to individual programs (display of up to ll characters possible)
4	MODE	-	Data transfer method
5	SOURCE PROGR	-	Workpiece number of the program to be transferred Number of programs entered: 16
6	TOOL DATA	_	File number of the data on each of TOOL SET, TOOL DATA, TOOL FILE and TOOL OFFSET DATA pictures to be transferred (0 to 99)
7	C-COND	_ ,	File number of the data on the CUTTING CONDITION picture to be transferred (0 to 99)
8	PARAM	-	File number of the data on four PARAMETER pictures to be transferred (0 to 99)
9	CHUCK DATA		File number of the data on the CHUCK JAW DATA picture to be transferred (0 to 99)

Mazak -


2-2-11 CHUCK JAW DATA Picture

Function

(1) To manage 16 types of chuck (jaw) data.



Note: The figures on picture indicate the maximum values of the setting range (unit: mm).






Display data of CHUCK JAW DATA picture

No.	Data Designation	Unit	Description
1	TYPE	-	External jaw (OUT)/Internal jaw (IN)
2	DIM-A	mm (inch)	Jaw length A (See display.)
3	DIM-B	mm (inch)	Jaw length B (See display.)
4	DIM-C	mm (inch)	Jaw length C (See display.)
5	DIM-D	mm (inch)	Jaw length D (See display.)


Mazak

2-2-12 LAYOUT Picture

Function (1) To edit processes



Note: Figures on the above picture are examples.





Display data of LAYOUT picture

ì	1	
Data Designation	Unit	Description
PNO.	-	Machining process number
		R 1 Rough (R)/finish (F) Process number
PROCESS	_	Process machining
		BAR - OUT Machining mode Machining location
TNO.	-	Machining tool number and compensation number
TIME	hr/min/ sec	Cutting time for each process in a program (Note 1)
TOTAL CUTTING	hr/min/ sec	Cutting time for all processes (Note 1)
	PROCESS TNO. TIME TOTAL CUTTING	PROCESS - TIME hr/min/sec TOTAL CUTTING hr/min/


Note 1: These data will be displayed by executing simulation. They are not displayed by a mere preparation of a new program.


Mazak —

2-2-13 CHECK Picture

Functions

- (1) To display the established tool path (with continuous/intermittent displayed)
- (2) To adjust the tool path size to a particular scale.
- * Programs for the workpiece being selected are checked on the PROGRAM display WORK PROGRAM picture.







Display data of CHECK picture


T T			
No.	Data Designation	Unit	Description
1	(Chuck)		Chuck shape
	(Blank)		Blank shape
	(Tool path)	·	Path along which the tips (nose radius center) of tools in turret pass
		a was	cutting feed rapid feed
	(•)		Tips (nose radius center) of tools in turret (Note 1)
	(Program zero point)		Zero point of graphic to be displayed (program zero point)
	(Tailstock)		Tailstock shape and position
2		mm (inch)	Limit value displayed
3	WNO.		Workpiece number in a displayed program
4	P		Running machining process number
	N		Running block number
	Т		Indexing tool number and compensation number
	х, Z	mm (inch)	Current position of tool tip in the workpiece coordinate system (diameter value for X)
5		mm (inch)	Scale value of a graphic displayed

Note 1: This is not applicable to the Z direction of edge machining (EDG), #0 of grooving (GRV) and the measure (MES).


2-2-14 SIMULATION Picture

Function

- (1) Simulation of a program(execution speed of axis movement command can be chagned as required.)
 - * Display of this picture is possible after return to the zero point and when the control is not in automatic operation mode.
 - * Simulation of the program for the workpiece selected on the WORK PROGRAM picture is made.



Note: The figures on the picture indicate the maximum values of the setting (unit: mm).



Note:
Nos. in ____ are correspondent to display data
Nos. on the next

page.



Display data of SIMULATION picture

<u> </u>			
No.	Data Designation	Unit	Description
. 1			See TRACE picture.
2	.WNO.	_	Running workpiece number (Note 1)
3	P	-	
. 4	N		See TRACE picture
5	х, Z	mm (inch)	
6	S-	rpm	
7	SPD OVERRIDE	- %	Rate of machining speed (feedrate) to introprogram command speed
8		mm (inch)	Displayed graphic scale value
9		mm (inch)	Displayed limit value


Note 1: The first workpiece number will remain even if other programs are executed continuously.




2-2-15 TOOL DATA Picture

Functions

- (1) Registration of specifications of tools to be used.
- (2) Setting of the life of the tool to be mounted and setting of the spare tool



Note: The figures on the picture indicate the maximum values of the setting range (unit: mm).





Display data of TOOL DATA picture

No.	Data Designation	Unit	Description
. 1	TNO	_	Tool number
2	FNO	-	Corresponding file number
3	SHAPE	-	Tool kind and machined portion
4			
5	NOSE-R	mm (inch)	Nose radius of tool tip Nose radius (Note 1)
6	FWD/REV		Spindle rotating direction
	•	: : :	Forward
			: Reverse
7	R/L	_	Cutting direction of tool (Note 2)
8	SPARE-TOOL	-	Spare tool No. and offset No. in case life has been reached (Note 5)
9	LIFE (TIME)	min	Maximum time of use (internally measured in terms of seconds) (Note 3)
10	LIFE (NUM)	pcs.	Maximum No. of workpieces cut (Note 3)
11	USED (TIME)	min.	Time of use (internally, measured in terms of seconds) (Note 4)
12	USED (NUM)	pcs.	No. of workpieces cut (Note 4)



- Note 1. Not applicable to threading, drilling and tapping tools.
 - 2. Not applicable to drilling and tapping tools.
 - 3. Life check is not performed when this data is "0".
 - 4. When the end of the life has been reached, the background for the data is inversed. This data will not increase thereafter.
 - 5. The kind of the spare tool should be same as the tool mounted.
 - 6. Parenthesized description is applicable to EIA.


Mazak -

2-2-16 TOOL SET Picture


Before entering automatic operation, always set the tool set value for the mounted tool, using this picture.

Functions

- (1) Definition of tool set value
- (2) Management of tool tip position offset



Note: The figures on the picture indicate the maximum values of the setting range (unit: mm).





Data displayed of TOOL SET picture


No.	Data Designation	Unit	Description
1	TNO	45	Tool number
2	TOOL SET-X	mm (inch)	Distance between the tool movement command target position in the machine zero point
3	TOOL SET-Z	mm (inch)	and the zero point of the reference workpiece. (Note 2)
4	OFFSET-1 X	mm (inch)	Amount of tool tip position offset for Offset No. 1.
5	OFFSET-1 Z	mm (inch)	
6	OFFSET-2 X	mm (inch)	Amount of tool tip position offset for Offset No. 2
7	OFFSET-2 Z	mm (inch)	
8	OFFSET-MAX X	mm (inch)	Limit (absolute value) of offset
9	OFFSET-MAX Z	mm (inch)	

- Note 1. All the X's are expressed in terms of diameters.
 - 2. It is a quantity to be set when the distance is already known.


Mazak

2-2-17 TOOL FILE picture

Function (1) Setting of tool shape



Note: The figures on the picture indicate the maximum values of the setting range (unit: mm).





Display data of TOOL FILE picture

No.	Data Designation	Unit	Description
1	FNO	-	Tool file number
2	SHAPE	-	Tool group and portions of workpiece machined (Note 1)
3	HLDR	-	Type of tool holder
4			
5	DEP-ANG	deg or mm (inch)	Major cutting angle or maximum groove depth
6	CUT-ANG	deg or mm (inch)	Tool tip angle or tool width (grooving tool)
7	WIDTH	mm (inch)	Tool shank width
8	PITCH	mm (inch)	Pitch (thread and tap only) (Note 2)
9			
10			


- Note 1. The tool shape determined here is patterned and displayed with the cutting direction and rotating direction taken into account.
 - 2. Values up to 999.99999 can be set.

Mazak -


2-2-18 TOOL OFFSET Picture (only for model with EIA/ISO specifications): Optional

Function

(1) Tool offset data of tools storable in NC.



Note: The figures on the picture indicate the maximum values of the setting range (unit: mm).





Display data of TOOL OFFSET picture


No.	Data Designation	Unit	Description
1	OFFSET-X	mm (inch)	Tool offset amount
2	OFFSET-Z		
3	NOSE-R	mm (inch)	Nose radius of tool tip
4	DIRCTN	_	Direction of cutting tool




2-2-19 CUTTING CONDITION NO. 1 picture

Function

(1) Registration of basic data for automatic determination of cutting conditions




Note: The figures on the picture indicate the maximum values of the setting range (unit: mm).






CUTTING CONDITION NO. 2 picture

Function (1) Setting of 16 kinds of materials



Note: Materials for No.1 thru NO.5 were inputted by the manufacturer.

For those for NO.6 and thereafter, use your discretion.





Display data of CUTTING CONDITION picture


No.	Data Designation	Unit	Description
1	SURFACE SPEED RV	m/min (ft/min)	Surface speed for rough cutting
2	SURFACE SPEED FV	m/min (ft/min)	Surface speed for finish cutting
3	FEED	mm/rev (inch/rev)	Maximum allowable feed rate for rough cutting
4	DEPTH	mm (inch)	Maximum allowable penetration for one pass during rough cutting (Setting is unnecessary for thread (THR), tap (TAP) and drill (DRL).)
5	MATERIAL	-	Materials. Five standard materials of CB ST (carbon steel), AL ST (alloy steel), CS IR (cast iron) ALMNM (light alloy) and STNLS (stainless steel) plus user's special materials
6	%	%	Coefficients for determinining surface speed for individual material types

Mazak


2-2-20 USER PARAMETER Picture

Function

(1) Registration of parameters concerning the machining methods freely utilized by the user



Note: For the scope of parameter setting, see Parameter List.







MACHINE PARAMETER No. 1 Picture

Function

- (1) Registration of various machine parameters necessary for NC.
 - * User should not change data on this picture at his own discretion. If data is changed, normal opration will not be assured.



Note: For the scope of parameter setting, see Parameter List.







MACHINE PARAMETER No. 2 Picture

Function

- (1) Registration of various machine parameters necessary for NC.
 - * User should not change data on this picture at his own discretion. If data is changed, normal opration will not be assured.



Note: For the scope of parameter setting, see Parameter List.







2-2-21 DIAGNOSIS Picture

Function

- (1) Check and adjustment of status of NC and servo
- * This picture should be serviced by YAMAZAKI only.



Note: The figures on the picture indicate the maximum values of the setting range.






Display data of DIAGNOSIS picture

No.	Data Designation	Unit	Description
1	(TOTAL=)	-	Total No. of alarms currently given
2		· -	Contents of alarms currently given (MAX10) Red: very serious trouble, Blue: trouble (For details of contents, see Alarm List.)
3	H, Q (Note 1)	Byte	I/O port address (hexadecimal) H: Input, Q: Output (Note 2)
4	(Note l)		I/O data (binary)
5	(Note 1)		I/O data (hexadecimal) (Note 2)
6	MH, WH (Note 1)	Byte	Memory R/W (read/write) address (special hexadecimal) MH: Read WH: Write (Note 2, 4)
7	(Note 1)	_	R/W data (binary)
8	(Note 1)	_	R/W data (hexadecimal) (Note 2)
9	DROOP (Note 3)	0.5 m	Positon droop. It is zero when the axes are stopped. Reliability value is 1 - 2 m/min.
10	GRID (Note 3)	0.5 m	Distance between end of origin dog to first grid
11	GAIN (Note 3)	_	Position loop gain
12	PHASE (Note 3)	Pulse	Phase difference between reference signal in NC and resolver feedback signal
13.	VERSION	-	Quantity of software for each CPU and number of optional versions
	•		1 Main 1 2 Main 2 3 MCU 4 PCB (main) 5 PC (user) 6 Language 7 EIA/ISO 8 Milling 9 DNC
14	MD (Note 1)	Byte A / A	Memory read-out address (secial hexadecimal) (Note 2, 4)
15	(Note 1)	-	Memory read-out data (decimal)

Mazak -

- Note 1. Displayed when address is set. (When the power is switched on, address is not set.)
 - 2. Like numerical keys, the menu "A" through "F" can be manipulated.
 - 3. Every time when the menu key ADJUST is pushed, the screen is turned on and off.
 - 4. Address is expressed according to the following format.

 In setting of the address, use this format.



Sign presentSign absent

→ Data length: 0-4 bytes


Specify MCU in even number address 80000 - 80FFF.

Mazak ·


2-2-22 MEASURE Picture: Optional

Functions

- (1) Display of status of operation
- (2) Display of items of measurement and results of measurement
 - * For the measuring method, see another instruction manual.



Note: The figures on the picture indiate the maximum values of the setting range.





Display data of MESURE picture

No.	Data	11	
NO.	Designation	Unit	Description
1	WNO. (Note 1)	-	Work No. subjected to execution
2	PROCESS NO. (Note 1)	- -	No. of machining process under execution
3	TOOL NO. (Note 1)	-	No. of tool indexed and its offset number
4	BLOCK NO.	-	No. of the block being executed (EIA/ISO)
	MARKED DATA X, Z (Note 3)	mm (inch)	Target measured value (It is displayed when measurement starts.) (Note 2)
6	MEASURED POINT #1, #2	mm (inch)	Position at which the sensor made measurement.
			<pre>#1: First measured value #2: Second measured value</pre>
7	POSITION (Note 1)	mm (inch)	Current position of tool in the workpiece coordinate system.
8	MEASUR. DATA X, Z	mm (inch)	Measured value found from measurement
9	OFS AMT	mm (inch)	Difference between measured value and target value
10	MACHINE (Note 1)	mm (inch)	Current position of tool in the machine coordinate system
11	T LIM+ T LIM- (Note 3)	mm (inch)	Upper and lower limits of tolerances
12	SNS (ON) (Note 3)	mm (inch)	Diameter of sensor probe. The instant the probe is brought into contact with the workpiece, the characters "ON" are inverted. When the probe moves away from the workpiece, these characters reappear.
13	OFS TNO. (Note 3)	_	Tool No. and offset No. necessary for offset



No.	Data Designation	Unit	Description
14	FEED (Note 1)	mm/min (inch/min)	Speed of sending command to tool
15	(Process) (Note 1)	WHO IS	Machining process being executed and to be executed
16	COUNT	pcs.	Counter for judgment of execution of measurement. The data within the parentheses are the standard number of workpieces to be sampled. The data outside of the parentheses are the number of workpieces as counted from starting of execution. These values can not be counted unless the parts count data are "1". Data rewrite is valid even when the program is locked.
17		-	When measurement has been started, "MEASURING" is displayed. When measurement has been completed, it disappears.

- Note 1. Same as the data on the POSITION or COMMAND picture.
 - 2. The data are not displayed at all in case of external measurement. In other cases, the dimensions (parameters U28 and U29 in case of tool tip measurement) to which tolerances are added are displayed.
 - 3. Display is made based on the value set in the measurement process within the program.
 - 4. No data are displayed in target value (MARKED DATA),
 measurement point position (MEASURED POINT), measured value
 (MEASURE. DATA) and sensor (SNS) in case of external
 measurment.



2-3 Functions of Operation Panel Buttons

	Names		Purposes	
12-A	0//	Resetting	 o Sets NC system to initial status. o On alarm, press this button to erase it out of display after eliminating cause. o On the resetting in automatic operation, performs immediate stop and return to the head of run program. o Interrupts shape check operation. 	
10-A	° • • • • • • • • • • • • • • • • • • •	Power on Power off	o Start and end of NC/machine operation. o Validates changed parameter. (Immediately valid parameters are also available.) Handling 1 Change parameter value 2 Power off 3 Power on End Value does not become valid without this operation. o NC/machine alarm resetting	
12-B	O	OT release	o Returns stroke end turret to movable range (refer to "Cancel of Stroke End" as to handling).	
11-B		Display erasure	 o Erases display to elongate its life when it is not needed. o Erased display can be restored using any push button or any menu key. o On alarm, automatically displays its message. 	



	·	Names	Purposes
12-D	TPS	Tool path storage	o Used to replace tip on its faulure during machining. o Press this key when storing tool relief path points on the manual interrupt in automatic operation. Handling Interrupt automatic operation by the change-over to step mode or feed hold. Change-over to manual operation mode Press - current position stored Manual move of turret Replace tip Return to automatic operation mode Press (cycle start) key - operation restarted after tracing stored points. End Note: Steps 3 and 4 can be repeated until five times.
11-D	VFC	Change of machin- ing conditions	o Automatically replaces the programmed conditions stored in numerical controller with the cutting conditions changed by jog feed and spindle override in automatic operation (valide one time per process). However, not valide for EIA/ISO program.
8-A		Cycle start	o Starts and restarts operation in automatic mode.
7-A	0	Feed hold	o Automatic operation interrupt, axis-move deceleration and stop, dwell interrupt, M,S,T, or GEAR command interrupt after current run completion.



,						
	Names		Purposes			
/-B 8-b		Rapid feed override Increase Decrease		press (inc	reases or decre	10% each time of eases by 10% for each s continued for more
5−8 5−/	Increase 🏝 Decrease 🔻		o Jog (cutting) feedrate varies by 10% each time of press (increases or decreases by 10% for each 0.1 second while press is continued for more than one second). Manual: 0 - 240% 24-step rate is fixed by mm/min. or deg./m. Automatic: 0 - 200% (including automatic dry-run on)			
		Indication	Feed	(mm/min)	Indication	Feed (mm/min)
		0		0	130	52
		10		1.0	140	72
		20		1.4	150	100
		30		2.0	160	140
		40		2.7	170	200
		50		3.7	180	270
	•	60		5.2	190	370
	-	70		7.2	200	520
- 1			1		T	

	Names		Purposes		
7-F 8-F		Spindle over- ride Increase▲ Decrease▼	o Varies the revolutions of spindle by 10% each time of press. Manual: 0 - (max. revolutions of spindle in selected gear range), unit: 10 rpm Automatic: 0 - 150%		
8-D		Spindle starting	o Performs the spindle. revolutions indicated on segment indicator. Note: Valid only in manual operation mode.		
7-D		Spindle spindle stop	o Stops spindle. Note: Valid only in manual operation mode.		
8-E	0	Spindle inching	o Performs the parameter fixed revolutions of spindle only while button is pressed. Note: Valid only in manual operation mode.		
7-E	0()	Change-over of spindle running direction	o Selects the forward or revers rotation of spindle in manual operation mode.o Former is performed when power supply is on.		
Н-8		Manual pulse feed	o Fixes the amount of the pulses generated per graduation of manual handle and at the same time performs the change-over to manual operation mode (refer to "Handling		
1-H			Procedure"). Note: Do not make the change-over from auto- matic operation mode to manual operation mode while thread ridges are cut. Or, tip will fail in some cases.		



		Names	• Purposes
1-8	0~	Rapid feed	o Move at rapid feedrate.
1-L		Jog (cutting) feed	o Move at the rate corresponding to the segment value of feed override.
7-J	0	Zero-point return	o Performs the change-over to manual operation mode and validates the functions of axis-move keys. Note: After power on and emergency stop, be sure to return the dog to zero-point before operation.
7-8	0	Auto	o Change-over to automatic operation mode. Handling Set work number using menu. Press (reset) key. Press (cycle start) key. End Selected work number program will then be run
			from beginning. Note: Operation is not valid with WORK PROGRAM, LAYOUT, SIMULATION, SHAPE CHECK and CHECK pictures.
7-L	OMI	Restart	o Used to start the machining interrupted due to circumstances halfway. Notes 1: Workpiece number must be selected when in automatic mode. 2: Valid only with POSITION, COMMAND
			and TRACE pictures.



		Names	Purposes
8-K	0	Single process	O Runs only the selected process in program. Handling Select the process to be run from menu (rough, finish or re-finish machining).
			Select the number of the process to be run. 3 Press (cycle start) key. End
			Only selected process will then be run. Notes 1: Select work number in automatic
			mode.
			2: Valid only on POSITON, COMMAND or
			TRACE display.
	·		3: Re-finish can be selected only for
			threading process and only its last
			step is performed.
7-K	°Ф	Test	o Used for maintenance and test.
6-A	О х	Selection of manual pulse	o Selects the valid axis of manual pulse generator.
Z-9	O z	Selection of manual pulse Z-axis	o Selects the valid axis of manual pulse generator.
Q-9	0	Handle interrupt on	o Shifts work coordinate system over the distance corresponding to the amount of the pulses generated on the interrupt by manual pulse generator in automatic operation. Note: Use parameter P12 when fixing the shift distance per pulse.



	Names		Purposes		
5-D	O_H	Handle interrupt off	o Completes handle interrupt function. Note: Pressing this button will protect the duration of the interrupt.		
6-E		Parts catcher forward (optional)	o Used to forward parts catcher.		
5-E		Parts catcher reverse	o Used to reverse parts catcher.		
6-F		Bar feeder on (optional)	o Used to start bar feeder mode.		
5-F		Bar feeder off (optional)	o Used to complete bar feeder mode.		
9-9		Steady rest l clamp (optional)	o Used to clamp steady rest l.		
5-G	0	Steady rest 1 unclamp (optional)	o Used to unclamp steady rest 1.		
H-9		Steady rest 2 clamp (optional)	o Used to clamp steady rest 2.		
5-H	0	Steady rest 2 unclamp (optional)	o Used to unclamp steady rest 2.		



		Names	Purpose	s
I-9		Tool swing	o Tool number is select button is released it o V/H change-over type time of starting.	_
1S	0⁄2	Selection of turrets	o Change-over between front and rear turrets manual mode. o V/H change-over type: select either of 0 horizontal type 2 vertical type o Change-over between ID and OD cutting too	
			O Horizontal type Front turret OD cutting	Vertical type Rear turret ID cutting is selected on the start
f-9		Tail body	out to connect tail Notes 1: Invalid whe	rned on, joint pin comes body with turret. en self-move tail body is in manual mode.
5-J		Tail body connection on/off	Notes 1: Invalid whe	tail body connection. en self-move tail body is in manual mode.
		·		



		Names	Purposes
3-н	0	Tail body forward	o Forwards tail body. Once this button is pressed, it continues forwarding unless tail body stop or reverse button is pressed and stops at stroke end.
			Notes 1: Invalid for connecting type tail spindle. 2: Valid only in manual mode.
3-I	0	Tail body stop	o Stops the operation of tail body. Notes 1: Invalid for connecting type tail spindle. 2: Valid only in manual mode.
3~J		Tail body reverse	o Reverses tail body. Once this button is pressed, it continues reversing unless tail body stop or forward button is pressed and stops at stroke end. Notes 1: Invalid for connecting type tail spindle.
1-H	0	Tail spindle forward	2: Valid only in manual mode. o Forwards tail spindle. Once this button is pressed, it continues forwarding unless tail spindle stop or reverse button is pressed and stops at stroke end. Note: Valid only in manual mode.
1-1	0	Tail spindle	o Stops the operation of tail spindle. Note : Valid only in manual mode.
·			



		Names	Purposes
1-1		Tail spindle reverse	o Reverses tail spindle. Once this button is pressed, it continues reversing unless tail spindle stop or forwared button is pressed and stops at stroke end.
		`	Note : Valid only in manual mode.
No.2 2-F	Lathe OX AXIS Z AXIS Z AXIS X X	X-axis move (up and down) Z-axis move (right and left)	o In manual mode, performs the move along pressed key axis only while key is kept pressed. o No move is performed when both up and down or right and left move buttons are turned on at a time.
No.1 2-F	Vertical lathe X AXIS SELECT X Z	X-axis move (right and left) Z-axis move (up and down)	Notes 1: Valid only in manual mode. 2: Axes are independent from each other.
11-H to 10-K	0	Numerals	Twenteen numeral keys [0, 1, 2, 3, 4, 5, 6, 7, 8, 9, ., - are provided for the input of numeral data. Distance data are fed with decimal point by millimeter, inch or deg.
11-L	0	Clear	o Cancels data entered at data setting part. o Press this key to erase the message after removing its cause.



		Names	Purposes
10-T		Input	o Inputs data etered at data setting part into data indicating part.
5-K	LOCK ENABLE	Program rewrite lock/enable	o No data rewrite is possible when inserted key is set to LOCK side. See Annex 9-4.
2-L	RESET	Emergency stop button	o Used on machine malfunction or abnormality. Note: Be sure to return the dog to zero-point after cancelling emergency stop.
2-3		Manual pulse generator	 o Valid when manual mode and handle interrupt are on. Subjects machine to fine feed when its handle is turned. o When the handle is turned in automatic machining operation, coordinates are shifted correspondingly to turned angle from the
			position fixed by block command. Note: The pulses generated per graduation amount to parameter P12 fixed value.
13-A		Picture selection	o Used for the change-over of a picture to another. Press the menu key for the picture to be displayed after this key. Corresponding picture will then appear.
		•	



	Name	Purpose		
M	Menu selection	o Used for the change-over of menu display. Note: Changeable menus are limited to the ones usable in each status. For example no manual operation menu is displayed even if this key is presse in automatic operation mode.		
°C C	Cursor call-up and shift (up, down, right, left)	o Used to set or shift the cursor in the display. Note: The cursor shifts continuously while this key is kept pressed.		
, (†)				
	•			
		•		



	Names		Purposes	
1-5		Magazine ATC position (ATC type)	o Index a tool selected by operation button (on another board) to ATC position.o Selects magazine swing position in manual operation.	
Magazine 5-I		Magazine tool mounting location (ATC type)	o Index a tool selected by operation button (on another board) to tool mounting location. o Selects magazine swing position in manual operation.	
5-J		Magazine swing (ATC type)	o Magazine swing command o Valid only in manual mode.	



Vertical lathe operation buttons

,		Names	Purposes
3-н	₹	Cross rail up (ATC type)	o Selects cross rail up mode in manual operation.
Cross rail		Cross rail down (ATC type)	o Selects cross rail down mode in manual operation.
3-J		Cross rail starting (ATC type)	o Shifts cross rail. Five stop positions are provided. One-position shift per press time. Note: Valid only in manual mode.
1-H		Chip scraper forward rotation	o Rotates chip scraper in the reverse direction when viewed from downward to discharge the cutting chip on chip cover into chip pan or chip conveyor.
1-I	0	Chip scraper	o Stops chip scraper.
<u></u>	0	Chip scraper reverse rotation	o Rotates chip scraper in the forward direction when viewed from downward.
9-E	0	Table orienta- tion (optional)	o Orientation of table (spindle). o Valid when selecting C-axis or in manual mode.
	·		



		Names	Purposes
5-E	о *	Mill spindle orientation	o Orientation of mill spindle. o Valid in milling mode or in manual mode.
6-F	0	Magazine cover open (ATC type)	o Used to open magazine cover during ATC. o Valid only in manual mode.
, 5-F	0	Magazine cover close (ATC type)	o Used to close magazine cover on the comple- tion of ATC. o Valid only in manual mode.
9-9 ·		Chuck loosening (optional)	o Loosens hydraulic chuck if any. o Unclamps pallet if pallet changer is provided.
5-G		Chuck tightening (optional)	o Tightens hydraulic chuck if any. o Clamps pallet if pallet changer is provided.
Н-9		Turret forward rotation (turret type)	o Forward rotation of turret in manual operation.
Turrer 6-I	0	Turret reverse rotation (turret type)	o Reverse rotation of turret in manual operation.
6-J	0	Turret swing (turret type)	o Turret swing command. o Valid only in manual mode.

Mazak -


Lamps	Functions	Purposes	Remarks
READY	Preliminary setup completed for operation	o On when machine is operable (green). Notes 1: Off on emergency stop. 2: On 4 sec. after power on.	
6 BUSY	Arithmetic opera-	o On in machining program arithmetic operation (green).	
% P. HEAD	Program head	o On only when NC system is reset in automatic mode (green). Indicates that run is possible starting from program head.	
→ P. END	Program end	o On only when program run is completed (green). Note: Instantaneous lighting since program run position is reset to head at same time as completion.	
TURRET	Tool swing	o On while a tool is in the tool swing position in auto-matic mode (green).	
? MC ALM	Machine alarm	o On upon machine side alarm (red).	
? TOOL ALM	Tool alarm	o On upon tool life alarm (red).	·



Lamps	Functions	Purposes	Remarks
? NC ALM	NC alarm	o On upon NC system alarm (red).	
+ z home	X-axis zero-point	o On when X-axis is at machine zero-point (green).	
Т х номе	Z-axis zero-point	o On when Z-axis is at machine zero-point (green).	
COUNT	Parts count-up	o On while the work counter that can be set using POSITION or COMMAND picture performs count-up in automatic operation (green).	

3. FOR OPERATION BEGINNERS


A variety of operations are necessary after machine installation and adjustment until the completion of products. Flow-diagrammed below is the main handling steps until starting automatic operation.




- A: New work machining
- B: Continuous work machining


The diagram roughly shows flow. Refer to the corresponding descriptions made in accordance with the diagram for further details.

Mazak -




- o READY (preliminary setup completed for operation) lamp on.
- o POSITION picture appears on display.
- o (zero-point return) key lamp turns on and the message "HOME RETURN?" is displayed.






Refer to Programming
Manual in separate volume.










- o Check that X HOME, Z HOME(zero-point return) lamps,
 | READY (preliminary setup completed for operation)
 lamp and % P. HEAD (program head) lamp are on.
- o Check tool setting and Z-offset again.
- o Press 🥢 (reset) key.





- 9) End of automatic operation

 Automatic operation end
 - o \bigcirc (cycle start) key lamp off
 - o | P.END (program end) lamp instantaneously on.
 - o %P.HEAD (program head) lamp on
 - o Turret is at tool change position.


^{*} Repeat steps 8) and 9) when continuously machining work.

4. MANUAL OPERATION

4-1 Stop of Machine Operation

Emergency machine stop is necessary in some cases during machine handling or automatic operation.

(1) Emergency stop button Stops all operating commands in either manual or automatic mode.



- o The same position as that on power supply is obtained if | READY (preliminary setup completed for operation) lamp on after cancel.
- o The machine is in an alarm condition if READY (preliminary setup completed for operation) lamp does not come on. In this case use DIAGNOSIS picture for check.
- (2) (reset) key
 - o All axes and spindle stop in the %P.HEAD (program head) position when this key is pressed in automatic mode operation.
 - o Alarm can be cancelled using this key.
 - o If alarm occurs again after cancel, press (reset) key after locating the cause once more.





- (3) Manual mode change stop
 - o The axes and spindle stop when changing to manual mode in automatic operation.
 - Note 1: Automatic operation continues if the automatic mode is selected and (cycle start) key is pressed.
 - Note 2: Coordinate system deviates when a move is performed along axes after changing to manual mode.
- (4) O (power on) key stop

 Stops the machine by cutting off the NC power in manual or automatic mode. This method however puts the spindle in a free run condition. Therefore, it takes a few moments until the spindle stops.



NOTE:





Indication MACHINE LOCK appears when MACHINE LOCK menu key is pressed.

Such character highlighting by a key press is named inverting.

Press MACHINE LOCK once more. It will then be reset.

Note that for the following description.

4-2 Zero-Point Return

Zero-point return is an important handling for storing the turret (tip) position i.e. machine zero-point in the numerical controller. Perform the following zero-point return steps when the message "HOME RETURN?" is displayed.


Handling

1

2

Press (zero-point return) key.

- o Zero-point return mode is automatically selected when the power is turned on.
- Move the turret to the possible zero-point return range using an axis-move key.
 - o Universal type: do not cause the interference between the tail body and the turret.



- Move the turret in the zero-point return direction using an axis-move key.
 - Return axis zero-point indicator lamp on.
 - X HOME (X-axis zero-point)
 - Z HOME (Z-axis zero-point)


End

4

Note 1: When the simulation is valid, \bigcirc Z HOME and \bigcirc X HOME (zero-point) indicator lamps do not come on even if the turret is at the zero-point.

Note 2: When decelerated during zero-point return, the axis will not move in the opposite direction but will continue to return until it reaches the zero-point even though in or in the axis will move in the commanded direction at the rapid feed.

Note 3: Zero-point return rate pattern:



(1) Rate before reaching the zero-point dog during the initial zero-point return

Initial zero-point return rate = RF * A3 /100

RF, A3 are fixed by MACHINE PARAMETER.



(2) Rate after reaching the zero-point dog during the initial zero-point return

Zero-point approach rate = MACHINE PARAMETER

[DF]

(3) Rate after the zero-point return


MACHINE PARAMETER RF

Rapid feed override will not be valid for the first zero-point return.

Note 4: If the turret is located near the zero-point return position, the zero-point return can also be performed by the cradle method i.e. to return the turret to the zero-point position after moving it opposite to the zero-point return direction using an axis-move key. However, pay much attention in doing this.

4-3 Rapid Feed

Used to move the tool rapidly mainly to obtain an easy access position or to approach the work for simple cutting in the manual operation.



Note 1: Refer to the Specifications for the maximum rapid feedrate.

Mazak —

4-4 Jog Feed

Used for standard work skin cutting, simple jig and other machining.

Handling	
1	Press w (jog feed) key.
2	Adjust feedrate per minute after pressing (jog feed override) key.
	Feedrate is indicated as
	illustrated below.
3	Check that there is no obstacle on the move axis and in
	the move direction; keep the axis move key pressed until
·	the target position is reached.
	o Step 2 can be performed during the move.
End	

Note 1: The following table lists the feedrate codes.

Jog feed override and actual move rate

Indication	Feed (mm/min)	Indication	Feed (mm/min)
0	0	130	52
10	1.0	140	72
20	1.4	150	100
30	2.0	160	140
40	2.7	170	200
50	3.7	180	270
60	5.2	190	370
70	7.2	200	520
80	10	210	720
90	14	220	1000
100	20	230	1400
110	27	240	2000
120	37		



4-5 Manual Pulse Feed

Performed to position the tool edge accurately, and to cut the work while finely varying the feedrate.

Handling

Press and mx (manual pulse feed) keys.

o Manual pulse feed keys - and and - are used to fix the relative magnification of move distance to the graduation value on the manual pulse generator.

o Press and release both and keys when turning them on at the same time. This operation is valid only when both key lamps are on.


Select the move axis using $\begin{bmatrix} X \end{bmatrix}$ and $\begin{bmatrix} Z \end{bmatrix}$ (axis select) keys.

Turn (manual pulse generator) toward the move direction.

End




Relationship between the manual pulse generator magnifications



Note: No pulse feed is possible using the axis move key.

4-6 Stroke End Cancel

Generally, the corresponding axis cannot be moved when the alarm "109 STROKE END XX" is generated by the turret leaving the movable range. The move is made possible and the alarm is cancelled by following handling.






Note 1: The X- and Z-axis stroke end position means that the turret has reached the machine safe operating limit.

Normally no stroke end position is obtained since NC supervision (soft) limit is less.

Relationship between the stroke end and the soft limit



Limit fixed using the OT limit switch (stroke end)

Some models do not have this function.

NC supervision (soft) limit fixed in accordance with

MACHINE PARAMETER B1 to B4.




4-7 Spindle Gear Selection

Used for changing to the desired spindle gear number.

No spindle gear number has been selected so no rotation is possible immediately after turning the power on.

To select the gear number, therefore, perform following handling.



Note 1: Refer to the Specifications for gear numbers.

4-8 Spindle Start

Used to turn the spindle when jaw forming, tool edge position measuring or machine testing, etc.

Handling

1

2


Note the POSITION or COMMAND picture to confirm that the proper gear is selected.

- o The speed varies depending on the selected gear (refer to the Specifications).
- o Refer to Spindle Gear Selection.

Select the run direction by pressing the C (run direction change) key.


- o Key lamp off: forward rotation ©
- o Key lamp on: reverse rotation 🖰
- o When turning, the spindle stops if this key is pressed.

Reverse rotation



Forward rotation






- Note 1: The speed can be increased or decreased by the spindle override key even while the spindle is turning.
- Note 2: The spindle does not turn when the override indication is "0". Note this when the spindle start key has already been pressed.
- Note 3: The maximum revolutions vary depending upon the specifications of the machine.
- Note 4: Do not press the (spindle inching) key while the spindle is turning. If pressed, the speed will be changed to inching.

4-9 Spindle Stop

Used to stop the spindle rotation.




Note 1: The revolutions indicated on the spindle segment do not vary even after it stops.

_	SPINDLE
	$\boxed{0}\ \boxed{1}\ \boxed{5}$

4-10 Spindle Inching

Performed to turn the jaw to an easy-to-handle position for fitting or removal.




Note 1: Spindle stops when the (crun direction change) key is pressed during inching.

Note 2: Spindle inching speed is set at approximately 1 percent of the maximum r.p.m. of the selected gear.

Mazak —

4-11 Turret Unclamp

Performed to change the inside parts, alignment, adjustment of the turret and other maintenance.



Note 1: This function continues unless the invert is cancelled by pressing this key again.


Note 2: The turret unclamp procedure will vary depending on the model.



4-12 Tool Swing

Used to swing the turret for tool mounting/detaching, tool nose position measurements, etc.


Single turret type:



Note: Be cautious lest the tool should come into collision with the chuck or workpiece while swinging.

It is recommended to move the tool to a safety zone in advance at the rapid feed.

Double turret type:




Note 1: The operation may vary depending on the model.



4-13 Machine Protection

Used to prevent one turret from intefering with another for machine with two turrets.

Applicable models: M4, M5, P.M., etc.




- o For further information on the machine protect function, see the Operating Manual of the respective model.
- o The PROTECT menu key is provided only for double-turret models.



4-14 Tail Stock Move

Tail stock performs self or non-self move.

Self move type - tail body move:



Note 1: Pressing and at the same time will result in the (tail body stop) state.

Note 2: Inching is not possible by either $\stackrel{\circ}{\leftarrow}$ or $\stackrel{\circ}{\leftarrow}$.


Note 3: When the tail body reaches the forward or reverse end,

will be effective automatically even pressing

or or , and the tail body will stop.

Note 4: For further information, see the Operating Manual of the respective model.

Self move type - tail spindle move:




Note 3:

For further information, see the Operating

Manual of the respective model.




Non-self move type:



- Note 1: When moving the Z-axis, pay attention so that the turret will not interfere with the tail body.
- Note 2: Tail body move is effective only with the jog feed.
- Note 3: For further information, see the Operating Manual of the respective model.


4-15 Lighting

Used to turn the machine work lamp on or off.



4-16 Coolant


Used to start or stop the cutting fluid.



Note 1: Begin this procedure after filling the coolant in the machine.

4-17 Machine Lock

Performed to check a program by running without actual machining for fixing the turret in the current position. Move for ATC operation: once the machine lock is cancelled, the axis move is performed, and after the ATC operation is completed, the machine lock position is selected again.





Note 1: The machine lock is a condition made mechanically. Its internal processing does not differ from normal. The coordinate value, tool picture and other display data vary from time to time depending on the control.

Note 2: The operation is interrupted if the procedure is performed. By pressing the (cycle start) key, however, it can be restarted with the machine lock position maintained.

If the machine lock is cancelled during the operation, the turret will start to move as soon as the distribution of moving blocks is completed. At this time, however, the coordinates deviate by the distance corresponding to the shift in the numerical controller during machine lock. Therefore, be sure not to turn the machine lock on/off during operation, otherwise, the machine will jam.


Note 3: If the machine lock is turned on while decelerating during the return to zero point, the machine-lock condition will not occur immediately, but only after returning to zero point.



5. DISPLAY DATA

Outline

When machining materials, it is very important to prepare a suitable program. To execute the program, it is prerequisite beforehand to store the necessary data in the NC. These data include information on the tools, chuck and tailstock. In this Chapter, how to set data is described according to the following sequence:



5-1 TOOL FILE Picture

Performed to set the shape data of the tools to be used for machining work or to be stored in the numerical controller in advance.

A total of 64 tools - 16 x 4 (pictures) - are registrable. To change displays, press |PAGE| menu key, and the next page will be displayed.


Setting items:

FNO.	SHAPE	HLDR	DEP-ANG	CUT-ANG	WIDTH	PITCH
1	MDL-OUT	4	0	0	0	0
	(a) (b)	(c)	(d)	(e)	(f)	(g)

Call up - (cursor) and set above one by one.

(a) TOOL DATA SHAPE (MENU)?: setting should be performed using the general names of the tools to be registered.

When TURNING was selected in response to "WHICH TYPE OF TOOL (MENU)?":





One should be selected.

- (1) GENERAL TURNING: general machining tool
- (2) GROOVE:

grooving tool

(3) THREAD:

threading tool

(4) DRILL:

lead hole cutting drill

(5) TAP:

tapping tool


(6) TOUCH SNS:

special tool for coordinate measuring



(b) TOOL MACHINING PART (MENU)?: tool cutting range of work is registered.


When TU	RNING was	selected:			
OUTER DIAMETER	INNER DIAMETER	EDG		TOOL DATA	PAGE
ę	2	·			
	Select o	ne.			






(c) TOOL HOLDER TYPE?: 1-digit input of tool holder by using 0 to 4 ten-keys. This registration sets holder barrier.

Barrier setting range:






Above case: holder type 1

All B17 to B32 should be set using PARAMETER (MACHINE) (refer to Parameter). Holder types are set as tabulated below using parameters.


Holder type	PARAMETER	(MACHINE) set	ting points
	A	В	©
0	I	Holder absent	
1	B21	В22	В23
2	B24	В25	. в26
3	B27	B28	В29
4	в30	B31	В32

(d) CUTTING ANGLE (DEPTH)?: Set the main cut angle, maximum grooving depth or first cutting depth in the milling mode such as GNL, GRV, THR, etc. using ten-keys.

Example




(e) CUTTING ANGLE (WIDTH)?: Set the nose (tip) angle of tool or the nose width of grooving tool such as GNL, GRV, THR, etc. using ten-keys.



Note 1: If this data is not set, alarm "333 ILLEGAL GROOVE WIDTH" occurs.



(f) TOOL SHANK WIDTH/DIA.?: Set tool shank width such as GNL, GRV,
THR, *TOUCH SNS, *CHIP VACUUM, etc.
using ten-keys. (*: optional)




- (g) PITCH?: Set the pitch of THR, TAP, MTP and other tools using ten-keys. Setting is possible up to fifth decimal digits.
- Note 1: The tool shapes on SIMULATION and TRACE disdplays depends on the cut and nose angles fixed in TOOL FILE display. They are classified into the types tabulated below because they considerably vary.

Mazak —

Example: slant type GNL, reverse rotation left hand cutting.


	OUT	IN	EDG
$A \leq 72.5$ $B \leq 60$			
72.5 < A < 105 B < 60			7
72.5 < A < 105 B ≥ 60			
A ≥ 105 B < 60			
A ≥ 105 B < 60			



A: Cut angle

B: Nose angle


Note 2: No chip display is given for forward rotation right hand cutting.



Mazak -

TOOL FILE CANCEL operation

To cancel the already entered tool file number data, use the following procedure.




Note 1: For T-2 specification macines: data entered in response to "SHAPE DATA OF TOOL (MENU)?".

Mazak ·

ALL ERASE operation

To cancel all tool files, use the following procedure.



Note 1: Entering other number than "-9999" will cause the alarm "401 INPUT FOMAT ERROR" (bleu).

5-2 TOOL DATA Picture

Should be used to set the shape of machine fitting tool, tool control data and spare tool data.

The data of up to 64 tools - 16 tools x 4 (pictures) - can be set although this quantity depends on NC fitting models.

To change displays, press PAGE key, and the next page will be displayed.

Setting items:

TNO.	FNO. SHAPE	NOSE-R	FWD/REV	R/L	SPARE-	LII	FE	USE	ED
0					TOOL	TIME	NUM	TIME	NUM
1	14 GNL-OUT	0.4		LEFT	3-1(0)	80	130	4	15
(a)	(b)	(c)	(d)	(e)	(f)	(g)	(h)	(i)	(j)

Set the following one by one using cursor:-

(a) TOOL DATA MOVE (MENU)?: Perform following handling when replacing all tool number data on TOOL DATA display.

Following menus are displayed.

T DATA MOVE	T DATA	TOOLDATA CANCEL	TOOL FILE	PROGRAM	PAGE	
----------------	--------	--------------------	--------------	---------	------	--

Press T DATA MOVE .


T DATA		T DATA	TOOLDATA	,	TOOL	PROGRAM	PAGE
MOVE		V	CANCEL		FILE		

TOOL NO?: Set the number of the tool to be replaced uisng ten-keys.



(b) TOOL FILE NO.?: Set the tool file number registered on TOOL FILE display.

(c) NOSE RADIUS?: Set the radius of the nose of GNL and TOUCH SNS.




Set data are valid only for MAZATROL programs.

(d) SPNDL ROTATION FWD/REV (MENU)?: After selecting tool, select its spindle running direction from menu.


FWD	REV	CANCEL		TOOL FILE	PROGRAM	PAGE
		,			,	

Select one.

Reverse rotation



Forward rotation





(e) RIGHT/LEFT HAND (CUT)
(MENU)?:

Set the cutting hand direction of fitted tool such as GNL, GRV, THR, etc.

RIGHT HAND	LEFT HAND	CANCEL			TOOL FILE	PROGRAM	PAGE
			•				

Select one.

Use CANCEL menu key to cancel RIGHT HAND or LEFT HAND data already entered.

Left Right

Set data influence simulation tool shape and path data.

(f) SPARE TOOL NO?:

Not used.

TOOL OFFSET NO?:

Not used.

TOOL OFFSET NO(EIA)?:

Not used.

(g) TOOL LIFE TIME (MIN.)?: Set maximum operable time.

This setting by minute is internally processed by second. Setting range:

0 - 999. When the setting is "0",

lifetime control becomes invalid.

(h) MAX NUMBER OF WORKPIECES?:

Set maximum cutting number.

Setting range: 0 - 999. When the setting is "0", lifetime control becomes invalid.



(i) TOOL CUTTING TIME
 (MIN.)?:

The operation time of the tool in cutting feed is measured by second and indicated by minute.

When TOOL DATA picture is selected, internal measuring continues although no count indication is performed.

When lifetime setting data are reached, display is inverted and alarm "152 TOOL LIFE TIME ERROR (TIME)" is generated. (Note 1)

(j) WORKPIECE NO. TO BE COUNTED?:

Displays cutting times.

When TOOL DATA picture is selected, internal count continues although no count display is performed.

When life quantity setting data are reached, display is inverted and alarm "151 TOOL LIFE TIME ERROR (NUMBER)" is generated. (Note 2)

- Note 1: Data change is possible only when TOOL LIFE TIME (MIN.)

 TOOL CUTTING TIME (MIN.) Former can however be set to
 "O".
- Note 2: Data change is possible only when MAX NUMBER OF WORKPIECES > WORKPIECE NO. TO BE COUNTED. Former can however be set to "0".



Automatic Spare Tool Change Function

- o There are four methods for changing tools automatically.
- (1) Without indexing spare tools:

 Input "0" to parameter P4.
- (2) Changing depending on the number of workpieces machined: Input "1" to parameter P4.
- (3) Indexing by controlling the total operation time:
 Input "2" to parameter P4.
- (4) Changing by controlling OFFSET-MAX:

 Input "3" to parameter P4.

 However, the method (4) must be used together with the automatic tool measurement (MMS, tool tip measurement).
- Note 1: To carry out indexing depending on the number of workpieces machined (P4 = 1):

 If the service life has been entered and expires before all workpieces are machined, no spare tool will be indexed and the alarm "152 TOOL LIFE TIME ERROR (TIME)" will be displayed.

 This also applies to indexing by controlling the total operation time.

 Normally enter "0" to the service life of the tools not used to control the indexing.
- Note 2: Up to 8 spare tools can be indexed.
- Note 3: If 9 spare tools have been entered in the change depending on the number of workpieces, the eighth tool will be used to machine an additional workpiece.

 Therefore, be sure to index no more than 8 tools.



Example:

o Indexing depending on the number of workpieces machined (P4 = 1)
TOOL DATA picture

When the number of workpieces machined (USED NUM) of TNO. 1 becomes "5", TNO. 7 is automatically indexed from the next program.



TOOL DATA Picture - Supplement

Tool data exchange

The tool data registered on this picture are easily replaceable with other ones by following handling.

Handling				
1	Shift cursor to the tool	TNO.	FNO.	SHAPE
	number to be replaced.	1	14	GNL-OUT
		2	10	GRV-OUT
		3	21	GNL-IN
		4	6	TAP
2	Press T DATA MOVE.			
3	Set substitute tool number			
	in response to "TOOL NO?"			
	using ten-keys. If sub-			
	stitute tool number is "1"			
	for example, press 1 and (input).			
	<u> </u>	ø-		
4	TNO. 4 data are replaced	TNO.	FNO.	SHAPE
	with TNO. 1 ones.	1	6	TAP
		2	10	GRV-OUT
		3	21	GNL-IN
		4	14	GNL-OUT
End	·)			



Tool data cancel

Carry out following handling when cancelling registered tool data for each TNO.

Handling 1 Shift cursor to TNO. for TNO. FNO. SHAPE which tool data are to be 1 14 GNL-OUT 2 cancelled. 10 GRV-OUT 3 21 GNL-IN 6 TAP Press TOOL DATA CANCEL .. (input) in response to "TOOL DATA CANCEL (INPUT)?". 4 All tool data at the cursor TNO. FNO. SHAPE position are cancelled. 1 14 GNL-OUT 2 3 21 GNL-IN 6 TAP

End

Mazak —

All tool data erase

Used to erase all tool data.

Handling	•
1	Press ALL ERASE menu key.
2	Respond to the message "ALL ERASE (-9999 INPUT)?" by pressing -, 9, 9, 9, 9 and (**) (input) keys. All tool data are erased.
End	

Note 1: Entering other number than -9999 will cause the alarm "401 INPUT FORMAT ERROR" (blue).



35

(e)

CHUCK JAW DATA Picture


Stores 16 kinds of chuck (jaw) shape data.

Registered data influence the chuck shape display on CHUCK BARRIER and SIMULATION pictures.


Up to 16 kinds of data can be set.

Picture selection order:

Setting items:




(a) CHUCK JAW TYPE (MENU)?: Chose either outer or inner diameter jaw of chuck from menu.



- (b) JAW DIMENSION A?
- (c) JAW DIMENSION B?
- (d) JAW DIMENSION C?
- (e) JAW DIMENSION D?
- Set the length defined on picture using ten-keys.

Mazak -



- Note 1: Type display data are not erasable. Therein, set DIM-A to DIM-D to "0".
- Note 2: Length data are not registered if they are absent. No correct display is performed on the graphic write for example of chuck shape.
- Note 3: Second decimal digit cannot be entered (millimeter).

Mazak —

Chuck data cancel

Used to cancel chuck data stored by JAW NO.


1	Move the cursor to	JAW NO.	TYPE	DIM-A	DIM-B	DIM-C	DIM-I
	JAW NO. whose chuck	1	OUT	30	15	30	30
	data are to be	2	IN	30	15	30	30
	cancelled.	3	OUT	30	15	30	50
2	Press CHU. DATA CANCEL	menu key	•				
3	Press CHU. DATA CANCEL			CEL (II	NPUT)?'	" by	•
	' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	CHUCK DAT		CEL (II	NPUT)?'	" by	•
	Respond to the message "	CHUCK DAT	A CANO				DIM-I
3	Respond to the message "pressing 🏐 (input) key	CHUCK DAT.	A CANO				DIM-I 30
3	Respond to the message "pressing (input) key All tool data at the	JAW NO.	. CANO	DIM-A	DIM-B	DIM-C	

5-4 TOOL SET Picture

For the control and setting of machine fitting tool coordinate system data (so called tool setting value and tool offset data (X-and Z-axis independent, two kins can be set)). For tool setter, see the Instruction Manual of Optional Functions.

Setting items:


- (a) TOOL NO?: Set tool number using ten-keys.
- (b) TOOL SET-X (TEACH MENU)? | Set TOOL SET-X and -Z. (c) TOOL SET-Z (TEACH MENU)?
- * Supplement Tool set and coordinate system



"Tool set" is setting the coordinate system for machine and program zero points by using TEACH function.



Tool setting (turning):



Be sure to confirm
that zero-point return
is completed. When
is pressed, a
coordinate system
ranging between
machine and program
zero-points is set up
only for selected
tool.

When setting tools, observe the tool preconditions given in the following table. Setting tools in positions other than those illustrated will cause improper machining or a displacement of the display or barrier.

The symbol "." denotes the tool setting position.

GNL-OUT	GNL-EDG	GNL-IN	
GRV-OUT	GRV-EDG	GRV-IN	
THR-OUT	THR-EDG	THR-IN	

TAP

SNS-OUT

SNS-EDG

- (d) TOOL OFFSET-X?
- (e) TOOL OFFSET-Z?
- (f) TOOL OFFSET-X?
- (g) TOOL OFFSET-Z?

Set tool wear offset value. OFFSET-1 and -2 are valid only for MAZATROL programs. The data of the offset number set in programs are valid.

Note 1: X-axis: diameter input

Note 2: Setting range:

OFFSET-1

< OFFSET-MAX

OFFSET-2


Note 3: Offset data: incremental input

Data will be cleared only when "0" is entered.



Example of setting OFFSET-1 and TOOL OFFSET-X

TOOL SET picture when machining:



(Program specified value) - (Workpiece measuring value) =

TOOL OFFSET

50.0

50.24

= -0.24



Note 1: If offset amount has exceeded OFFSET- MAX in case the measuring fonciton (optional) is provided, data background is displayed in purple to indicate that limit value is reached.

Alarm "402 DATA INADEQUATE" is displayed if the data set on OFFSET-1 and -2 have exceeded OFFSET-MAX set value.


When clearing data, press $\boxed{0}$ and $\boxed{\hat{}}$.

- (h) MAXIMUM X OFFSET VALUE? Set the absolute limit value of offset amount.
- (i) MAXIMUM Z OFFSET VALUE? | Setting range: 0 99.999
- Note 1: If OFFSET-MAX is set to "0", OFFSET-1 and -2 data become valid but neither alarm 402 nor limit value reach are displayed.
- Note 2: The TOOL SET-X for turning drills and taps should be set using machine stroke value as minus data.

Mazak -

Erasing all tool settings

Used to erase all tool settings.



Note 1: Entering other number than -9999 will cause the alarm "401 INPUT FORMAT ERROR" (blue).



5-5 PROGRAM FILE Picture

Used to set the reference work zero-point offset (Z-OFFSET), chuck barrier reference point (CHUCK-X, CHUCK-Z), jaw number and the length of tailstock projection. Transfer, erase or name of program No. may also be entered.

Setting items:

NO.	WNO.	BLOCK	Z-OFFSET	CHUCK-X	CHUCK-Z	JAW NO.	TAIL STOCK	NAME
1	1234	56 M	-10.5	180.	-115.	Z	0	ABCDEF12345
(a)	(b)	(c)	(d)	(e)	(f)	(g)	(h)	(i)

- (a) NO.: displays the number in PROGRAM FILE picture.


 Sixteen programs Nos. 1 through 16 can be displayed.
- (b) WNO.: displays work number prepared in WORK PROGRAM picture.
- (c) BLOCK: displays the quantity of the blocks of prepared program. M (blue) is displayed for MAZATROL program, while E (red) for EIA program.

When cursor is called up, following messages are displayed and descriptions are made as to setting data.

(d) Z-OFFSET (TEACH)?: Set Z-offset. It is the distance between tool setting reference program zero-point and machining program zero-point. With Z-offset, no tool setting is necessary when program zero-point is changed in the Z-direction.



o Example of setting Z-offset



Handling 1: No Z-offset value is calculated

Move the tool set at reference program zero-point (1) to machining program zero-point (2).

Press Z-OFFSET TEACH, 0 and $\hat{} \Rightarrow$.

"-50" is set at Z-OFFSET in the picture.

Handling 2: Z-offset value is calculated

Press __, 5, 0 and 🏵 using ten-keys in response to "Z-OFFSET (TEACH)?". In this case, Z-OFFSET TEACH cannot be pressed.


Note 1: No Z-offset is necessary for X-axis direction.

Note 2: Normally Z-offset funciton is not available for EIA/ISO programs, but available in the G53 mode.

- (e) CHUCK BARR REF PT-X (TEACH) ?
- (f) CHUCK BARR REF PT-Z (TEACH) ?

Set the reference point of the length data set in CHUCK JAW DATA picture.

Mazak



Outer jaw

Inner jaw

Program zero-point

.... Chuck barrier reference point

Handling 1: No chuck reference point is obtained

Move the tool set at reference program zero-point to the chuck barrier reference point illustrated above.

Press C-BARRIER TEACH, 0 and in response to "CHUCK BARR REF PT-X (TEACH)?". CHUCK-X in picture is set to "100".

Carry out the same input in response to "CHUCK BARR REF PT-Z (TEACH)?". CHUCK-Z in picture is set to "-50".

Handling 2: Chuck reference point is obtained

Press 1,0,0 and in response to "CHUCK BARR REF PT-X (TEACH)?".

Press -, 5, 0 and → in response to "CHUCK BARR REF PT-Z (TEACH)?".



Note 1: Machine stops without entering chuck barrier but its stop position depends on axis move rate. It is desirable to give allowance in setting barrier.

Note 2: Barrier fucntion becomes invalid if BARRIER CANCEL is selected in POSITION or COMMAND picture.

Note 3: Barrier function is valid in all modes and pictures.


Note 4: Data in X-axis direction is set as diameter value.

(g) JAW DATA NO. (CHUCK DATA)?: Set the jaw number registered in CHUCK JAW DATA picture.

Therein enter numerals using ten-keys.

Reference: Press CHUCK DATA when calling up CHUCK JAW DATA picture.

(h) TAILSTOCK QUIL LENGTH?: Set the length of tail spindle projection.



Measure the length of tail spindle projection and set it using ten-keys.



Note 1: Tailstock shapes are set using PARAMETER (MACHINE) B9 to B15.

registered name.

Note 2: If minus numeral is set, tailstock shapes are not properly displayed.

(i) PROGRAM TITLE (MENU)?: Register program name using menu alphabet and ten-keys.

Press | SPACE | and | when erasing

Up to 11 characters are registrable.

In PROGRAM FILE picture, such handling as renumbering, program transfer and program erasure as well as of data registration is possible. However, it is not possible during automatic operation. If no menu is displayed, shift cursor to left end (number column).

Renumbering: Carry out following handling when changing registered work number.

Handling)			
1	Press PROGRAM RENUMBER .	NO.	WNO.	BLOCK
T		1	1234	56M
	Cursor will then flicker at head.	2	1	134E
		3	555	38 M
		4	1000	25M
		5	38	96E
2	Shift cursor to the number to be	NO.	WNO.	BLOCK
	changed in response to "WORKPIECE >	1	1234	56M
	NO.?".	2	1	134E
	Press or .	3	555	38M
		4	1000	25M
		. 5	38	96E∞



7				. 1 6 4. 1 1
3	Set changed work number using	NO.	WNO.	BLOCK
	ten-keys.	1	1234	56M
	Press 7 , 0 and $ \Longrightarrow$.	2	1	134E
		3	70	38M
1	Change will then be performed to	4	1000	25M
	work no. 70.	5	38	96E
End				

- Note 1: If above handling is carried out in automatic operation, alarm "436 AUTO OPERATION MODE" (blue) is displayed.
- Note 2: If registered work number is set, alarm "415 SAME PROGRAM IS DESIGNATED" (blue) is displayed.



Program Transfer:

Should be carried out to prepare and correct programs (optional background programming) after that in automatic operation.

Handling)			
Handling)			
	•			
1	Press PROGRAM MOVE .	NO.	WNO.	BLOCK
	'	1	1234	56M
	Cursor will then disappear.	2	1	134E
		3	555	38M
		4		
2	Set the work number to be	NO.	WNO.	BLOCK
T	transferred to the last using	1	1	134E
	ten-keys in response to	2	555	38M
•	"WORKPIECE NO.?".	3	1234	56M
		4		
	Press $[1,2,3,4]$ and $[]$.			
	Set work number will then be			
	registered lastly.			
(End				

Note 1: If non-registered work number is set, alarm "429 PROGRAM NOT FOUND" (blue) is displayed.

Mazak –

Program Erasure:


Work number or all program erasure is possible.

Handling				
1	Press PROGRAM ERASE .	NO.	WNO.	BLOCK
	•	1	1234	56M
		2	11	134E
		3	555	38 m
		4	1000	25M
2	Set the work number to be erased	NO.	WNO.	BLOCK
	using ten-keys in response to	1	1234	56M
	"WORK NO. TO ERASE (INPUT)?".	2	555	38M
	·	3	1000	25M
		4		
	Press 1 , 1 and $\stackrel{\circ}{\Longrightarrow}$.	1		
	Set work no. 11 will then be erased.			
End				

Note 1: If non-registered work number is set, alarm "429 PROGRAM NOT FOUND" (blue) is displayed.

Mazak -

All Program Erasure:



- Note 1: On setting to other than -9999, alarm "401 INPUT FORMAT ERROR" (blue) is generated.
- Note 2: At same time as renumbering, program transfer and program erasure handling, Z-offset, chuck reference point (X, Z) and jaw number are changed.



5-6 WORK PROGRAM Picture

Refer to Programming Manual.



5-7 SHAPE CHECK Picture


Used to check the shape of the program in preparation.

Scale function insures partial enlargement and reduction.

For displaying this picture, press and FIGURE CHECK in WORK

PROGRAM picture (program in preparation).

After displaying picture, work and program shapes are displayed in green and purple respectively.



If SCALE is pressed, "SCALE SHIFT (CURSOR)?" is displayed and cursor flickers at the center of side view so it becomes possible to set central point a desired using cursor shift key.

Use ten-keys when setting scale length. Setting range: 1 - 999.

If STORE is pressed, graphic is preserved even though other picture is selected.

Press PROGRAM when returning to WORK PROGRAM picture.



- Note 1: The scale length upon power on is automatically fixed in accordance with the work maximum outer diameter and length set at PNO $\,$ 0.
- Note 2: FIGURE CHECK is displayed only during preparation in WORK PROGRAM picture.
- Note 3: Thread and tap shapes: neither actual pitch nor thread ridges are correctly displayed.
- Note 4: No grinding escape shape is displayed.



5-8 LAYOUT Picture

In this picture for laying out prepared programs, rough machining or program priority, layout process replacement and transfer edit are possible.

Layout is possible only for MAZATROL programs.

Handling LAYOUT picture:

1	· .					
	NO.	PNO.	PROCESS	TNO.	TIME	
	1	R1	BAR-OUT	1-0	0:1'02"	
	2	F1	BAR-OUT	2-1	0:0'43"	
	3	R2	BAR-IN	4-0	0:1'38"	
	4	F2	BAR-IN	6-2	0:0'57"	
ł						

TOTAL CUTTING TIME 0:13'21"

Press (picture select key)—PROGRAM LAYOUT when selecting LAYOUT picture.

The layout of the work numbers selected in WORK PROGRAM picture is displayed.

Mazak —

Rough Machining Priority:


Handling			·
	ROUGH PROGRAM REPLACE MOVE ROUGH PRI PRI R	FINISH CH	EK PROGRAM SIMULATN
1	<u> </u>	UGH PROGRA	AM REPLACE MOVE
2	ROUGH CUT PRIORITY (INPUT)?	NO. PNO	O. PROCESS
		1 R	1 BAR-OUT
	Press (input key).	2 R	2 BAR-IN
		3 F	1 BAR-OUT
	Rough machining process will	4 F	2 BAR-IN
·	be laid out prior to finish		
	machining process.		
End			

Program Priority:

Handling				
1	Select PROGRAM PRI .	 	OGRAM F	EPLACE MOVE
2	PROGRAM PRIORITY (INPUT)?			
3	Press 🏟 (input key).	NO.	PNO.	PROCESS
	Layout will then be made	1 2	R1 F1	BAR-OUT BAR-OUT
. *	in the order of program	3	R2	BAR-IN
	process number.	4	F2	BAR-IN
End)			

Mazak

Replacement:



Example


When replacing No. 2 with No. 4, shift cursor to No. 2 and press FINISH F, 4 and 3 in succession.

NO.	PNO.	PROCESS
1	R1	BAR-OUT
2	R2	BAR-IN -
3	F3	THR-OUT Process to be replaced
4	F4	GRV-OUT

	/			
	NO.	PNO.	PROCESS	
	1	R1	BAR-OUT	
	2	F4	GRV-OUT	Process No. R2 will then be replaced
	3	F3	THR-OUT	with F2.
	4	R2	BAR-IN	
- 1	•			

Mazak -

Transfer:



Example

When replacing No. 2 with NO. 4, shift cursor to No. 2 and press
FINISH F, 4 and 🖘 in succession.

NO.	PNO.	PROCESS
1	R1	BAR-OUT
2	R2	BAR-IN
3	F3	THR-OUT
4	F4	GRV-OUT

Process to be inserted

_			
	NO.	PNO.	PROCESS
	1	R1	BAR-OUT
	2	F4	GRV-OUT
	3	R2	BAR-IN
	4	F3	THR-OUT



- Note 1: Machining time is displayed after the check in SIMULATION picture.
- Note 2: Priority is given to programs in the layout after preparing new programs.
- Note 3: Alarm "422 LAYOUT NOT COMPLETE" is generated in some cases after program correction. Therein carry out layout handling.
- Note 4: LAYOUT cannot be edited if the program rewrite switch is locked.



5-9 CHECK Picture

Continuously or discontinuously displays the tool path of laid-out programs. Insures partial scale enlargement and reduction.

Handling

1

2

Select WORK PROGRAM picture and press CHECK .

o Picture will then be selected and work profile will be displayed.

Press | SHAPE |. Programmed shape will then be drawn in purple.

o Press CHECK CONTINUE when continuously checking tool path.

Nose position will then be displayed, followed by the solid or dotted line (white) of tool path for cutting or rapid feed respectively.

The characters of menu display invert (CHECK CONTINUE) in drawing and return to initial position on its completion.


- o Press | CHECK STEP | when step checking tool path. Drawing will then be performed each time of pressing menu key.
- o Press SHAPE ERASE when erasing only shape.
- o Press TOOL PATH ERASE when erasing only tool path.
- o When changing scale length, press | SCALE | and change central point as desired using the cursor flickering at the center of side view coordinates. Set scale length using ten-keys.

If CHECK picture is selected, scale length is automatically fixed in accordance with the work data in program.

End



CHECK Picture Display Items:



SIMULATION Picture Display Items

- WNO.: The work number being checked currently is displayed. It is same as the work number in WPRK PROGRAM picture but differs from that in POSITION and COMMAND pictures.
- P: The process number being run is displayed.
- N: The block number of EIA/ISO programs is displayed. In MAZATROL program, a block number of internal processing data is displayed and this number differs from that in WORK PROGRAM picture.
- T: Tool and offset nubmers are displayed.
- X,Z: The current tool position in the work coordinate system set up for program zero-point is displayed.
- 0 50: The scale length being run currently is displayed.



Shape data:

Work:

Work profile is automatically drawn in green when

picture is selected.

Shape:

Program shape is displayed in purple.

Tool path: The white solid or dotted line of tool path is displayed

for cutting or rapid feed respectively.

Note 1: No grinding escape is displayed.

Note 2: Thread and tap shapes: neither actual pitch nor thread

ridges are displayed.



- Note 1: If CHECK STEP is pressed in execution of CHECK

 CONTINUE, change-over occurs to step drawing. If CHECK

 CONTINUE is pressed in execution of CHECK STEP,

 change-over occurs to continuous drawing.
- Note 2: If SHAPE ERASE is pressed in execution of SHAPE, completed shape drawings are erased but the drawing then in course continues.
- Note 3: If TOOL PATH ERASE is pressed in execution of CHECK


 CONTINUE or CHECK STEP, already drawn tool path is erased but the drawing then in course continues.
- Note 4: Shape is neither drawable in execution of CHECK CONTINUE nor CHECK STEP. For this drawing, press and SHAPE.
- Note 5: Neither continuous nor step check is possible in execution of SHAPE. For continuous or step checking, press and CHECK CONTINUE or CHECK STEP respectively.
- Note 6: Chuck and tail barriers are displayed if JAW NO. and TAILSTOCK data are set in PROGRAM FILE picture.
- Note 7: For tool path drawing, NOSE-R is taken into account in MAZATROL programs.
- Note 8: NOSE-R offset entered in EIA/ISO programs will affect the tool path.
- Note 9: Pressing and STORE will cause graphs to be stored even if a different picture is selected.

Mazak

5-10 SIMULATION Picture

Gives chuck, work and tool shapes to CRT display to simulate cutting operation.

Simulation speed is variable by 10% each time over the range from 0 to 500%. Simulation is possible only for MAZATROL programs.





- Note 1: Press SIMULATN HOLD when interrupting simulation.

 When restarting it, press SIMULATN START.
- Note 2: Press SIMULATN RESET or and SIMULATN START in the order when restarting from the begining the simulation stopped halfway.


 Tool will then return to tool swing position and restart operation.
- Note 3: Press SCALE when changing coordinate scale. Central position is variable as desired using cursor shift key for handling the cursor flickering at the center of side view coordinates.

Set scale length using ten-keys in response to "SCALE SHIFT (CURSOR)?". Setting range: 1 - 999

Note 4: Pressing STORE menu key will cause graphs to be strored even if a differenct picture is selected.



SIMULATION Picture



Display items in SIMULATION picture:

- WNO.: The work number being simulated currently is displayed. It is same as the work number in WORK PROGRAM picture but differs from that in POSITION and COMMAND pictures.
- P: The process number being run is displayed.
- N: The block number of EIA/ISO programs is displayed. In MAZATROL program, a block number of internal processing data is displayed and this number differs from that in WORK PROGRAM picture.
- T: Tool and offset numbers are displayed.
- X,Z : The current tool position in the work coordinate system set up for program zero-point is displayed.



SPD OVERRIDE: Current simulation speed is indicated by percentage.

0 999:

The scale length being run currently is displayed.

Shape data:

Chuck: Chuck and jaw barrier ranges are displayed in yellow.

Display data determination factors:

Chuck barrier range: PARAMETER (MACHINE) B5, B6, B7 and B8


Jaw barrier range: DIM-A, DIM-B, DIM-C and DIM-D in

CHUCK JAW DATA picture


Chuck position: CHUCK-X, CHUCK-Z and JAW NO. in

PROGRAM FILE picture

Mazak-



Outer jaw chuck



Inner jaw chuck



Tool: Turret barier range and tool shape are displayed in red.

Display data determination factors:

Turret barrier range: PARAMETER (MACHINE) B17 to B23


Tool shape:

TOOL FILE picture All data .

TOOL DATA picture

Nose position:

TOOL SET picture



^{*} In case of holder type No. 1



Tailstock: Tailstock barrier range is displayed in yellow.

Display data determination factors:


Tailstock barrier range

PARAMETER (MACHINE): B9 to B15


PROGRAM FILE picture (shaft work): TAILSTOCK QUIL LENGTH

COMMAND picture (chuck work):

tailstock position



Shaft work



Note 1: TAILSTCK TEACH is valid only for COMMAND picture and this fucntion is used to set tailstock position.



Work: Green sectional display is given for side coordinates and work profile only is displayed for front view coordinates. If simulation is performed in turning, work undergoes cutting shape display (real). However it is not performed in milling.

Shape: Prepared program shape is drawn in purple.

- Note 2: Thread and tap shapes: neither actual pitch nor thread ridges are displayed.
- Note 3: No grinding escape shape is displayed.
- Note 4: If SIMULATN START is pressed without AUTO selected, alarm "171 AUTO START COND INSUFFICIENT" (red) is generated.
- Note 5: SIMULATN START does not actuate unless SIMULATN READY is selected.
- Note 6: Tool path consideration is given to OFFSET-X and -Z but not to NOSE-R.
- Note 7: Simulation stops if its speed is 0%.
- Note 8: Simulation does not continue even if setting is made to CONTINUE in program END mode.
- Note 9: The scale length upon power on is automatically fixed.
- Note 10: No EIA/ISO programs can be simulated.
- Note 11: Proper display is not performed in some cases depending simulation speed.
- Note 12: Simulation in threading programs stops when threading is completed.



- 6. HANDLING FOR AUTOMATIC OPERATION
- 6-1 What is Automatic Operation?

A series of operation steps are automatically performed one by one to run prepared programs and set data items after pressing starting button until the automatic stop on completion. If programs and data are completed, operator is not required in principle to handle numerical controller but allowed to change cutting conditions and carry out interrupt handling and operation interrupt in machining.

Categories of program operation:

Program operat:	ion is	divided	in	three	_	AUTO	,	RESTART	<u></u>	and
SINGLE PROCESS	<u>.</u>	•					•			


- 1-1 AUTO mode runs all the contents of programs. This mode is capable of running programs in combination with other ones.
- 1-2 RESTART mode runs the contents after desired machining process of programs.
- 1-3 SINGLE PROCESS mode runs one machining process in programs. This mode is capable of performing only the last step of threading.

Description will be made as to the procedures of the handling in each mode hereunder.

Mazak –

6-2 Program Operation - AUTO Mode

Used to perform all the steps of machining, starting with the head of programs.





Check running conditions.

Before starting, the condition of planned operation can be limited with respect to the items selected from menu or override. Running condition is also variable through examination after starting.

* Run condition menu

WORK NO.		1	OPT. STOP	DRY RUN	MACH LO	K COOLA	i i	BARRIER CANCEL
	ı	(1)	(2)	(3)	(4)	(5)	(6)	(7)

Run condition menu include:

o Step run:

- (1) SINGLE STEP
- (2) OPT. STOP
- o Change of cutting condition: (3) DRY RUN
- o Mechanical operation:
- (4) MACH LCK (5) COOLANT
- (6) WORK LIGHT
- o Barrier valid/invalid:
- (7) BARRIER CANCEL

(1) SINGLE STEP

Runs blocks one by one. When pressed in axis move, stops after the end of the block being run. Press cycle start button each time cycle start lamp goes off for each block. When automatic operation starts, "BUFFER" in COMMAND picture is convenient for check.

OPT. STOP (2)

Only if MO1 of process data is entered in program, the machine stops temporarily with CYCLE START light on after running up to the block where it is present. If this menu is off, however, the contrary takes place even though that entry is performed.

Runs following blocks when cycle start button is pressed

Operation does not stop even if MO1 is entered in sequence data M.



(3) DRY RUN

Performs the change-over to jog feedrate code, invalidating the feedrate command selected in program.

Use or when increasing or decreasing the jog feedrate, respectively. The jog feedrate code number is displayed in

Jog Feedrate Codes:

Display	Feed (mm/min)	Display	Feed (mm/min)
0	. 0	130	52
10	1.0	140	72
20	1.4	150	100
30	2.0	160	140
40	2.7	170	200
50	3.7	180	270
60	5.2	190	370
70	7.2	200 .	520
80	10	210	720
90	14	220	1000
100	20	230	1400
110	27	240	2000
120	37		

Note 1: In threading or tap cutting, either DRY RUN valid or invalid is selectable using parameter U19; 1 - valid and 0 - invalid.

Note 2: When in the rapid feed mode, DRY RUN validity can be selected using parameter <u>U18</u>; 1 - valid and 0 - invalid.

(4) MACH LCK

Counts position displays without axis move on move command. Performs the count of those for POSITION, COMMAND or TRACE as if axis moves. Makes other modes of operation as commanded by programs. If this is pressed as the axis is moving, it will cause the single step stop. The move will continue at the end of the block. Note that this can cause the coordinate system to shift.

Mazak

(5) COOLANT

Used to supply cutting fluid. In automatic operation mode, works when reading MO8 in program (no cutting fluid is supplied by pressing simply this key).

(6) WORK LIGHT

Comes on when manual or automatic operation is underway.

(7) BARRIER CANCEL

Tailstock barrier, chuck barrier and tool barrier become invalid.

The conditions of (1) to (7) can be set with menu key pressed. On press, menu display inverts to indicate switch-on. On next press, inverted display returns to initial position, indicating switch-off.

* Override

In automatic operation mode, this function maintains optimum cutting condition for situations by varying surface speed and feedrate without modifying program.

Override is divided in:

(1)	Rapid feed override (RAPID)	RAPID
(2)	Spindle override (SPINDLE)	SPINDLE
(3)	Jog feed override (FEED)	FEED

The significances of override display differ depending on whether manual or automatic operation mode is selected.

	Manual operation mode	Automatic operation mode
Rapid feed override	Rapid feedrate (%)	Rapid feedrate (%)
Spindle override	Actual revolutions (x 10 rpm)	Ratio to program command revolutions (%)
Jog feed override	Code display (mm/min)	Ratio to program command feedrate (%) (Note)

Note: Dry run on is excluded.

In automatic operation mode, all overrides are fixed in terms of the ratio to program command value.

Vary segment display using UP or DOWN key in accordance with run conditions.

Example: after the start of power supply

(1) When manual operation mode is selected, it is assumed that following display is given.

RAPID	SPINDLE	FEED
$\sqrt{070}$	035	w 240
70%	350 rpm	2000mm/min

(2) If automatic operation mode is selected with (1) maintained, following display is obtained.

RAPID		SPINDLE	FEED
~ 100	•		$\mathbf{w} \boxed{1} \boxed{0} \boxed{0}$
100%		100%	100%

(3) It is assumed that the run conditions in automatic operation are limited as follows.

RAPID	SPINDLE	FEED
$\sqrt{050}$		ww 090
50%	110%	90%



(4) If manual operation mode is selected again, return occurs as follows.

Segment display values are kept stored even if change-over, manual mode automatic mode or automatic mode manual mode, is performed.

(5) If automatic mode is selected and DRY RUN key in run condition menus is pressed, only jog feed override display shows jog feed code.

The run conditions changed by override are rechangeable with the condition of the production of cutting chips, their shape, the loading condition of load meter, the roughness of finish surface checked after the start of machining.

- 6 Press 🥢 (reset) key.
 - o Program will then come to head.

 Ascertain that READY (preliminary setup completed for operation)
 and %P.HEAD (program head) lamps glow.
- 7 Press 🗀 (cycle start) key.
 - o Machining steps will then be taken one by one in accordance with program.
 - o After starting, change-over is allowable to any picture.

End

Mazak

6-3 RESTART Mode

Used to restart machining after the interruption under various conditions.

Handling 1 Fix program number and run conditions. o (Take the handling steps 1 - 5 for automatic operation.) Press [m] (restart) key. 2 %P.HEAD (program head) lamp will then turn on. o "RESTART DATA (MENU)?" appears and restart data input part is displayed above the picture name. M-code fed to machine before restart. -Restart process number o Following menu is displayed. PROCESS INPUT NO. **END** 3 Press PROCESS NO. . "PROCESS NO. (MENU)?" is displayed and menu changes as follows. ROUGH FINISH R




}	
4	Select rough or finish machining process for restarting and press menu button.
	o Pressed menu display inverts. o The rough/finish machining selection is the same as the layout on the LAYOUT picture.
5	Select the process number to be restarted.
	o Example: process No. 5
	5 , 🏟 (up to two numeral digits can be set.)
	o If set process number is found out through search, R or E and process number are entered in restart data input part and menu returns to the status described in 2 (on the contrary, error "PROCESS NOT FOUND" occurs).
6	Press M.
	o "M CODE (MENU)?" is displayed and change-over occurs to M-code setting menu.
7	Display the menu of the M code to be set.
	o Use at left end for menu change-over.

o M code menus

-00 01 0304 0509								
PROGRAM	OPT.	SPNDL	SPNDL	SPNDL	COOLANT	COOLANT	CANCEL	
STOP	STOP	FWD	REV	STOP	ON	OFF		

The following M codes are displayed by setting parameter P16.



Note: For M codes, see the Operating Manual of the respective model.

Press the menu key for the M code to be set. (1)

If the M code to be set is not displayed or known beforehand, use ten-keys for its direct setting. (2)

Set M code is displayed in restart data input part and menu returns to the status described in $\boxed{3}$.

o At (2), carry out handling as follows.

·Example: M80

8

8, 0 and (input) (up to three numeral digits can be set.)

- o Do not select unusalbe M code.
- o Repeat steps 6 to 8 for setting other M codes if any.
 - o Up to six M codes can be selected.
 - o Press CANCEL when cancelling already-set M codes. M code lastly set will then disappear.



γ	
9	Press INPUT END . Change-over will then occur to
	automatic operation menu.
10	Press 🥢 (reset) key.
	Confirm again that %P.HEAD (program head) is on.
11	Call up selected starting picture and press (cycle start) key.
	Then, set M codes will be run and machining will start with
	selected process. When an M code has been run, its dispaly
	also disappears.
End	


Mazak -

6-4 SINGLE PROCESS Mode

Used to repeat a specified step of machining when work finish is not good.

Handling	
1	Select program number and run conditions.
	o Take the handling steps 1 to 5 of AUTO mode operation.
2	Press (single process) key.
	o "PROCESS NO. (MENU)?" and following menu are displayed.
	ROUGH FINISH REFORM R F
3	Select ROUGH R, FINISH F or REFORM for re-machining
	process.
	o Selected menu display inverts.
	o Press ROUGH R for SGL, MES or M process.
	o Menu REFORM is selectable only for threading process and
	runs only its last step.





Note 1: When the machining is performed in the SINGLE PROCESS mode, the service life of tools is controlled by the time, but not by the number of workpieces machined.



6-5 Stop of Automatic Operation

Performed on an emergency or for check when tool is going to interfere with or run against work or chuck or cutting is examined on its completion to some degree in the automatic operation and trial cutting.

Particularly in former's case, securely carry out this very important handling for safety.

(1) Press EMERGENCY STOP button.



EMERGENCY STOP

- o Alarm "EMERGENCY STOP" is displayed in picture, and the spindle rotation, axis feed and other functions in operation all stop (excluding the machine, unit and pump functions).
- (2) Press 🥢 (reset) key.
 - o Operation stops and control informations are all internally reset.
 - o Operation object program run position returns to head.
- (3) Press [(feed hold) key.

Feed stop:

- o Only axis feed stops (spindle and other functions continue operation).
- (4) For the change-over to manual operation mode, press one of , , , and keys.
 - o The functions in operation stop (spindle rotation and axis feed). In this condition, offset number does not change even if tool swings.



Turn off power supply by pressing (power off) key. o The electric circuits and numerical controller of machine

> are all cut off and hydraulic and pneumatic pressures decrease (spindle is set to free run position (inertia)).

Steps (1) to (5) are available for stopping automatic operation. Besides, axis feed, etc. can be stopped through the change-over to SINGLE STEP, OPT, STOP, MACH LCK or other automatic operation mode in run condition menus.

Cancellation of stop status:

Emergency stop (1) to (3) of course come from some causes. Therefore eliminate them before restarting machining.

- Turn EMERGENCY STOP button clockwise. (1)
 - o Alarm "NMI EMERGENCY STOP" **EMERGENCY STOP** disappears and machine is set to initial status (same as that after power on).



- o READY lamp glows if the initial status that insures operation.
- o In this case zero-point is lost. Therefore carry out zero-point return (thereafter carry out operation referring to automatic operation mode).
- (2) When RESET key is pressed, run program head is called up. Therefore run is performed from beginning again when CYCLE START button is pressed. Restarting is possible halfway if necessary using RESTART or SINGLE PROCESS.

Mazak -

(3) Press (cycle start) key.

Since feed hold is maintained, operation restarts from the current position to run succeeding programs when CYCLE START key is pressed again.

- (4) Perform the change-over to automatic operation mode and press CYCLE START key. In the case of AUTO, RESTART or SINGLE PROCESS, run starts from the stop position if CYCLE START key is pressed. Resetting is however necessary if deviation has occurred in manual handling. Otherwise run will start from the deviated position. (This does not apply when parameter P14 is input as "1".)
- Note 1: If the | READY lamp does not come on, the other alarm-condition cause must exist. In this case, perform a diagnostic check and when the other cause is found, release the EMERGENCY STOP button while pressing the RESET key.




7. DISPLAY IN AUTOMATIC OPERATION

The turret position, feedrate, tool number and so forth in automatic operation can be checked using POSITION and COMMAND pictures. The nose position and path being run can be checked using TRACE picture.

7-1 POSITION Picture: displays running condition.


Press (picture select) key and invert POSITION to display
POSITION picture. (Unit: mm in the Fig. illustated below)





Space $\widehat{\mathbb{A}}$:	
Following restart o	lata input part appears when 🛅 (restart)
P M M M	M
ACT DATA:	
FR X/Z MM/REV: (IN/REV)	feedrate per revolution of X- and Z-axes
MM/MIN: (IN/MIN)	feedrate per minute of X- and Z-axes
SPINDLE RPM:	spindle revolutions per minute
():	selected spindle gear number
Display of the proc	
(a - b -	c)(a - b - c)
a: machining	modes (BAR, CRY, DRL, SGL, etc.)
	part (OUT, IN, FCE, etc.)
c: rough/fin	ish machining selection (R F)





Quantity of machined workpieces

If targe quantity is set in parenthesis, operation stops after the run therefor, provided NUMBER in the program end mode is set to "1".

LOAD METER:

SPINDLE: load of spindle motor % (1) 0 - 100% (blue)

X AXIS: load of X-axis servomotor % 100 - 120% (yellow)

Z AXIS: load of Z-axis servomotor % (2) 0 - 100% (blue)

100 - 180% (yellow)

180 - % (red)



7-2 COMMAND Picture: displays running condition in further details than POSITION picture.

Display menus using (picture select) key and COMMAND picture by pressing COMMAND. (Unit: mm in the Fig. illustrated below)

WNO III	PROCESS NO.	TOOL NO	BLOCK NO.
POSITION X	BUFFER U		TAILSTOCK
MACHINE X	REMAIN U		POWER ON
		<u>`</u>	TOTAL CUT
	TOOL POCKET NO. TOOL NO.	SPINDLE	0 50 100 150 200
SPINDLE RPM (()) () M/MIN		X AXIS Z AXIS	
M SPIN RPM ([]) *** COMMAND ***	COUNTER [[]] ([]]]) H SPIN	
COLUMN	FAZATROE		
WORK NO.	SINGLE OPTIONAL E	PRY RUN MACH LCK	COOLANT LIGHT CANCEL

WNO.:	program number being run currently
PROCESS NO.:	process number being run at present
TOOL NO.:	tool and offset numbers being indexed currently
BLOCK NO.:	block number being run presently
POSITION X	current tool position in work coordinate
G Z] system (absolute value)
MACHINE X	current tool position in machine coordinate
	system (absolute value)
G _ Z _	


Mazak —

BUFFER U	X- and Z-axis move distance (incremental value) in the block to be run next
REMAIN U	remaining distance (incremental value) of the move in the block being run at present
TAILSTOCK:	distance between the zero-point of the reference program and the tailstock reference point (obtained by taking Z-OFFSET into account for TAILSTOCK of PROGRAM FILE picture)
CHUCK-X . :	distance between the zero-point of the reference program and the chuck reference point in X-axial direction (CHUCK-X (diameter value) of PROGRAM FILE picture)
CHUCK-Z ::	distance between the zero-point of the reference program and the chuck reference point in Z-axil direction (obtained by taking Z-OFFSET into account for CHUCK-Z of PROGRAM FILE picture)
POWER ON: ":	total cumulative time ranging between power on and off
AUTO OPR : ":	total cumulative time of automatic operation (starting - stop) including single step and feed hold stop time
AUTO CUT : ":	total cumulative time of automatic starting (CYCLE START light on)
TOTAL CUT : ": ":	total cumulative time of cutting feed
The lower part of picture same as POSITION picture	e that contain ACT DATA and LOAD METER is



7-3 TRACE Picture: displays cutting condition picture

Display menus using (picture select) key and TRACE picture by pressing TRACE. (Unit: mm in the Fig. ullustrated below)



WNO.	:	program number being run at present (same as W in
		POSITION picture)
P	:	process number being run currently (same as P in
		POSITION picture)
N	:	block number being run currently (same as BLOCK NO. in
		COMMAND picture)
T	·:	tool and offset numbers being indexed presently (same as
		T in POSITION picture)
x		current tool position in work coordinate system (X-axis)
z]:	current tool position in work coordinate system (Z-axis)
S	:	spindle revolutions or command cutting speed (surface
		speed)



CUT TIME[: ': automatic machining time (after	starting
	until stop)	
Scale :	same reduced scale is displayed as line length	(on the
0	start of power supply, automatically fixed red	uction
	scale is displayed.)	



TRACE picture shape display:

Handling

1

2


Display following menu using | (menu select) key.

WRKPC WOK FIG SHAPE SHAPE FIGURE ERASE STORE SCALE

- o If any of chuck and tailstock shapes is inputted, TRACE picture is displayed when this menu is selected.
- o The coordinates viewed from sideward is already displayed in picture.

Press WRK PC FIGURE and SHAPE menu keys in succession.

o When pressing WRK PC FIGURE or SHAPE menu key, menu display inverts. Inversion disappears when work and graphic shapes are drawn.



- o The side view work shape is colored green on display.
- o The front view work shape is displayed by green lines.
- o Graphic shape is displayed in purple.

 The graphic shape in the work shape colored green is however displayed in white.
- o Press WOK FIG ERASE or SHAPE ERASE when erasing work or graphic shape display respectively.
- o Scale value and display limit are automatically fixed in accordance with work shape.




Press SCALE menu key when enlarging or reducing graphic shape or a certain part thereof.

Handling

1 |

Press SCALE menu key.

- o When pressing SCALE menu key, menu display inverts. SCALE SCALE
- o When only side view coordinates are displayed, cursor flickers at the center of picture.
- o When the 2-division (side and front views) coordinates are displayed, cursor flickers at the center of side view coordinates (left half of picture).
- o Message "SCALE SHIFT (CURSOR)?" is displayed.
- Shift cursor to new display center position when enlarging or reducing partial display.
 - o No cursor shift is necessary for the enlargement or reduction at current position.





Setting scale value.

Setting scale value to 50:

Example: 5 0 (input) Scale display

0 50

o Setting range: 1 - 999

o Setting is made to the scale length display in the lower right part of picture and the work and graphic shape displays in picture are cleared.

End

Display work and graphic shapes by pressing WRKPC FIGURE and SHAPE menu keys again.

o Start automatic operation. Then red mark or tool will

o Press STORE when preserving shape display data. These will then be preserved even after the display changes. The STORE menu display will invert when valid.

appear and current machining spot will be displayed.

End



Displayed shape data:

The TRACE picture is the same as the CHECK and SIMULATION pictures in that the chuck, tailstock and tool barrier shapes as well as graphic shape data can be displayed and checked. Refer to "SIMULATION picture" for the chuck, tailstock and tool shapes as well as workpiece and graphic shapes.

The machining shape displayed by the above operation is accompanied by the tool path display corresponding to the machining condition with the tip radius and compensation taken into account at the start of machining. The machining status, in this way, can be observed.

If the different programs are continuously run during automatic operation, the shape data in the TRACE picture vary when a program has changed to another. When the STORE menu is valid, however, the shape data do not vary.



8. AUTOMATIC OPERATION HANDLING MODES

8-1 Machining Condition Changes

Particularly during trial machining in the automatic mode, it may necessary to alter machining conditions depending on the shape of the chips from the first workpiece, their generation condition, the load indicated by the load meter and the roughness of the finish. In this case machining conditions are variable using override and the menus in same manner as the run conditions in the automatic mode.

In the automatic mode, override is always expressed in terms of the ratio (%) to the value of the run program command. Use the UP or DOWN key when varying the override display.

Limitation of run conditions by the menu: fully understand the significance of menus when changing or blanking them.

8-2 VFC Function

Replaces the feed, revolutions and other cutting conditions set in programs with those obtained by the override change.

VFC is very useful for machining efficiency because it is capable of storing the optimum machining conditions obtained through the override change. Only the rough machining conditions (not the finish machining) are variable using the VFC. The new conditions obtained by the override change are run starting with the next machining step.



Adjust the override to optimum machining conditions using the UP or DOWN key.

Press (VFC) key.

o VFC is valid only during rough machining and not valid during finish machining. (In finish machining its key light does not come on.)

o VFC is valid at either rapid or jog feed.

o Stored data are registered when key light goes out on the completion of process. (Program data are rewritten.)

- Note 1: When the DRY RUN key is pressed, its light goes out and the VFC function becomes invalid.
- Note 2: VFC does not functions during DRY RUN.
- Note 3: VFC is valid even during the interruption of automatic operation by FEED HOLD or SINGLE STEP, but not valid if the manual mode is selected.
- Note 4: Override displays return to 100% after the conditions have been changed.
- Note 5: The VFC function will not be valid if the spindle override or feed override value is changed.
- Note 6: The VFC function will not work with EIA/ISO programs.
- Note 7: The VFC function will not work while the program rewrite switch is locked. Pressing the [(VFC) key will cause the alarm "406 WRITE PROTECT" to be displayed.

Example: If the surface speed 100m/min and the feed 1mm/rev are registered as rough machining conditions.

Mazak

- (1) Override display
- (2) Display in POSITION or COMMAND picture

o Auto mode selection

SPINDLE FEED

100 w 100

100%
100%

o Start of automaic operation and start of machining

SPINDLE 100M/MIN
FR 1MM/REV

o Change of machining conditions

Change override uisng its UP or DOWN key.

 SPINDLE
 FEED

 I 2 0
 w 0 6 0
 SPINDLE 120M/MIN

 1 2 0 %
 6 0 %
 FR 0.6MM/REV

Press (VFC) key (key light on)

o Completion of rough machining

VFC key light out

To next processing step

Override display does not return to initial condition and the finish machining surface speed and feed are kept as below:

SPINDLE 100%

FEED 100%

o After machining

Machining conditions during the rough machining in the program are changed to:

Rough surface speed: 120 m/min

Rough feed:

0.6 mm/rev



Appendix: The following table lists the VFC registration conditions for each process.

Process			Rough machin	ning	Finish machining
			Surface speed	Feed	Surface speed
BAR			o .	0	0
CPY			0	0	0
CNR			0	0	0
EDG			0	0	0
THR			·		0
GRV	#0		x	o	0
	#1	ROUGH	0	0	
		FINISH	x		0
DRL			0	0	
TAP					0
MNP	MNP				
MES	MES				
M	М		·		
END					

Mazak-

8-3 TPS Function

This so-called tip path store fuction is used in case of a tip failure, etc. in automatic operation. By using it, the axis can be moved while up to five path points are stored through manual handling after automatic operation interruption.

Handling

1

2

3

Interrupt the operation.

When TPS is used, this interruption should be performed as described below (1) to (5).

Hold:

- (1) Press (feed hold) key.
- (2) Select the manual operation mode key.

Stop:

- (3) Press the SINGLE STEP menu key (the operation stops after the current block is finished).
- (4) Press ohter automatic mode key (the operation stops after the current block is finished).
 - (5) When OPT. STOP menu is valid (stop occurs when the NC reads MO1 in the program).

Change to manual operating mode

o Not necessary when the operation is interrupted by pressing the manual operation mode key.

Press (TPS) key.

o Light on positions are stored in the memory.

o TPS is capable of using up to five path points including the point where the tip stopped at the interruption of operation. If there are more than five points, the light does not come on even when the tool has come to the stop position.

4 Manual handling. TPS key light will go out.


o Repeat steps 3 and 4 until desired axis reaches target position.

5 Carry out handling requiring interruption such as chip change.

Return to the automatic operation mode used before interruption.

Press 🗀 (cycle start) key.

o Tip points stored using TPS function are traced back before restarting. After restarting, machining feed is performed between the point, Pl and path point, P2 used before interruption.



Position at operation interruption

Manual handling path
 TPS key on-position
 Path point


P5 ----- P4 ----- P3 ----- P2 ----- P1
Rapid feed Rapid feed Rapid feed Machining feed

Mazak


A cutting feedrate may be determined with parameter S15 for cutting feedrate before the TPS or if cutting feed has not been executed at all after switched on.

The tip moves, skipping positions not stored in memory, as illustrated below.


Example 2:



Example 3:



o If no tip positions are stored in the memory, the rest of the process is run starting at the operation restart position without returning to the initial position.



Note 1: Do not use TPS function when interrupting again while returning to the operation interrupt position.


Note 2: If the TPS key is not pressed at the operation interrupt position, the final stage return procedure will depend on the interruption condition.

Hold:

- (1) Feed hold on
- (2) Direct manual handling mode on

. Path point

TPS key on-position




. Stop:

- (3) Single step on
- (4) Other automatic mode on
- (5) Optional stop on

. Path point

TPS key on-position

Mazak



- Note 3: Upon approaching, a cutting feedrate is dependent on the feed mode when the TPS interruption is made.
 - (1) TPS interruption in the cutting feed mode:

 Approaching will be made at the feedrate upon interruption.
 - (2) TPS interruption in the rapid feed mode:
 - i) When even one cutting feed block should exist between the top of the program and the interrupted block;

Approaching will be made at the feedrate of the block nearest to the interrupted one.

ii) If there is no cutting feed block between the top of the program and the interrupted block;

Approaching will be made at the feedrate selected with parameter \$15. Note that no motion is available with this parameter set to "0".

Note 4: With MANUAL ABSOLUTE on (parameter P14 set to "1"), the TPS lamp will go on when a manual interruption is made. In other words, the TPS button is pressed automatically. Even if the axis has been manually moved, approaching is made at the cutting feedrate up to the position just before the interruption. And the coordinate system does not shift.



- Note 5: After a tentative stop during the threading process, the TPS stores a maximum of 2 points only.
- Note 6: As long as the measurement process is being executed (with "MEASURING" displayed on the MEASURE picture), the TPS function remains invalid.

Mazak

8-4 Manual Handle Interrupt Function

Performed to move the program zero-point and to change tool path with the manual pulse generator in the automatic operation.

Allows the independent movement of the three axes (X, Z). Valid while the manual handle interruption switch light is on. Note that, until the move is cancelled, its distance remains valid for all programs.

* Movement setting (common for X- and Z-axes)


Handling Press (manual handle interrupt) key. 1 o Key light on indicates that the movement is valid. 2 Select the move axis using the manual pulse feed axis select key. X or Z ON Turn the manual pulse generator (handle) through the corresponding angle to the move distance. o The run distance per graduation can be set to 0.001mm or 0.01mm (0.0001 inch or 0.001 inch in inch system). (0: 0.001mm, 1: 0.01mm), (0: 0.0001 inch, 1: 0.001 inch) o Repeat moving for other axes if necessary.

End

Mazak -

* Operation

Example



* Cancellation of the move distance

Method 1: Pressing the RESET key after activating the manual handle interrupt key.

Method 2: Turning off the power supply.

Method 3: Move the same distance in the opposite direction to the set move.

Note 1: Even if the manual handle interrupt key is off after setting, its switch light will not go out unless all of the axis move distances have been cancelled.

Note 2: The move distance is cancelled when the turret returns to the tool change position or the machine zero-point. When the turret leaves this position by CYCLE START, etc., however, its operation is taken into account.



- Note 3: With some models, the handle-interrupt key lamp will continue to flicker even if the move distance is cancelled. Note that if this flickering condition exists, both the handle-interrupt mode has been selected and the myoe distance has been cancelled.
- Note 4: Exercise extreme care when using the handle-interrupt during double-turnet operation especially when:
 - the rear turret continues after the front has stopped.
 - the front turret continues after the rear has stopped.



8-5 Background Program (Optional)

Automatic operating time can be utilized for preparing the next machining step program.


Background programs are capable neither of trace nor of simulation checking.

If any erroneous data were entered while preparing the program, cancel them using $| \bigcirc \rangle$ (clear) key.

Refer to the Programming Manual for the program preparation procedures and methods.

8-6 Picture Erasing Function

The CRT display is blanked during idle times in the automatic operation mode to save energy and extend the CRT life.



o Even while the display is off, an alarm can be displayed if one exists.

Mazak

8-7 Data for Rewriting in Automatic Operation

Following data can be rewritten during the automatic operation.

o POSITION picture:

Parts count

o COMMAND picture:

Parts count, time display

o MEASURE picture:

Measuring count

o TOOL SET picture:

Offset value

o TOOL OFFSET DATA picture:

Offset value (X, Z), tip radius,

direction

o CUTTING CONDITION picture:

Cutting condition values

(surface speed, feed, infeed, etc.) in each mode, cutting condition ratio

of each material

o WORK PROGRAM picture:

Background program

o TOOL DATA picture:

Tip radius, service life

(time, number), used (time, number)

Note 1: For data change on the WORK PROGRAM picture, see the Operating Manual of Background Program.

Note 2: The data being run in WORK PROGRAM picture are not changeable.

Note 3: Take care when rewriting data during the automatic operation.

9. SUPPLEMENT

9-1 Counter Setting Function

In POSITION or COMMAND picture, the counters:

- 1. X- and Z-axes
- 2. Parts count
- 3. Time display

can be set as desired.

1. X- and Z-axis counter setting methods:

Handling

1

Select manual mode and press the cursor shift key .


The cursor flickers at the current position coordinates X.

X	345.834	WNO. 1234
Z	-10.14	POSITION X 345.834
		Z -10.14
POS	SITION picture	COMMAND picture

Set desired value in response to "X POSITION DISPLAY SET?" using the ten-keys.

(Example)

1 5 0 €






The counter display is changed to the set value.

Z-axis can be handled in same manner.


End

- Note 1: Resetting each axis counter is possible only in manual mode.
- Note 2: If the automatic mode is selected after reset, the counter display will return to the previous position.
- Note 3: Any cursor shift key can be used to call up the cursor.
- Note 4: The counter cannot be reset in automatic mode. If this is attempted, the alarm "416 OPERATION MODE MALFUNCTION" will be displayed (blue).

9-2 Parts Count Setting








Note 1: Parts count can be set in either the manual or automatic operation mode.

Mazak

9-3 Time Display Setting



Note 1: The time can be set in either automatic or manual mode.

Note 2: Automatic sexagesimal computation is performed for minute and second displays.



9-4 Write-inhibit Conditions

If the data lock button on the control panel is switched to "LOCK", part of the data, which otherwise could be entered, will not be accepted.

This feature is used to prevent the stored programs from inadvertently being erased. Data writability is determined by the following:

Picture		Data rewrite conditions
	POSITION	o
POSITION/COMMAND	COUNTER	O
	Time display	x
	TAILSTOCK	x
MEASURE		0
TRACE		0
WORK PROGRAM		x
PROGRAM FILE		x
LAYOUT		x
SHAPE CHECK		0
CHECK		0
SIMULATION		0
TOOL SET	TOOL SET	×
	OFFSET	0
TOOL DATA		. 0
TOOL FILE		x
TOOL OFFSET DATA		0
CHUCK JAW DATA		x
CUTTING CONDITION		x
DATA IN OUT (CMT,	TAPE, etc.)	0 _
PARAMETER		X
DIAGNOSIS		0

Inputting data to the parts marked by "x" will cause the alarm-"406 WRITE PROTECT" to be displayed.

This alarm can be cleared by pressing [(clear) key.



10. PARAMETERS

Set parameters - the constants and data specific for the numerical control of the machine and important information needed for machining - are classified as follows:

- (1) User parameters: stored information, principally relating to machining.
- (2) Machine parameters No. 1: stored numerical control constants and data.

Machine parameters No. 2: stored numerical control constants and data.

Users can change user parameter (1) depending on the various machining conditions. However, machine parameters (2) are stored data specific to each machine. Therefore, these normally should not be changed, since accidents might result.

Some machine parameters (2) can, however, be changed by the user.

Changeable machine parameters are marked with an "*" in the Parameter List. No other parameters should be changed. There are two kinds of parameters: one becomes valid after the power is off; the other immediately after rewrite. In the Parameter List, the following two indications are employed:


Immediate: becomes valid immediately after rewrite.

Power on : becomes valid when turning the power on again after turning it off following rewrite.

When changing parameters, select optimum values after fully understanding the contents and meanings of the Parameter List. Incorrect values can cause the machine or numerical controller to fail. Record all changed values and those resulting from such changes.



Parameter change procedure:



Precautions for parameters:

- Note 1: Do not overlook the parameters listed on the sheet attached (in NC electrical control panel) before delivery.
- Note 2: Parameter storage protection battery may become discharged during a long shutdown (battery alarm will be given). In this case identify the parameter values using the attached Parameter List. Altered values can cause the machine to fail.

Mazak -

User Parameters

*M : valid only for MAZATROL programs

*E : valid only for EIA/ISO programs

*M, *E: valid for both MAZATROL and

EIA/ISO programs

Addresses		Names	Significance S. desert.	
Addresses	Unit	Setting range	Significance & items	
P1 ,	point retu	nt/machine zero- urn d/invalid	Selection of tool return position after machining - return position depends on the combined setting of	
Immediate		0 : invalid 1 : valid	FIX POS RET and NUMBER in END mode and of parameter P1	
P2	Tool swing	g position	—————————————————————————————————————	
Immediate	0:A3:D 1:B4:E 2:C		A: Clearance position B: Machine zero-point A C	
P3	Not yet d	afined	D: Machine zero-point Machine zero-point E: Fixed point Fixed point	
	Not yet di			
P4	Spare tool indexing		O: No spare tool will be indexed. 1: Specified spare tools will be indexed when the number of workpieces machined reaches the set value. 2: Specified spare tools will be indexed when the tool using time	
Immediate	,	0: no indexing 1: number 2: time 3: max. wear	reaches the set value. 3: Specified spare tools will be indexed when the offset amount reaches the max. wear value. Note: Up to 8 spare tools can be indexed.	
P5	Not yet defined.			



A d d ma a	Names		Cianificana C incur		
Addresses	Unit	Setting range	Significance & items		
P6	Inch/metr	ic changeover	When this is changed, length parameters will change from millimeters to inches		
Power on		0: metric 1: inch	or inches to millimeters. If machining is to be done after this change; 1. Parameter data indicated in both millimeters and inches and 2. Machining condition data must be changed accordingly.		
P7_	Not yet d	efined.			
P8	Initial s	etting when power	GOl: cutting feed GOO: rapid feed Available when EIA program is used.		
Power on		0: G01 1: G00			
Р9	Initial setting when power on		G99: feed per revolution G98: feed per minute		
Power on		0: G99 1: G98			
P10	Not yet d	efined.			
·					



A 3 3	Names		Cdamificance S. drass		
Addresses	Unit	Setting range	Significance & items		
P11	G53 MAZATROL coordinate system select valid/invalid		 In the EIA G53 (MAZATROL coordinate system selected) mode, the G50 coordinate system command is given. In this case, 0: The selected G50 coordinate system is available. 1: The selected G50 coordinate system is is unavailable. 2: The selected G50 coordinate system is available. If resetting or the end of 		
•			a program has resulted during the G53 mode, the coordinate system immedately before entering the G53		
Power on	~	0 - 3	mode is restored. 3: The selected G50 coordinate system is unavailale. If resetting or the end of a parogram has resulted during the G53 mode, the G50 coordinate system just before entering into the G53 mode is restored.		
P12		andle interrupt	In automatic operation, 0: 0.001mm (or °), 0.0001 inch 1: 0.01mm (or °), 0.001 inch		
Immediate	·	0: x 1 1: x 10	1: 0.01mm (of), 0.001 Inch		
P13	T-1 progr	cam judgment	Set NC to the following when MAZATROL T2/T3 is loaded with T-l program by		
Immediate	8	0: standard (YL-2) 1: optional (YL-3)	the CMT. 0: T-l program incapable of setting four work number digits. 1: T-l program capable of setting four work number digits.		



t yet de	Setting range solute select 0: invalid 1: valid M code menu	When an interruption is manually made in the automatic operation mode; O: The coordinate system shifts by the manual interruption stroke. 1: Approaching is performed up to the position just before the manual interruption. The coordinate system does not sift. Used to set the number of M code menu
t yet de	0: invalid 1: valid	in the automatic operation mode; 0: The coordinate system shifts by the manual interruption stroke. 1: Approaching is performed up to the position just before the manual interruption. The coordinate system does not sift. Used to set the number of M code menu
mber of	l: valid	position just before the manual interruption. The coordinate system does not sift. Used to set the number of M code menu
mber of	l: valid	position just before the manual interruption. The coordinate system does not sift. Used to set the number of M code menu
mber of	•	
mber of	•	
	M code menu	
		pictures. 0; The M codes with 1 digit are displayed
	0: 1 picture 1: 4 pictures	on a picture. 1: The M codes with 1 or 2 digits are displayed on four pictures.
t yet d	efined.	
Grooving bottom dwell		Used to set the dwell times at the groove bottom. Tool stops at the groove bottom while the spindle makes
m.	0-255	the revolutions set with this parameter.
t yet d	ifined.	
t yet d	efined.	
	oving l	yet defined. oving bottom dwell



	N					,			
Addresses	Unit		Significance & items						
P21	Amount of mill borin orientation		Used to set this at the hole bottom. 1) OUT 2) FCE						
Immediate	mm/1000 inch/10000	<u>+</u> 32767	-	P2 I		· .	P21		
P22	Not yet de	efined.							
P23	Not yet de	efined.						-	
P24	Not yet de	efined.							
P25	Not yet de	efined.			•				
P26	Not yet de	efined.							
P27	Not yet de	efined.							
P28	Not yet do	efined.							
P29	Not yet de	efined.							
P30	Not yet do	efined.							



	N	ames		
Addresses	Unit	Setting range	Significance & items	
U1	Tool swing X-axis (di	clearance ameter)	interference between the workpiece and the tool as the latter swings (X-direction).	*M
Immediate	mm/1000 inch/10000	0 – 65535	Max. outer diameter of workpiece	
U2	Tool swing Z-axi	clearance s	Used to the set distance to prevent interference between the workpiece and the tool as the latter swings (Z-direction).	*M
Immediate	mm/1000 inch/10000	0-65535	Length of projection of workpiece face	
U3	Not yet de	fined.		
U4	Fixed poin X-axi	t return posiiton s	U5	*M *E
Immediate	mm/1000 inch/10000	<u>+</u> 9999999	Machine zero-point U4 2 Fixed point	
U5 .	Fixed poin Z-axi	t return position s	<u> </u>	*M *E
Immediate	mm/1000 inch/10000	<u>+</u> 9999999		



	Na	ames	
Addresses	Unit	Setting range	Significance & items
U6		le clearance * dia. (diameter)	U8 U6/2
Immediate	mm/1000 inch/10000	0-65535	Max. outer diameter of workpiece Length of the projection of workpiece
U 7	Safe profi	le clearance	U8
Immediate	mm/1000 inch/10000	0-65535	U7/2 Min. inner diameter of workpiece
U8	Safe profi Face	le clearance end	See <u>U6</u> and <u>U7</u> .
Immediate	mm/1000 inch/10000	0-65535	
U9	Grinding e (width) #	scape pattern 1. #2. #3	Shapes #1, #2 and #3 (X: radius)
Immediate	mm/1000 inch/10000	0-65535	# 1 U 10 # 3
U10		scape pattern 1. #2. #3	U 10 # 3
Immediate	mm/1000 inch/10000	0-65535	U10 #2 U10 P U10 U9 P: program end point (right angle feed)

* Safe profile is obtained by adding the values of U6 - U8 clearances to those of the maximum outer diameter, minimum inner diameter and workpiece face projection specified for the approach from tool swing position to the cutting start point.



Addresses	Na	mes	04454
Addresses	Unit	Setting range	Significance & items
U11	Grinding es (width) #5	cape pattern	
Immediate	mm/1000 inch/10000	0-65535	#5
U12	Grinding es (depth) #5	cape pattern	U112
Immediate	mm/1000 inch/10000	0-65535	Same shape as #1; the size is changed. (X: radius value)
U13	Grinding es (width) #6	cape pattern	#6
Immediate	mm/1000 inch/10000	0-65535	U 14
U14	Grinding es (depth) #6	cape pattern	U13 P
Immediate	mm/1000 inch/10000	0-65535	Same shape as #2, the size is changed. (X: radius value)
U15	Grinding es (width) #7	cape pattern	#7
Immediate	mm/1000 inch/10000	0 - 65535	
U16	Grinding es (depth)	cape pattern	U 15 U 16 P
Immediate	mm/1000 inch/10000	0-65535	U16 U15 Same shape as #3, the size is changed. (X: radius value)



A 3 3	. Na	mes	Cimitiana S. itana	
Addresses-	Unit	Setting range	Significance & items	
U17	EIA/ISO restart, single step stop		When the EIA/ISO program restarts, it is possible to have the tool made a single step stop after having it approached to the machining start point.	*E
Immediate		0: invalid 1: valid	0: Single step stop is not made.1: Single step stop is made.	
U18	Rapid feed valid/	dry run invalid	On rapid feed program command, change is possible to manual mode feedrate code by operating the DRY RUN key.	*M *E
Immediate		0: invalid 1: valid	code by operating the DRI ROW Rey.	
U19	Threading o		During threading or tapping, a change is possible to manual mode feedrate by operating the DRY RUN key.	*M *E
Immediate		0: invalid 1: valid	by operating the bar and key.	
U20	Not yet def	ined.		
U21	Threading acceleration distance fixing value valid/invalid		Used to determine the validity of threading acceleration distance fixing value. 0: invalid	
Immediate		0: invalid 1: valid	Run is performed even on its shortage. 1: valid Alarm occurs if shortage exists.	
U22	Not yet dei	fined.		
U23		ncrease at wall rough machining i/invalid	The feedrate at the wall is variable during the bar rough machining cycle in the MAZATROL program.	*M
Immediate		0: invalid 1: valid	The feedrate here can be increased. Refer to U56 and U57 for further details.	



٠ ا	Na	nmes	Cinnificance C there
Addresses	Unit	Setting range	Significance & items
U24	Feed hold o	luring threading invlid	Pressing the FEED HOLD button in the threading cycle will cause the tool to escape from the workpiece while chamfering (finishing a thread). As a result, feeding is stopped. Press the CYCLE START button and the tool will start threading again from the
Immediate		0: invalid 1: valid	Position at which FEED HOLD has been aplied. Note: Only G92 and G76 in the EIA program are valid.
U25	Selection of operation	of G80's cycle	EIA/ISO G83/G87 cycle type selection and initial point return/R point return selection of G80's cycles. 0: Type of return in the amount same as that of relief (high-speed deep hole drilling cycle) during drilling
			1: Type of return up to R point (deep hole drilling cycle) during drilling Return to initial point 2: Type of return in the amount same as that of relief (high-speed deep hole drilling cycle) during drilling
Immediate		0 - 3	3: Type of return up to R point (deep hole drilling cycle) during drilling Return to R point
U26	Return to l change pos valid/inva		Used to determine whether or not to return the tool to the change position after running the M-process. 0: non-return
Immediate		0: invalid 1: valid	1: return
U27		the escape after	① normal ① ②
Immediate		0: normal 1: 45° 2: speed up	© Spect Sp. (2) See U70.

Mazak -

Addresses	Na	nmes	Significance & items
Addresses	Unit	Setting range	Significance & Items
U28	Measuring t	colerance range 1	T LIM-: lower tolerance limit a Set in program
			T LIM-: lower tolerance limit a ₂ program Offset made $ \left\{ \frac{a_1 - a_2}{100} * \boxed{U29} \ge \text{offset data} \ge \frac{a_1 - a_2}{100} * \boxed{U28} \right. $ $ \left\{ -\frac{a_1 - a_2}{100} * \boxed{U28} \ge \text{offset data} \ge \frac{a_1 - a_2}{100} * \boxed{U29} \right. $
Immediate	%	0-100	No offset made: $\frac{a_1 - a_2}{100}$ * U28 > offset data > $-\frac{a_1 - a_2}{100}$ * U29
U29	Measuring	tolerance range 2	
Immediate	%	0-100	Offset data are added incrementally to offset amount. This parameter is not valid for tool tip measurement.
U30	Not yet de	fined.	
U31	Not yet de	fined.	
บ32	Not yet de	fined.	
U33	Threading (diameter	finish allowance value)	
Immediate	mm/1000 inch/10000	1-65535	Threading finish allowance:
U34	Threading (radius va		Threading clearance: U34
Immediate	mm/1000 inch/10000	1-65535	



Addresses	Nai	mes	
Addresses	Unit Setting range		Significance & items
บ35	Fixing threacceleration	_	L Lo
· · · ·			Threading start point
			L: valid thread part Lo: acceleration distance
Immediate	lead/10	0-255	Lc: acceleration distance value $\boxed{\text{U35}}$ When Lo > Lc, acceleration alarm occurs. When $\boxed{\text{U21}}$ = 0, however, no alarm occurs and cutting is performed.
U36	Thread cham	fer value	L ₂ L ₁ L Start point
Immediate	lead/10	0-40	L: effective thread length L1: even pitch incomplete thread length L2: chamfer value U36 : chamfer angle
U37	Threading depth constant Metric (outer dia., face end)		
Immediate	%/100	0-32767	This parameter sets the thread ridge height and is computed using the following equation.
U38	Thread cham Metric (inn		Height = pitch x parameter Metric Inch OUT U37 U39
Immediate	%/100	0-32767	IN U38 U40 FCE U37 U39
U39		epth constant dia., face end)	Standard settings: U37) 6495(thread angle 60°)
Immeidate	%/100	0-32767	U38 h=0.6495P U39) 6403(thread angle 55°) U40 h=0.6403P
			h: thread ridge height, P: pitch JIS recommended value
U40	Threading d Inch (inner	epth constant dia.)	
Immediate	%/100	0-32767	



Addresses	Na	mes	Significance & items
uddi esses	Unit Setting range		Significance of flems
U41	X-axis grooving clearance (diameter value)		
Immediate	mm/1000 inch/10000	0-65535	U6/2 U41/2 U8 OUT IN
U42	Z-axis groo	ving clearance	U 42
Immediate	mm/1000 inch/10000	0-65535	
U43	Grooving re	lief	Used to set pecking return distance on deep grooving.
Immediate	mm/1000 inch/10000	0-65535	
U44	Grooving overlap		Used to set tool width overlap on wide grooving.
Immediate	mm/1000 inch/10000	0–65535	L: groove width d: tool width L U44 L: groove width U44 L U44 L: groove width
U45	Grooving re	tracting rate	Used to set feedrate for retracting from from the groove bottom.
Immediate	mm 1000/rev inch 1000/rev	0-65535	
U46	Not yet def	ined.	
U47	Not yet def	ined.	
			N#25 A-A233 1 1 4 4 55 A 5 A 80



Addresses		nes	Significance & items	
Addresses	Unit	Setting range	Significance & items	
U49	Drill feed	tolerance	D di d1	*M
Immediate	mm/1000 inch/10000	0-65535	D: drill feed dl: depth of lst pass di: depth of n-th pass di = dl - U49 x (i-1) (when di ≥ b) di = b b: drill feed fixing parameter U53	
บ50	Drill relief amount		Relief amount in the high-speed deep hole drilling cycle	*M
Immediate	mm/1000 inch/10000	0–65535		
U51	Drill feed coefficient		Set to automatically fix the first drill feed.	*M
	%	0-999	dl = Drill dia. x $\frac{\boxed{\text{U51}}}{100}$	
U52	Reamer reci coefficient	procating rate	Parameter to determine reamer reciprocating rate	
Immediate	%	0-999	Reciprocating rate = feedrate $\times \frac{\overline{U52}}{100}$	
U53	Fixing drill feed (min.)		Feed is determined as follows: First feed - U49 x (n-1)	*M
Immediate	mm/1000 inch/10000	0-9999999	n: feed times Set the minimum value.	
L	<u> </u>			ď



	Nan	nes		
Addresses	Unit	Setting range	Significance & items	
U54	thread ridge		Used to add the offset value to the tap path value (the value obtained by following computation to final point value). Pitch x $\frac{\overline{\text{U54}}}{10}$	*M
Immediate	pitch/10	0-99	Pitch is fixed by program. 1 : $\frac{\overline{\text{U54}}}{10}$ 2 : $\overline{\text{U8}}$ 3 : $\frac{\overline{\text{U55}}}{10}$	
U5 5	Allowing for	tap elongation	Used to compensate tap path with tap elongation taken into account (the value obtained by adding following computation to the value of start point + clearance).	*M
Immediate	putch/10	0-99	Pitch x $\frac{\overline{\text{U55}}}{10}$ Pitch is fixed by program.	
U56			Used to set the ratio of the feedrate increase at last wall during bar rough machining.	* <u>M</u>
Immediate	%	100-200	When $a \neq 0$, increase ratio = $\overline{U56} \times \frac{b}{a}$	
U57 ·		,	When $a = 0$, increase ratio = $\overline{U57}$ When increase ratio > $\overline{U57}$, it becomes	
Immediate	%	100-200	This function is valid only when <u>U23</u> = 1 and only for the final block at last wall during bar rough machining cycle.	
U58	1	e feedrate yond the work- in copy (CPY)	While part of tool path is beyond the workpiece shape in the rough machining CPY cycle, the machining feedrate can be increased.	*}
Immediate	%	100-200	Feedrate beyond the workpiece shape = feedrate inside workpiece shape x (100 + U58)/100	



Addresses	Nai	nes	Cionificanos C itama
Addresses	Unit	Setting range	Significance & items
U 59	Decrease ramachining c		Specified feed can be decreased as work thickness decrease in O.D. or I.D. rough turning. Object of O.D. or I.D. turning: residual
Immediate	%	1-100	part of the thickness obtained when inner or outer diameter is set at minimum or maximum respectively.
U60	Overlap cleaduring rough	arance at wall h machining	Used to set the clearance for the final relief in rough machining by MAZATROL program.
	/1000:		7777
Immediate	mm/1000 inch/10000	0-65535	Relief amount: U60
U61	EDG relief	amount	Used to set the return distance after rough machining the face end.
Immediate	mm/1000 inch/10000	0-65535	Relief amount: U61
U62 _.	Minimum thro	eading feed	Valid on the threading cycles by EIA/ISO program.
			$ \begin{array}{c c} \hline & \triangle d \\ \hline & 1st \\ \hline & d \leq 2 \end{array} $
			△d: depth of the lst pass (program-specified) di: depth of the i-th pass
Immediate	mm/1000 inch/10000	0-65535	$di \leq b: di = b$ $di > b: di = \Delta d \times (\sqrt{i} - \sqrt{i-1})$ $b/2 = \boxed{U62}$
		and the second s	



Addresses	Names			
Addresses	Unit	Setting	range	Significance & items
บ63	Not yet defi	ined.		
,4				
U64	Not yet defined.			
U65	Not yet defined.			
U66	Not yet defined.			•
U67	Not yet defined			
U68	Not yet defined.			o
U69	Not yet defined.			
บ70	Coefficient of increasing feedrate when U27 = 2			F ₁
Immediate		0-99		$F_2 = F_1 \times \overline{U70}/10$ Where $\overline{U70} = 0$, F_2 is regarded as 10.
u71	Not yet def	ined.	din na na il mangana a alam a an	
U72	Not yet def	ined.		



Addresses	· Nai	nes	Significance & items
Addresses	Unit Setting ra		Significance & Items
U73	setting work	utomatically k coordinate he return to ce point	Used to set this for the dog type zero-point return during automatic operation by EIA program.
Power on	mm/1000 inch/10000	<u>+</u> 9999999	Reference point U74 (Dog type zero-point
U74	setting wor	utomatically k coordinate he return to ce point	Program zero-point X-, Z-axis
Power on	mm/1000 inch/10000	<u>+</u> 9999999	
บ75	Not yet def	ined.	
U76	Initializin display (X- diameter va	axis:	Used to specify the tool path starting point for checking.
Immediate	mm/1000 inch/10000	<u>+</u> 9999999	
บ77	Initializin display (Z-		Used to specify the tool path starting point for checking.
Immediate	mm/1000 inch/10000	<u>+</u> 9999999	Note: Always "0" for C-axis.
บ78	Not yet defined.		
U79	Not yet def	ined.	



Machine Parameters

Addresses	Nam	es	Significance S its	
Addresses	Unit	Setting range	Significance & items	
BL (X.Z)	Backlash com	pensation	Used to electrically compensate X-and Z-axis move errors with respect to command value (X-axis: radius)	
Immediate	X.Z mm/1000	0-255		
ZP (X.Z)	Zero-point s	hift distance	Limit S/W —— Return direction Zero-point shift distance: ZP Approx. point dog Approx. Point dog	
Immediate	X.Z mm/1000	0-16383	distance Machine zero-point Electric zero-point	
DF (X.Z)	Zero-point approach rate		Approaching speed to zero-point Approx. point dog zero-point Zero-point return rate Machine zero-point	
Power on	X.Z mm/min	0-500	o Only the zero-point return on the power supply, emergency stop, etc. o After first time, zero-point return is performed at high speed.	
ZR (X.Z)	Zero-point return direction		When viewed from the dog, the machine zero-point is	
Power on		0/1	on the + side: ZR=0 on the - side: ZR=1	
* RF (X.Z)	Rapid feedrate		Used for setting rapid feedrate. If no zero-point return is completed, however, it is performed at a rate set by parameter A3.	
Power on	X • Z	0-20000		



Addresses	Name	s	
Addresses	Unit	Setting range	Significance & items
TC (X.Z)	Rapid feed de constant	celeration	Used to set the time constant of the increase to or the stop of rapid feed.
Power on	msec	0-500	Exponential rise between TC set values or linear stop between 2 and TC set value.
MC (X.Z)	Servo constant d1, d2, d3		dl: linear zone d2: polarity d3: τ setting
Power on		d1: 0-3 d2: 0/1 d3: 1.2.4.8	
OD (X.Z)	Ratio of decr constant on s deceleration	easing oftware limit	Used to determine deceleration constant in deceleration stop mode (OT-0) when turret exceeds software limits (B1 - B4).
Power on	%	0-63	Time constant = TC x (1-OD/100) TC: rapid feed deceleration constant
LP (X.Z)	Constant for threading acc distance		Omitted
Power on	1/sec	20–50	
* ED (X.Z)	Setting cutti deceleration error detecti	(width of	Used to determine corner roundness. ED M51: error detect OFF M52 M52: error detect ON
	X.Z mm/1000		M51 M52: effor detect on
Power on	inch/10000	0-2000	On power supply: M52
* HS (X.Z)	Fixing manual interrupt	handle	Used to set the maximum handle interrupt value.
(X.Z mm/1000	No larger interrupt is allowabl (X-axis: diameter setting)	
Immediate	inch/10000	0-32767	



L	Name	es			
Addresses	Unit	Setting range	Significance & items		
TCC (X.Z)	Machining fee	ed constant	Used to set the time constant of the increase to or the stop of machining		
Power on	msec	0-500	feed. Both rise and stop are logarithmically performed at the TCC set time value.		
OT (X.Z)	Software lim	it stop mode	Used to select the stop mode when software limit is reached. 0: deceleration stop		
Power on		0-2	Refer to parameter OD. 1: speed loop step		
			stop Normally, should 2: servo OFF step not be used. stop		
SG (X.Z)	Scale specifications	ication 3-times distance	Omitted		
Power on	pulse	0-500			
JF (X.Z)	Upper machin	ing feed limit	Used for setting the upper feed limit including override during jog cutting. (Not used for X- and Z-axes.)		
Power on		0-20000			
AU (X.Z)	Not yet defin	ned.			
GR1-GR5	Maximum spind for gears 1		Used for setting the maximum spindle revolutions for each gear. GR1 - GR5 must not be changed because		
Power on	rpm	0-16000	they are used to automatically select gears. They correspond to gears, depending on machine models.		



Addresses	Name	es	
	Unit	Setting range	Significance & items
GR6-GR8	Not yet defin	ned.	
HP1-HP5	Not yet defin	ned.	
нр6-нр8	Not yet defi	ned.	



Addresses	Names .			
Addresses	Unit	Setting range	Significance & items	
A1	Specified distance for changing the thread end finish constant		G-point B-point A-point G 32	*1
			Normally the tool moves from A point to C point according to the rapid feed time constant. In this case, however, it	
Immediate		0-2000	moves as follow: A point \rightarrow B point: cutting feed time constant B point \rightarrow C point: rapid feed time constant L = $\overline{\text{RF}}/60 \times 0.017 \times \overline{\text{Al}}$	
A2	Thread accel	nread acceleration pitch $$ If pitch is P and pitch error is Δ		*1
Power on	0.1%	1-20	thread acceleration distance.	
A3	Deceleration of the rapid feedrate at the dog type zero-point return		Normal feedrate decelerates as set by this parameter at the first zero-point return after turning on the power or cancelling an emergency stop	*E
Power on	%	0-100	(until stepping the dog). Zero-point return rate = rapid feedrate x rapid feed deceleration/100 = RF x A3/100	
e to according			DF rate is obtained after stepping the dog (refer to DF).	
A4 ⁻	Zero-point return from the zero-point dog		When the zero-point return from the zero-point dog occurs; 0: Return to zero can occur. 1: Only the X-axis travel cannot occur.	*! *!
Power on		0-3	2: Only the Z-axis travel cannot occur. 3: Neither the X-axis nor the Z-axis travel can occur.	



	Names		
Addresses	Unit	Setting range	Significance & items
A5	EIA/ISO starting conditions		In the EIA/ISO mode, the alarm can be triggered if the X-axis and the Z-aixs zero-point return cannot be accomplished. (except the C-axis). O: Alarm is triggered when return to zero has not been accomplished.
Powwer on		0-1	1: Program can be run even when return to zero has not occurred.
A6	Offset-commanded axis move by EIA/ISO		Determine if the axis move occurs with an offset when a single T command is input during the EIA/ISO program. O: No axis move by the offset command (When the next axis move command comes,
Power on		0-1	there is a displacement with an offset) 1: Axis displacement by offset command.
A7	Selecting the cycle starting conditions		It is possible that starting may not be accomplished with various selected pictures. O: Cycle start is inhibited with the WORK PROGRAM, LAYOUT, SIMULATION, CHECK and
Power on		0: invalid 1: valid	SHAPE CHECK pictures. 1: Cycle start is possible only with the WORK PROGRAM and SHAPE CHECK pictures.
A8	Not yet defir	ned.	
* A9	Fixing spindle revolutions		Used to set the maximum value of spindle revolutions.
Immediate	rpm	0-16000	
* A10	Not yet defined.		
		•	
		·	



	Name	es	01151	
Addresses	Unit	Setting range	Significance & items	
A11	Not yet defin	ned.		
A12	Not yet defin	ned.		
A13	Not yet defin	ned.		
A14	Timer for premeasuring ski		Omitted.	*M *E
Power on	2.2msec	0-65535	Omreed.	
A15	RS232C parameter for serial tape reader/puncher		Omitted.	*E
Power on	bit	0/1		
A16	RS232C parame serial tape	eter for reader/puncher	Omitted.	*E
Power on	bit	0/1		
A17	RS232C baud 1	rate for CMT	Used to set the baud rate for CMT (cassette data) I/O.	*E
			1: 100 (bps) 2: 300 3: 600 4: 1200	
Power on		1-6	5: 2400 6: 4800 7: 9600 8: 19200	
A18	RS232C baud iserial tape i	rate for reader/puncher	Used to set the baud rate for connecting tape reader/puncher. (The contents are the same as in A17.)	*E
Power on		1-6		



Addresses	Names		
	Unit	Setting range	Significance & items
A19	Tape reader rewind code		Used to specify the rewind code outputted from the NC when using the tape reader with rewinding feature.
Immediate	· .	0-255	
* A20	N/C tape output code		Used to specify the code for punching the program tape.
Immediate		0/1	0: EIA code 1: ISO code
* A21		Used to specify the number of the code for the spaces between the work number and data. Tape Work No. Data	
Immediate	space codes /10	0-5	Number of space codes
* A22	Tape punch output - number of space codes between programs		Used to specify the number of space codes between programs if one tape contains several programs. Programm
Immediate	space codes /10	0-5	Specify the space code by A22.
* A23	Tape punch output - number of head and tail feed		Tape ER: (%) Pro gram
Immediate	number of feeds/10	0-255 -	The number of head The number of tail feeds is set to A23. feeds is set to A23.
* A24	T/V check - valid/invalid		Setting the validity of T/V check for input paper tape.
Immediate		0: invalid 1: valid	



Addresses	Name	·s	Cionificano Citare
Audresses	Unit	Setting range	Significance & items
A25	Spindle gears		Parameter setting No setting is made value. to "0".
Immediate		0-5	2 2nd gear spec. 3 3rd gear spec. 4 4th gear spec. 5 5th gear spec.
A26	Not yet defir	ed.	
A27	Intervals of reach signal	checking speed	Omitted.
Immediate	17.7 msec/ 100 rpm	0-255	
A28	Gear ratio between spindle and encoder		Gear ratio = $\frac{\text{spindle rev.}}{\text{encoder rev.}}$
Power on		0-9	
* A29	Detection of the tape reader program end		Used to set the detection point of tape reader program end. 0: Program end when reading M30, M99, M198 and M199
Immediate		0/1	1: Program end when reading M30, M99, M198, M199 or 0-code, ;-code.
* A30	Serial/paral	lel change-over	Bits 0 : serial reader 1 : ON, 0 : OFF 1 : serial punch 1 : ON, 0 : OFF
Power on	bit	0/1	2: parallel reader 1: ON, 0: OFF 3: parallel punch 1: ON, 0: OFF
			Note: Invalid for both serial and parallel readers when they are on. Invalid for both serial and parallel punchs when they are on.
•			



Addresses	Names		Cionificanco I desma	
Addresses	Unit	Setting range	Significance & items	
* A31	#-code for EIA punch		Used to specify the #-code for EIA punch.	*E
Immediate		0-255		
* A32	:-code for EIA punch		Used to specify the :-code for EIA punch.	*E
Immediate		0-255		

Mazak -

A d d m = = = = =	Names		Cionificano C itama				
Addresses	Unit	Setting range	Significance & items				
* B1 #1	Software limi		Used for	setting	the so	ftware limi	
Immediate	mm/1000 inch/10000	<u>+</u> 9999999				D2	P 1
* B2 #1	Software lim	it: +Z		B4		Machine zero-point	
	mm/1000 inch/10000	<u>+</u> 9999999	B 3 /2			Spindle center line	
* B3 #1	Software lim		P2				
Immediate	mm/1000 inch/10000	<u>+</u> 9999999		•		· ·	
* B4	Software lim	it: -Z					
#1	mm/1000 inch/10000	<u>+</u> 9999999					
* B5 #1	Chuck barrie	r					
Immediate	mm/1000 inch/10000	<u>+</u> 9999999			.:		
* B6 #1	Chuck barrie	F	·	B6 B8			• •
	mm/1000 inch/10000	<u>+</u> 9999999		B5	B7		



	Names		
Addresses	Unit	Setting range	Significance & items
* B7 #1	Chuck barrie	•	Refer to B5 and B6.
Immediate	mm/1000 inch/10000	<u>+</u> 9999999	
* B8	Chuck barrie		Refer to B5 and B6.
#1 Immediate	mm/1000 inch/10000	<u>+</u> 9999999	
* B9	Tail barrier		1. For shaft work
#1 Immediate	mm/1000 inch/10000	<u>+</u> 9999999	B 15
* B10	Tail barrier		B 14 B 10
#1 Immediate	mm/1000 inch/10000	<u>+</u> 9999999	B13 B13 Length of tailstock projection
* B11	Tail barrier		(Setting on the PROGRAM FILE picture)
#1 Immediate	mm/1000 inch/10000	<u>+</u> 9999999	
* B12	Tail barrier		
#1 Immediate	mm/1000 inch/10000	<u>+</u> 9999999	



A 3 3	Name	es ,	Significance & items		
Addresses	Unit	Setting range	Significance & items		
* B13 .	Tail barrier		2. For chuck work		
#1 Immediate	mm/1000 inch/10000	<u>+</u> 9999999	B14		
* B14	Tail barrier		B12 3×B10 B10		
#1	mm/1000 inch/10000	<u>+</u> 9999999	Tailstock (Setting on the COMMAND picture)		
* B15	Tail barrier				
#1	mm/1000 inch/10000	<u>+</u> 9999999			
* B16 #1	Not yet defin	ned.			
* B17	Reference too		W. L.		
(B1#2) Immediate	mm/1000 inch/10000	<u>+9</u> 999999	B18 Machine zero-point		
* B18	Reference too		B 17/2		
(B2#2) Immediate	mm/1000 inch/10000	<u>+</u> 9999999			
			Reference of spindle face end		



Names		Cionificano C itama	
Unit	Setting range	Significance & items	
		Holder type 1: In case that the value of the holder mounting location is positive.	
mm/1000 inch/10000	<u>+</u> 9999999	B 20	
Width of turn Z-direction	et body:	A B B 19	
mm/1000 inch/10000	<u>+</u> 9999999	 	
1	•	In case that the value of the holder mounting location is negative.	
mm/1000 inch/10000	+9999999	B 20 B 19	
Width of tool holder (tool barrier): Z		A B C	
mm/1000 inch/10000	+9999999	Holder A B C Stick tool	
		1 B21 B22 B23 barrier to	
mm/1000 inch/10000	<u>+</u> 9999999	Holder type 0 means no holder. Different turret drawings are obtained for the different mounting locations of holder.	
	Unit Width of turn X-direction (mm/1000 inch/10000 Width of turn Z-direction mm/1000 inch/10000 Width of tool barrier): X (mm/1000 inch/10000 Width of tool barrier): Z	Width of turret body: X-direction (radius) mm/1000	



	Names			
Addresses	Unit	Setting range	Significance & items	
* МЗЗ	X-axis tool-e ment sensor	axis tool-edge measure- Used to input sizes with respect to the tool-edge measurement sensor. (RENISHAW touch (MT pulse)		*M
Immediate	mm/1000 inch/10000	0-65535	sensor) generator)	
* M34	Z-axis tool-e ment sensor	dge measure-	M34/2 M34/2	*M
Immediate	mm/1000 inch/10000	0-65535	M 34 M 34	
* M35	Correction data for the diameter of the measurement sensor when measuring the outside diameter and the width.		Outside diameter $Ax = \left \frac{\#1 - \#2}{2} \right - 2R + \boxed{M35}$ Width $Az = \left \#1 - \#2 \right - 2R + \boxed{M35}$	*M
Immediate	mm/1000 inch/10000	-32767 - 32767	Ax, Az: Values measured #1, #2: Sensor starting positions R: Contact sensor tip radius	
* M36	Correction data for the diameter of the measurement sensor when measuring the inside diameter and the groove.		Inside diameter $Ax = \left \frac{\#1 - \#2}{2} \right + 2R + \boxed{M36}$ Groove $Az = \left \#1 - \#2 \right + 2R + \boxed{M36}$	*M
Immediate	mm/1000 inch/10000	-32767 - 32767		
* M37	Measurement s	speed	Omitted.	*!
Immediate			•	
* M38	Measurement s	speed	Omitted.	*1
Immediate				



Names			
Unit	Setting range	Significance & items	
Tool-edge mea	suremnt sensor xis: diameter)	Reference point M43	*E *M
mm/1000 inch/10000	<u>+</u> 9999999	Used to specify the contact sensor reference point with X and Z coordinates using the workpiece coordinate system.	
Not yet defir	ed.		
Not yet defir	ned.		
Not yet difir	ned.		
Tool-edge measurement sensor position (Z-axis)		See Parameter M39.	*E *M
mm/1000 inch/10000	<u>+</u> 9999999		
tool whose ed	ige is to be	Used to specify the change position of the tool whose edge is to be measured using the machine coordiange system.	*M
mm/1000 inch/10000	<u>+</u> 9999999	Machine zero-point M45 Tool change position	
	Unit Tool-edge mea position (X-a mm/1000 inch/10000) Not yet defin Not yet defin Tool-edge mea sensor position mm/1000 inch/10000 Position for tool whose ed measured (X-axis: diam mm/1000)	Tool-edge measuremnt sensor position (X-axis: diameter) mm/1000	Unit Setting range Tool-edge measuremnt sensor position (X-axis: diameter) Touch sensor reference point M43 Tool-edge measuremnt sensor reference point Morkpiece reference point workpiece reference point with X and Z coordinates using the workpiece coordinate system. Not yet defined. Not yet defined. Tool-edge measurement sensor position (Z-axis) mm/1000



Unit Position for tool whose ed measured (Z amm/1000 inch/10000) Not yet defin Workpiece measuroke	Setting range changing the lige is to be axis) +9999999	Significance & items See Parameter M44.
Position for tool whose ed measured (Z amm/1000 inch/10000	changing the dge is to be axis) +9999999	,
tool whose ed measured (Z a mm/1000 inch/10000 Not yet defin	tge is to be axis) +9999999	See Parameter M44.
inch/10000 Not yet defir Workpiece mea	ned.	A
Workpiece mea		A
, -	asurement	A
		Max.stroke (measurement zone) C
mm/1000 inch/10000	0-65535	Used to specify the distance to the start point A in the measurement zone with respect to he selected point B. If no sensor signal is given while moving to the final point C in the measurement, an alarm will be given resulting in an immediate stop.
Workpiece mea	asurment	
mm/1000 inch/10000	0-65535	Same as M47, used to specify the tool-edge measurment zone.
		C B W W W W W W W W W W W W W W W W W W
	inch/10000 Workpiece meastroke	workpiece measurment stroke mm/1000 0-65535



Addresses	Names			
Addresses	Unit	Setting range	Significance & items	
* S13	NC data auxiliary command interval (during simulation)		Parameter for adjusting the time used during simulation. Used to specify the time required for the	*M
Immediate	0.1 sec	0-65535	M codes and the speed range change.	
* S14	NC data auxiliary command interval (during simulation)		Parameter for adjusting the time used during simulation. Used to specify the time required for the T commands (tool rotation, ATC).	*M
Immediate	0.1 sec	0-65535	T Commands (1901 Totalion, A10).	
* S15	Advance speed Advance speed X-axis during	d of the	Used to specify the final approach rate when the TPS function is being used, when there is no approach interruption after the power is turned on. For the EIA run	
Immediate	mm/min	0-20000	used to sepcify the speed of travel towards the machining start point along the X axis.	

10-38E



11. ALARM

If an error occurs, an ALM status indicator lamp on the operating panel will come on and the alarm number and message be displayed below the name of the CRT picture. In this case check, repair and eliminate the cause. Several alarms if displayed should be checked using the DIAGNOSIS picture.

- Status indicator lights different lights come on for different error locations.
 - ? MC ALM Machine alarm
 - ? TOOL ALM ... Tool alarm
 - ? NC ALM NC alarm

Several lights turn on in some error conditions.


 Alarm numbers - different alarm numbers are used to identify different error locations.

Alarm	No.	Description

- 0 99 Alarms for the NC printed board and servoamplifier hardware
- 100 199 Alarms for the operation of X- and Z-axes and spindle
- 200 299 Alarms for electrical control panel and machine
- 300 399 Alarms for program contents (in preparation)
- 400 499 Alarms for key handling
- 500 599 Alarms for MAZATROL program contents (on check and tracing)
- 600 699 Alarms for EIA/ISO program contents (on check and tracing)



o The alarm location is displayed in the program picture for any program content alarm (300, 500 or 600-order alarm). Refer to these when correcting alarm causes.



- 3. Alarm color display
- Alarms are red or blue.

 Generally use AESET or CLEAR key when cancelling red or blue alarms, respectively. Do not press the AESET key for a blue alarm while the background program is being prepared in automatic operation, because this will stop the automatic operation.

4. Alarm table

1) Occurrence

Symbol	Contents
A	Machine/Electrical control panel
В	NC unit
C	Servo-amplifier/Sensor
D	Machining program/Operation
E	Key-input

Mazak -

2) Status of stop

Symbol	Contents
F	Emergency stop
G	Reset
Н	Single step stop
I	Feed hold
J	Operation continues

3) How to release

Symbo1	Contents								
K	Release not available (adjustment after power OFF)								
L	Power ON after releasing the cause								
М	(reset) key ON after releasing the cause								
N	(reset) key ON								
0	(clear) or (reset) key ON after releasing the cause								
P	🖄 (clear) key ON								



o System alarm

No.	Message	Display color	1)	scription Status in which error has taken place. Action taken or to be taken.	Occur- rence		How to Release
1	SERVO LAG EXCESS X AXIS	Red -	1)	The machine had a time lag in following on the X-axis in excess of a specified value in relation to the motion command.	С	F	L
2	SERVO LAG EXCESS Z AXIS	Red	1)	The machine had a time lag in following on the Z-axis in excess of a specified value in relation to the motion command.	C	F	L
3	SERVO LAG EXCESS C AXIS	Red	1)	The machine had a time lag in following on the C-axis in excess of a specified value in relation to the motion command.	С	F	L
5	SERVO OSCILLATION X	Red	1)	A tool did not stop at a specified position while moving on the X-axis but continues to back and forth.	С	F	L
6	SERVO OSCILLATION Z	Red		A tool did not stop at a specified position while moving on the Z-axis but continues to back and forth.	С	F	L
7	SERVO OSCILLATION C	Red	1)	A tool did not stop at a specified position while moving on the C-axis but continues to back and forth.	С	F	L
9	DETECTING NO SIGNAL X	Red	1)	No feedback signal is returned from the X-axial resolver in response to a NC unit command.	С	F	L



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
10	DETECTING NO SIGNAL Z	Red	 No feedback signal is returned from the Z-axial resolver in response to a NC unit command. 	C ·	F	L
11	DETECTING NO SIGNAL C	Red	 No feedback signal is returned from the C-axial resolver in response to a NC unit command. 	С	F	L
13	DRIVE ALARM X AXIS	Red	1) The X-axial servo- amplifier thermal relay has tripped or a no-fuse circuit breaker has opened. An error on the X-axis is too large or a feed- back signal is not received from the resolver.	С	F	L
14	DRIVE ALARM Z AXIS	Red	1) The Z-axial servo- amplifier thermal relay has tripped or a no-fuse circuit breaker has opened. An error on the Z-axis is too large or a feed back signal is not received from the resolver.	C	F	L
15.	DRIVE ALARM C	Red	1) The C-axial servo- amplifier thermal relay has tripped or a no-fuse circuit breaker has opened. An error on the C-axis is too large or a feed back signal is not received from the resolver.	C a	F	L



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	l .	How to Release
18	NMI POWER OFF	Red	1) With the power turned off, CPUs 1 and 2 operate improperly and the watch dog timer (to detect a hardware error while being normally reset repeatedly) is not reset.	С	F	L
19	NMI EMERGENCY STOP (PROGRAM)	Red	l) With the system stopped for a software emer- gency, the watch dog timer (to detect a hardware error while being normally reset repeatedly) is not reset.	С	F	L .
20	NMI EMERGENCY STOP	Red	 With the emergency stop button on the operating panel or in the electric control panel depressed, the watch dog timer (as referred to above) is not reset. 	C	F	L
21	NMI WATCH DOG ALARM	Red	1) With the main CPU mal- functioning, the watch dog timer (as referred to above) is not reset.	С	F	L
22	NMI MEMORY PARITY	Red	1) As a result of conducting a parity check (to detect an error by arranging to an odd or even number the number of 1s contained in the whole number by adding a bit to a group of 0 and 1 combinations) on the data in the main CPU system memories, an error or errors are found.	В	F	Ĺ



		*			,	
No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
23	NMI BATTERY ALARM	Red	 The voltage of the battery connected to the system circuit board dropped below rated value. 	В	F	L
24	NMI MEMORY GUARD	Red	 A CPU malfunction or self-diagnosis function (to write data) has entered data in an address area with no memory. 	В	F	L
25	NMI SERVO DRIVE ALARM	Red	1) A thermal relay has tripped or no-fuse circuit breaker has opened to X- and Z-axis servoamplifiers. Certain X- and Z-axis servoamplifiers have an excessively large error but no feedback signal has come from the resolver.	С	F	L
26	SUM CHECK ERROR	Red	1) The optional ROM (language, EIA, MILL, DNC) has not been installed or is installed incorrectly.	В	F	К



o Motion alarm

No.	Message	Display color	escription) Status in which error has taken place.) Action taken or to be taken.	- Status of stop	How to Release
101	STORED STROKE LIMIT +X	Red) The limit in the +X D direction is reached or a command is given beyond that limit. (The X-axis has reached the area determined by the parameter Bl).	G	N
102	STORED STROKE LIMIT -X	Red) The limit in the -X direction is reached or a command is given beyond that limit. (The X-axis has reached the area determined by the parameter B3.)	G	N
103	STORED STROKE LIMIT +Z	Red) The limit in the +Z direction is reached or a command is given beyond that limit. (The Z-axis has reached the area ditermined by the parameter BZ.)	G	N.
104	STORED STROKE LIMIT -Z	Red) The limit in the -Z direction is reached or a command is given beyond that limit. (The Z-axis has reached the area determined by the parameter B4.)	G	N
109	OVER TRAVEL +X	Red) The overtravel limit D switch in the +X direction has functioned.	G	N
			Continue to press the RESET and O.T. RELEASE buttons until the READY signal begins to operate. When this signal operates, stop pressing the RESET key only, to move the tool in the -X direction.		



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	1	How to Release
110	OVER TRAVEL -X	Red	 The overtravel limit switch in the -X direc- tion has functioned. 	D	G	М
			2) Continue to press the RESET and O.T. RELEASE buttons until the READY signal begins to operate. When this signal operates, stop pressing the RESET key only, to move the tool in the +X direction.			
111	OVER TRAVEL +Z	Red	 The overtravel limit switch in the +Z direc- tion has functioned. 	. D	G ~	М
			2) Continue to press the RESET and O.T. RELEASE buttons until the READY signal begins to operate. When this signal operates, stop pressing the RESET key only, to move the tool in the -Z direction.			
112	OVER TRAVEL -Z	Red	 The overtravel limit switch in the -Z direction has functioned. 	D	G	М
	•		2) Continue to press the RESET and O.T. RELEASE buttons until the READY signal begins to operate. When this signal operates, stop pressing the RESET key only, to move the tool in the +Z direction.			
117	CHUCK BARRIER	Red	l) The tool interferes with the chuck barrier.	D	G	N ·
118	TAIL BARRIER	Red	l) The tool interferes with the tailstock barrier.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
130	ILLEGAL PARAM. DATA (OP6,15,16)	Red	1) Incorrect input of the OP6 parameter for the PC model machine or the OP15 and OP16 parameters for selecting the machine model for NC.	В	F	М
131	ILLEGAL PARAM. DATA (M1-M12)	Red	1) Incorrect input of the M1 to M12 parameters for the tool number and the number of tools.	В	F	М
140	SELECT C AXIS	Red	1) The NC is trying to execute a C-axis command when the C axis is not connected.	D	G	N
142	MILLING MODE UNFINISHED	Red	1) The angle-indexing command is given but the machine with 1°-orientation feature is not in the milling mode.	D	G	N
143	INTERLOCK AXIS MOVE ALARM	Red	1) A command to move the axis interlocked is given.	D	G	N
145	ILLEGAL PARAM. DATA (GR1-5)	Red	Not used.			
149	ILLEGAL TOOL OFFSET NO.	Red	1) The tool offset number input exceeds the setting range.	D	G	N
150	ILLEGAL POCKET	Red	1) Setting incorrect or double of the pocket number on the mahcine with A.T.C.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
151	TOOL LIFE TIME ERROR (NUMBER)	Red	 Machining has exceeded the tool life number of workpieces inputted on the TOOL DATA picture. 	D	G	N
152	TOOL LIFE TIME ERROR (TIME)	Red	l) Machining has ex- ceeded the tool life time of workpieces inputted on the TOOL DATA picture.	D	G	N
153	X-MAX OR Z-MAX OFFSET OVER	Red	 Machining has exceeded the max. tool wear value inputted on the TOOL SET picture. 	D	G	N
154	WORKPIECE PROGRAM NOT FOUND	Red	1) While in the automatic mode, the NC attempts to search the number of workpiece in the END process or the number of external workpiece, but the programmed number of workpece does not exist.	D	G	N
155	START CYCLE ON COMMAND DISPLAY	Red	Not used.			
156	LAYOUT NOT COMPLETE	Red	1) The number of the part to be processed has not been laid-out.	D	G	N
157	NO TOOL NUMBER IN PROGRAM	Red	 Layout is impossible because of the machin- ing program is incorrect. 	Ď	G	N
167	TOOL SELECT ERROR	Blue	Not used.			
170	DATA NOT INPUT	Blue	1) The CYCLE START button was pressed without inputting the data while in the RESTART, SINGLE PROCESS or TEST mode.	D	G	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
171	HOME RETURN UNFINISHED	Blue	1) The CYCLE START button was pressed but there was no X-axis or Z-axis return to zero after the power was turned on.	D	G	P
172	SELEC AUTO MODE	Blue	1) The CYCLE START button was pressed in manual mode.	D	G	P
173	AUTO START INSUFFIC. (PROT.)	Blue	1) The CYCLE START button was pressed as the cycle start was blocked (such as by the FEED HOLD button being pressed, while CMT I/O was being performed, or while the shape of the workpiece was being displayed, etc.).	D	G	Р
174	AUTO START INSUFFIC. (MODE)	Blue	1) 1. When a restart is made after using manual interruption while in automatic mode, the first mode and the current mode are not the same. 2. the NC attempts to perform the simulation in other automatic modes than the AUTO Mode.	D	G	P
175	AUTO START COND INSUFFIC. (TOOL)	Blue	1) When a restart is made after using manual interruption while in automatic mode, the original tool number and the current tool number are not the same.	D	G	P



					······································	
No.	Message	Display color	nas taken place.	Occur- rence	Status of stop	How to Release
176	START CYCLE ON COMMAND DISPLAY	Blue	1) The CYCLE START button was pressed with a picture where the CYCLE START function is not available. the CYCLE START function is not available on the WORK PROGRAM, CHECK, LAYOUT and SIMULATION pictures.	D	G	P
177	C AXIS FEED CLAMP EXCEED	Blue	1) While interpolating milling, the C-axis feedrate exceeds the JFC parameter.	D	J	P
178	NC PCB THERMAL SENSOR MALF	Blue	1) Abnormal heating of the PCB inside the NC.	В	J	0
179	HOME RETURN ERROR (ON THE DOG)	Blue	1) The zero-point return command from the dog is given while this return is inhibited (the parameter Al is operating).	D	G	P
181	MES ALARM (SENSOR NOT ON)	Red	1) When the measurement movement is completed, the measurement sensor is not turned on. No signal is given by the measurement sensor to the NC. (Sensor disconnected(*) or not installed) *: The sensor does not reach the intended position because of a program error.	B D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
182	SENSOR ON NOT IN MESURING	Red	 The sensor has turned on outside the measure- ment area. 	B D	G	N
	·	·	2) Program error as the sensor comes in contact with some object. Incorrect installation of the sensor if this does not come in contact with an object.			
183	MES ERROR EX- CEEDED MAX OFFSET	Red	1) A measurement error has exceeded the allowable maximum.	D	G	N
184	MES ERROR OVER 1/2 TOLERANCE	Red	1) A measurement error has exceeded the tolerance range, parameter <u>U29</u> /100.	D	G	N
185	EXTERNAL MES EQUIPMENT ALARM	Red	 Error data or an error signal are given by external measuring equipment. 	D	G	N
186	TOOL LIFE TIME ERROR	Red	 The wear amount exceeds the max. value while measuring. 	D	G	N
187	TOOL OFFSET NO	Red	 No offset number is specified while measuring. 	ס	G	, N
188	EXTERNAL COMMAND ERROR	Red	 An incorrect command is input to the NC. Failures of the external I/O and the PC-ROM. 	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence		How to Release
190	X AXIS HOME RETURN UN- FINISHED	Red	1) While checking the return to zero (G27), the X-axis is not at the zero-point (EIA).	D	G	N
			2) Program revision.			
191	Z AXIS HOME RETURN UN- FINISHED	Red	1) While checking the return to zero (G27), the Z-axis is not at the zero-point (EIA).	D	G	N
			2) Program revision.			
192	C AXIS HOME RETURN UN- FINISHED	Red	1) While checking the return to zero (G27), the C-axis is not at the zero-point (EIA).	D	G	N
			2) Program revision.			
193	ILLEGAL TOOL OFFSET NO (EIA)	Red	1) An offset number higher than 65 is input to the EIA program.	i	G	N
194	NO FEED DATA	Red	1) While performing the single T command in the GO1 mode, no F command is provided before the particular block.	ס	G ·	N



o PC alarm

No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken. Occur- Stat rence of s	
200	THERMAL TRIP (EMERGENCY STOP)	Red	1) Thermal relay for A F hydraulic unit head lubricating oil feed motor inside electric control panel has tripped.	L
201	NFB (NO FUSE BREAKER) TRIP	Red	I) No-fuse circuit breaker or circuit protector inside electric control panel has tripped.	L
202	HYDRAURIC PRESSURE DOWN	Red	1) Hydraulic oil pressure A F has been low for more than 3 seconds.	L
203	AIR PRESSURE DOWN	Red	1) Air pressure has been A F low for more than 3 seconds.	L
204	SPIDLE CONTROLLER MALFUNCTION	Red	1) Alarm has occured in A F spindle controller.	L
205	MILLING CONTROL MALFUCNTION	Red	l) Alarm has occurred in A F milling spindle controller.	L
206	OPEN FRONT DOOR (EMERGE. STOP)	Red	l) Cutting tool cover was A F opened with doors inter-locked in automatic mode.	L
207	EXT EMERGENCY STOP	Red	l) External emergency stop A F input signal has been turned off.	L

Mazak -

No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
208	MAGAZINE SHEAR PIN CUT	Red	 Detection of magazine body misalignment has caused LS to operate. 	A	F	L
216	SPINDLE START MISOPERATION	Red	1) I. Alarm results if spindle start command (M3, M4, START SW) is given in any of the following conditions:	A	G	L
			a. Chuck open signal from external device is on.			
			b. External spindle interlock signal is off.			
			c. Door interlock limit SW is on when door inter- locking is effec- tive.			
			d. Gear identification signal is off in manual mode.			
eg e			e. Chuck close con- firmation signal is on when bar feed mode is off.	·		
			f. M command for measurement has been executed.			
			g. Spindle rotation OK signal does not come from automatic jaw changer.			
			II. Alarm No.216 occurs when head lubrica- tion alarm is given.			



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
217	MILLING START MISOPERATION	Red	1) Same as alarm No. 216.	A	G	L
218	AXIS MOVE MISOPRATION	Red	1) Only MEGA TURN; When the cross rail is un-clamped, the axis move command has been given or CYCLE START push button has been pushed.	A	G	L
219	INVALID ATC PARAMETER	Red	1) Incorrect setting of ATC type select para- meter (OP6). lst bit: V/H type ATC 2nd bit: Standby magazine type ATC 3rd bit: RAM type ATC 6th bit: Vertical lathe specifications	A	G	L
			 a. More than two parameters are entered in each of the 1st, 2nd and 3rd bits. b. 3rd bit is set but not the 6th bit. 			
220	TOOL SET MISOPERATION	Red	Not used.	A	G	L
221	ORIENT INHIBIT	Red	1) Milling spindle orient command is given when the milling tool mounting turret is moved to the V position. (For SLANT TURN 40N ATC MILL CENTER only)	A	G	L



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence		How to Release
232	SLIDEWAY LUBRICATION ALARM	Blue	 Sliding surface lubri- cating oil pressure too low for more than 3 minutes. 	A	н	0
233	HEAD LUBRI- CATION ALARM	Blue	1) Head lubricating oil pressure too low for more than 3 seconds. (All machines except vertical lathes)	A	Н	0
			2) The machine will perform a single step stop and "SPINDLE START MISOPERATION" alarm will be dis- played after CYCLE START light goes out.			
234	TABLE LUBRICATION ALARM	Blue	1) Same as alarm No.233.	A	Н	0
235	TOOL INDEX LS MALFUNCTION	Blue	1) Clamping confirmed but indexing confirmation signal did not come on.	A	н	0
			 Tool change command given but indexing con- firmation signal did not come on in seconds. 			
236	TOOL POSITION LS MALFUNCTION	Blue	1) Malfunction of the limit switch for confirming the tool position.	Α .	Н	0



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence		How to Release
237	TOOL CLAMP LS MALFUNCTION	Blue	 Clamp confirmation signal went off during axis movement in auto- matic opration. 	A	I	0
			2) Clamp confirmation signal was not given within seconds of giving the clamp command.			
238	TOOL UNCLAMP LS MALFUNCTION	Blue	1) Unclamp confirmation signal seconds of giving the unclamp command.	. A	Н .	. 0
239	TOOL SELECT ALARM	Blue	1) The T-code command does not match the tool position.	A	Н	0
240	COOLING FAN MALFUNCTION	Blue	1) Cooling fan rotation sensor inside electric control panel has triggered an alarm.	A	H	0
241	THERMAL TRIP (SINGLE BLOCK)	Blue	 Cooling/chip conveyor motor thermal relay inside electric control panel has tripped. 	A	н	0
242	FRONT DOOR LS MALFUNCTION	Blue	1) Front door open and close confirmation signals are both on.	· A	Н	0
	•		2) Neither open or close confirmation signal came on within seconds of giving the front door open or close command.			



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
243	TAILBODY LS MALFUNCTION	Blue	 Tail body forward end and reverse end con- firmation signals are both on. 	A	Н	0
244	TAIL SPINDLE LS MALFUNCTION	Blue	1) Tail spindle forward end and reverse end confirmation signals are both on.	A	н, I	0
			2) Tail spindle forward end signal came on and went off during auto- matic operation.		·	
245	TAIL SPINDLE SW. POS. ERROR	Blue	 Tail spindle key switch was not moved to the STOP position when automatic tailing is performed using the M command. 	A	Н	O
246	CHUCK LS MALFUNCTION	Blue	1) Spindle open and closed confirmation signals are both on.	A	I	0
247	CHUCK SYSTEM MALFUNCTION	Blue	1) Chuck closed end con- firmation signal came on after the spindle open and closed confirmation.	A	I	0
249	SPINDLE ORIENT MALFUNCTION	Blue	1) Orientation not com- pleted within several seconds of giving the spindle orient command.	A	I	0
250	MILLING SPINDLE ORIENT MALF	Blue	 Orientation not com- pleted within several seconds of giving the milling spindle orient command. 	A	I	0



]	December			
No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
251	ORIENT PIN LS MALFUNCTION	Blue	1) Simultaneous function of more than two limit switches for confirming the 1° orientation of the pin or malfunction of the limit switch.	A	Н	0
252	SPINDLE GEAR LS/SHIFT MALF	Blue	1) More than two gear position confirmation signals are on.	A	I	. O
			 Gear identification signal did not come on within at least several seconds of giving the gear shift command. 			
253	MILLING GEAR LS/SHIFT MALF	Blue	 More than two milling gear position confir- mation signals are on. 	A	·I	0
			2) Gear identification signal did not come on within at least several seconds of giving the gear shift command.			
254	MEASURING AMPLIFIER MALF	Blue	l) Measuring amplifier did not send the READY signal.	A	I	0
255	EXTERNAL CONTROL MALFUNCTION	Blue	1) Alarm triggered by the external control panel.	A	I.	0
256	PALLET CHANGE MALFUNCTION	Blue	1) Alarm triggered on the pallet changer.	A	I	0
257	C-AXIS OR SHIFT LS MALFUNCTION	Blue	1) Position confirmation LS did not come on during C-axis connec- tion or release.	A	I	0 .



					,	
No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
258	NC PCB THERMAL SENSOR MALF	Blue	 Temprature sensor on NC unit printed cir- cuit board operated. 	A	. Н,І	0
			2) Command FEED HOLD when CYCLE START light goes out after single step stop is performed.			
259	TAIL LUBRICATION ALARM	Blue	I) Tail lubrication pressure decrease detection switch was turned on.	A	Н	. 0
270	START COND. ERR. (DOOR OPEN)	Blue	1) CYCLE START SW was pushed with the front cover open.	A	G	0
271	START COND. ERR. (TUR UNCLAMP)	Blue	1) CYCLE START SW was puched with the turret unclamped (clamp conformation signal off).	A	G	O
272	START COND. ERR. (EXT RESET)	Blue	1) CYCLE START SW was pushed with the external reset signal on.	A	G	O
273	START COND. ERR. (EXT FEED HOLD)	Blue	1) CYCLE START SW was pushed with the external reset signal on.	A	I	0
274	START COND. ERR. (PAL UNCLAMP)	Blue	1) CYCLE START SW was pushed when the pallet was unclamped. (For MEGA TURN)	A	G .	0



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
280	CROSS RAIL OVERLOAD	Blue	1) Raising and lowering the cross rail is prevented by the mechanical lock. Alarm occurs if the cross rail clamp current flows for more than 5 seconds after the cross rail has stopped.	A	G	0
281	HOME RETURN NOT COMPLETE	Blue	 1) After switching the power or emergency stop on, the rapid feed mode is selected before all axes have returned to the zero point. 	A	J	0
282	OPEN FRONT DOOR (FEED HOLD)	Blue	1) Machining with the cover open.	A	ŗ	0
283	ILLEGAL TOOL CHANGE POINT	Blue	l) Tool change at other places than that intended.	A	D	E



o Program preparation alarm

No.	Message	Display color	nas taken place.	Occur- rence	Status of stop	How to Release
301	ILLEGAL PROCESS DATA	Blue	1) Correct process data are not inputted.	D	J	P
302	ILLEGAL SEAUENCE DATA	Blue	1) Correct sequence data are not inputted.	D	J	P
303	NO. OF SEQ data blocks >20	Blue	1) The number of sequence data has exceeded 20 per process (except for a manual program mode process).	D	J	P
304	NO. OF SHAPE SEGMENTS >128	Blue	1) The number of graphi- cally shaped blocks has exceeded 96 per process.	D	J	P
305	CUTTING DIRECTION NOT DEFINED	Blue	 The cutting direction (forward or reverse) is unknown. 	D	J	P
306	REVERSE SHAPE CONTOUR	Blue	1) A graphic shape path is partially inverted. (Outside and inside dia.: Z-axis direction) (Front: X-axis direction)	D	J	P
307	DOUBLE SHAPE CONTOUR	Blue	1) Graphically shaped paths are redundant (A path passes through an identical place twice.)	D -	J	P



No.	Message	Display color	1)	Scription Status in which error has taken place. Action taken or to be taken.	Occur- rence		How to Release
308	REVERSE CIRCLE CONTOUR	Blue	1)	A circular path is partially inverted. (In case of the circle which extends over two dimensions.)	D	J	P
309	SHAPE OUT OF MATERIAL LIMIT	Blue	1)	A graphic shape partially protrudes out of the blank shape.	D	J	P
310	ILLEGAL CUTTING POINT	Blue	1)	A cut-in point exists outside the range of a blank.	D	J	P
311	ILLEGAL SHAPE	Blue	1)	A graphic shape is not specified properly.	D	J	P
312	ILLEGAL CORNER DEFINITION	Blue	1)	Corner C has a value larger than the linear component of graphic patterns on both sides in which corner C are to be inserted.	D	J	P
313	CALCULATION UNFINISHED	Blue	1)	There are sequence data in which the calculation of intersectin point has not been accomplished.	D	J	P
314	ILLEGAL NOSE RADIUS	Blue	1)	A nose radius is incorrect (negativ).	D	J	P
315	ILLEGAL DEPTH OF CUT	Blue	1)	A roughing cut-in stroke is illegal (negative).	D	J	P



							
No.	Message	Display color	1)	scription Status in which error has taken place. Action taken or to be taken.	Occur- rence	Status of stop	How to Release
316	ILLEGAL MATERIAL DATA	Blue	1)	Blank shape data are not inputted properly.	D	J	P
317	ILLEGAL MATERIAL ID/OD	Blue	1)	A blank has a maximum outside dia. outside a range of (blank max. 0.D.) > (blank min. I.D.) ≥ 0.	D	J	P
318	ILLEGAL MATERIAL LENGTH	Blue		A blank is outside a length range of (blank length) > (end thrust length) ≥ 0.	D	J	P
319	ILLEGAL MATERIAL SHAPE (O.D.)	Blue	1)	A blank has an out- side dia. outside a range of (blank max. 0.D.) \geq (X-axis coordinate value) \geq (blank min. I.D.)	D	J	P
				<pre>0 ≥ (Z-axis coordi- nate value) ≥ - (blank length) + (end)</pre>			
320	ILLEGAL MATERIAL SHAPE (I.D.)	Blue	1)	A blank has an out- side dia. outside a range of (blank max. 0.D.) \geq (X-axis coordinate value) \geq (blank min. I.D.)	D	J	P
	·			<pre>0 ≥ (Z-axis coordi- nate value) ≥ - (blank length) + (end)</pre>		·	
321	REVERSE MATERIAL SHAPE	Blue	1)	A blank path is inverted in the Z-axial direction.	D D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place.	Occur- rence	1	How to Release
	ı		2) Action taken or to be taken.			
322	DWELL TIME NOT INPUT	Blue	 A manual program mode dwell time is not specified. 	D	J	P
						i
323	FIN POINT MISSING IN NML PROG	Blue	 A manual program mode end point is not specified. 	D	J	P
324	ILLGAL 1ST G CODE (GOO, GO1)	Blue	1) The G command at the top of a manual program mode is other than GO or G1.	D	J	P
325	G90 IN 1ST BLK OF MNL PROG	Blue	 In the manual program mode, a relative value command is given initially. 	. D	J	P
326	RPM IN MANUAL PROG MSSING	Blue	1) In the manual program mode, a speed is not specified.	D	J	P
327	FEEDRATE IN MNL PROG MISSING	Blue	1) In the manual program mode, a feedrate is not specified.	D	J	Р
328	CIRCLE R IN MNL PROG MISSING	Blue	1) In an arc specified in the manual program mode, a radius is not specified.	D .	J'	P
329	ILLEGAL G CODE INPUT	Blue	 In the manual program mode a G command not referred to in the specification is specified. 	D		P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
330	MNP C-AXIS INADEQUATE (G02/G03)	Blue	 A C-axis move command is given in the manual programming mode in a block for specifying an arc. 	D.	J	P
331	ILLEGAL THD LEAD/NO. OF PASS	Blue	 In threading, a lead or number of cycles is not specified properly. 	D	J	Р
332	ACCELERATION DISTANCE EXCEED	Blue	 A threading accelera- tion distance has exceeded a clamp value. 	D	J	P
333	ILLEGAL GROOVE WIDTH	Blue	 During grooving, the relation between the width of the groove and the width of the tool specified is incorrect. 		J	P
334	DESIGNETED FROM ERROR	Blue	 During rough machining, there is no part to be machined. 	D	J	P
351	C-AXIS OPTION INADEQUATE	Blue	l) Linear machining occurs in the milling mode inspite of a 1° orientation having been specified.		J	P
352	ILLEGAL MILLING TOOL DIA.	Blue	1) While milling, the diameter of the tool to be used is not specified.	D	J	P
353	ILLEGAL DEPTH	Blue	1) While milling, the depth of the hole for the point mahcining process is "0".	D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	l '	How to Release
354	ILLEGAL SURF- VELOCITY	Blue	1) While milling, the peripheral speed for the point machining process is "0".	D	J	P
355	ILLEGAL TOOL/HOLE DIA.	Blue	1) While milling, the tool diameter or the hole diameter for the point machining process is "0".	D	J	P
356	ILLEGAL FEED	Blue	1) While milling, the feed for the point machining process is "0".		J	P
357	ILLEGAL PITCH	Blue	1) While milling, the milling tap (MTP) pitch for the point machining process is "0".		J	P
358	ILLEGAL DEPTH OF CUT	Blue	1) While milling, the cutting depth data for the point machining process is not correct.	D	J	P
359	FEED OVER FLOW	Blue	1) While milling, the feed for the point machining process deviates form that calculated.	1	J	P
360	ILLEGAL CORNER R	Blue	Not used.			
361	ILLEGAL CIRCLE	Blue	1) During linear machining in the milling mode, the distance between the starting point and the end point for the circular command sequence is too close or exceeds 2r.	D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
362	ILLEGAL FINISH ALLOW.	Blue	1) During linear machining in the milling mode, there is nothing to machine because the finish allowance is greater than the depth or the finish allowance is greater than the depth of cut entered in tool data.		J	P
363	ILLEGAL CUTTING POINT	Blue	Not used.			
364	ILLEGAL C-AXIS GROVE	Blue	1) During milling, the angle command for the groove (GRV) is not given in 1° units inspite of the specification of 1° orientation.	ס	J	P
365	ILLEGAL STARTING R	Blue	l) During milling, the radius R for linear machining (OUT, OUT) is set to zero.	D	J	P
366	ILLEGAL RADIUS R	Blue	1) During milling, there is no radius value (R) for the circular command in the linear machining sequence data.	D	J	P
367	ILLEGAL SHAPE OF CIR.	Blue	1) During milling, the structure of the sequential data for linear machining is not correct.	D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
368	ILLEGAL SHAPE OF TOOL OFF	Blue	1) During milling, when an offset is made for the tool diameter, the offset shape requires more than 120 blocks.	D ·	J	P
369	IMPOS. SHAPE OF TOOL OFF	Blue	1) The shape does not permit the offset for the tool diameter to be made in the milling mode.	D	J	Р



o Operation alarm

No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken. Occurately state of seconds.	
400	SYSTEM ERROR	Blue	1) Data have broken and D E are not serviceable.	F
401	INPUT FORMAT ERROR	Blue	1) A format inputted E E differs from the specified one.	. F
402	DATA INADEQUATE	Blue	1) Incorrect data are E E inputted.	F
403	GEAR NO. ERROR	Blue	l) Incorrect gear is E E specified.	E F
404	NO. OF BLOCKS IN A PRGM >500	Blue	1) All programs are tried D E to be prepared beyond 500 lines.	E F
406	WRITE PROTECT	Blue	1) A PROGRAM switch on E H the operating panel is placed in LOCK position.	E F
407	DATA NOT FOUND	Blue	1) A specified number D I or character string does not exist.	E F
408	PROGRAM ERROR	Blue	1) The information D I stored in a program storage area has broken.	E F



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
410	ILLEGAL DELETION	Blue	 A condition has not permitted a program to be erased. 	D	J	P
412	ILLEGAL PROCESS COPY	Blue	1) A condition has not permitted a program to be copied.	D	J .	P
413	NO. OF PROGRAMS > 16	Blue	1) More than 16 types of programs are tried to be prepared.	D	, J	P
414	NO. OF SEQUENCES >250	Blue	1) More than 250 sequence data are tried to be prepared in one process.	D	J	P
415	SAME PROGRAM IS DESIGNATED	Blue	1) A program registered is specified.	D	J	P
416	OPRATION MODE MALFUNCTION	Blue	1) The coordinate system is tried to be changed during the automatic operation.	Е	J	P .
417	PROCESS DATA >99	Blue	1) More than 99 process data are tried to be prepared in one program.	D .	J	P
418	EIA PROGRAM IS DISIGNATED	Blue	1) A EIA program is specified.	D	J	Р



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence		How to Release
419	NO. OF SEQUENCES > 20	Blue	1) More than 20 sequence data are tried to be prepared in one process.	D	. J	P
420	1 BLOCK CHARACTERS >64	Blue	Not used.			
421	INPUT DATA FORMAT ERROR	Blue	Not used.			
422	LAYOUT NOT COMPLETE	Blue	1) The program is deficient as regards layout.	D	J	P
423	LAYOUT IMPOSSIBLE	Blue	1) Condition is such that layout is impossible.	D	J	P
424	LAYOUT MEMORY FULL	Blue	1) Tried to prepre a program exceeding 1,000 lines for a whole layout.	D	J	P
426	NO. CHUCK DATA REGISTERED	Blue	Not used.			
427	TOOL OFFSET LIMIT EXCEEDED	Blue	Not used.			·



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
428	TOOL LIFE LIMIT EXCEEDED	Blue	Not used.			
429	PROGRAM NOT FOUND	Blue	1) A program not yet registered is specified.	D	J	· P
430	MAZATROL PROGRAM IS DISIGNATED	Blue	1) A MAZATROL program is specified.	D	J	P
431	DATA NOT FOUND	Blue	1) A wrong process number is specified.	Е	J	P
434	TOOL NOT FOUND	Blue	1) A specified tool is unavailable.	Е	J	P
436	AUTO OPERATION MODE	Blue	1) A manipulation is tried during automatic operation.	Е	J	P
437	MO2 STOP MODE	Blue	1) A muniplation is tried during the machine stop by MO2.	E	· J	P
442	CHUCK BARRIER MALFUNCTION	Blue	1) Requirements to set the chuck barrier are wrong.	D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
443	T/S BARRIER MALFUNCTION	Blue	 Requirements to set the tail barrier are wrong. 	D	J	P
	i			•		
444	TOOL BARRIER MALFUNCTION	Blue	1) Requirements to set the tool barrier are wrong.	D	J	P
445	ILLEGAL TOOL NO.	Blue	Not used.			
		·	, ,			
446	SPARE TOOL IS DESIGNATED	Blue	Not used.			
447	HOME RETURN UNFINISHED	Blue	1) A cutting edge is tried to be stored when a return to the zero point has not been made.	Е	J	P
450	LOAD UNABLE (MEMORY PROTECT)	Blue .	1) Data are loaded from the exterior in the program LOCK mode.	D	J	Р
455	DATA NOT COINCIDENT	Blue	1) The information on a tape does not coincide with that in the RAM.	D	J	P
458	FILE NOT	Blue	l) No specified file is available.	Е	J _.	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	
459	CAM MALFUNCTION	Blue	Not used.			
460	TAPE PUNCHER ERROR	Blue	1) An error had occured during tape punching.	D	J	P
461	TAPE READER ERROR	Blue	1) An error has occured during tape read.	D	J	P
462	CMT 1/0 ERROR	Blue	1) An error has occurred during CMT operation.	D	J	P
463	CMT WRITE PROTECT	Blue	1) CMT is put in write protect state.	D	J	P
464	PARITY H ERROR	Blue	1) Error has been found by horizontal parity check.	D	J	Р
465	PARITY V ERROR	Blue	1) Error has been found by vertical parity check.	D	J	P
466	INADEQUATE CHARACTER	Blue	Not used.			
467	PARAMETER ERRRO	Blue	1) Incorrect parameter setting.	D	J	Р
468	PROGRAM END NOT FOUND	Blue	1) Loading or comparing a tape containing ER(%) before the end of the M30, M99, M198 or M199 program.	D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
470	ILLEGAL THREAD	Blue	 Nominal diameter and pitch for the speci- fied screw cannot be determined. 	D	J	P
475	CURSOR POSITION INADEQUATE	Blue	1) No opration is possible with the cursor at the current position.	D .	J	P
476	BACK GROUND EDIT UNABLE	Blue	1) No editing of the background is possible.	D	J	P
477	AUTO DETERMINATION IMPOSSIBLE	Blue	1) Calculations about intersection points cannot be made because the specified unknown coordinates fall out of the setting range.	D	J	Р
478	NO INTERSECTION POINT	Blue	1) The results of calcu- lations show that the specified intersection point does not exists.	D	J	P
479	BUBBLE MEMORY FULL	Blue	1) More than 128 kinds of programs were going to be stored in the bubble memory or programs whose size exceeds the bubble memory capacity were going to be stored in the bubble memory.	D .		P
480	BUBBLE ERROR	Blue	1) I/O error happened during bubble access.	D	J	Р



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
485	DŅC COMMAND IMPO	Blue	1) Command that DNC received cannot be executed.	D	J	P
486	DNC SEND- RECEIVE ERROR	Blue	1) I/O error happened while DNC was trans-mitting/receiving.	D	J	P
487	RECEIVE ILLEGAL DNC COMMAND	Blue	1) DNC received illegal command.	D	J	P
488	OPRATION NOT ALLOWED	Blue	1) Incorrect operation after searching the EIA proram restart.	E	J	P
489	DNC SYSTEM ERROR	Blue	1) I/O error happened during DNC manipulation.	D	J	P
490	BUBBLE ERROR	Blue	1) I/O error has occurred during preparation of bubble header.	D	J	P
491	BUBBLE ERROR	Blue	Not used.			
492	BUBBLE ERROR	Blue	Not used.	-		
493	BUBBLE ERROR	Blue	1) I/O error has occurred during bubble formating.	D .	J	P
494	BUBBLE ERROR	Blue	1) I/O error has occurred during calculation of bubble size.	D	J	P



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
501	ILLEGAL PROCESS DATA	Red	1) Correct process data are not inputted.	D	G	N
502	ILLEGAL SEAUENCE DATA	Red	1) Correct sequence data are not inputted.	D	G	N
503	NO. OF SEQ data blocks >20	Red	1) The number of sequence data has exceeded 20 per process (except for a manual program mode process).	D	G	N
504	NO. OF SHAPE SEGMENTS >128	Red	1) The number of graphi- cally shaped blocks has exceeded 96 per process.	D	G	N
505	CUTTING DIRECTION NOT DEFINED	Red	1) The cutting direction (forward or reverse) is unknown.	D	G	N
506	REVERSE SHAPE CONTOUR	Red	1) A graphic shape path is partially inverted. (Outside and inside dia.: Z-axis direction) (Front: X-axis direction)	D	G	N
507	DOUBLE SHAPE CONTOUR	Red	1) Graphically shaped paths are redundant (A path passes through an identical place twice.)	D .	G	N



No.	Message	Display color	1)	scription Status in which error has taken place. Action taken or to be taken.	Occur- rence		How to Release
508 -	REVERSE CIRCLE CONTOUR	Red •	1)	A circular path is partially inverted. (In case of the circle which extends over two dimensions.)	D	G	N
509	SHAPE OUT OF MATERIAL LIMIT	Red	1)	A graphic shape partially protrudes out of the blank shape.	D	G	N
510	ILLEGAL CUTTING POINT	Red	1)	A cut-in point exists outside the range of a blank.	D	G	N
511	ILLEGAL SHAPE	Red	1)	A graphic shape is not specified properly.	D	G	N
512	ILLEGAL CORNER DEFINITION	Red	1)	Corner C has a value larger than the linear component of graphic patterns on both sides in which corner C are to be inserted.	D	G	N
513	CALCULATION UNFINISHED	Red	1)	There are sequence data in which the calculation of intersectin point has not been accomplished.	D	G	N
514	ILLEGAL NOSE RADIUS	Red	1)	A nose radius is incorrect (negativ).	D	G	N
515	ILLEGAL DEPTH OF CUT	Red		,	D.	G	N



No.	Message	Display color	1)	scription Status in which error has taken place. Action taken or to be taken.	Occur- rence		How to Release
516	ILLEGAL MATERIAL DATA	Red	1)	Blank shape data are not inputted properly.	D	G	N
517	ILLEGAL MATERIAL ID/OD	Red	1)	A blank has a maximum outside dia. outside a range of (blank max. 0.D.) > (blank min. I.D.) ≥ 0.	D	G	N
518	ILLEGAL MATERIAL LENGTH	Red	1)	A blank is outside a length range of (blank length) > (end thrust length) ≥0.	D	G	N
519	ILLEGAL MATERIAL SHAPE (O.D.)	Red	1)	A blank has an out- side dia. outside a range of (blank max. 0.D.) \geq (X-axis coordinate value) \geq (blank min. I.D.) 0 \geq (Z-axis coordi-	D	G	N
				nate value) ≥ - (blank length) + (end)			
520	ILLEGAL MATERIAL SHAPE (I.D.)	Red	1)	A blank has an out- side dia. outside a range of (blank max. 0.D.) \geq (X-axis coordinate value) \geq (blank min. I.D.)	D.	G	N
			•	<pre>0 ≥ (Z-axis coordi- nate value) ≥ - (blank length) + (end)</pre>			-
521	REVERSE MATERIAL SHAPE	Red	1)	A blank path is inverted in the Z-axial direction.	D	G	N



No.	Message	Display color	Description 1) Status in which error , has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
522	DWELL TIME NOT INPUT	Red	1) A manual program mode dwell time is not specified.	D	G	N
523	FIN POINT MISSING IN NML PROG	Red	1) A manual program mode end point is not specified.	D	G	N
524	ILLGAL 1ST G CODE (G00, G01)	Red	1) The G command at the top of a manual program mode is other than GO or G1.	D	G	N
525	G90 IN 1ST BLK OF MNL PROG	Red	1) In the manual program mode, a relative value command is given initially.	D	G	N
526	RPM IN MANUAL PROG MSSING	Red	1) In the manual program mode, a speed is not specified.	D	G	N
527	FEEDRATE IN MNL PROG MISSING	Red	1) In the manual program mode, a feedrate is not specified.	D	G	N
528	CIRCLE R IN MNL PROG MISSING	Red	1) In an arc specified in the manual program mode, a radius is not specified or an incorrect radius is specified.	D	G	N
529	ILLEGAL G CODE INPUT	Red	1) In the manual program mode a G command not referred to in the specification is specified.	D .	G	N



1						
No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
530	MNP C-AXIS INADEQUATE (G02/G03)	Red	 A C-axis move command is given in the manual programming mode in a block for specifying an arc. 	D	G	N
531	ILLEGAL THD LEAD/NO. OF PASS	Red	 In threading, a lead or number of cycles is not specified properly. 	D	G	N
532	ACCELERATION DISTANCE EXCEED	Red	 A threading accelera- tion distance has exceeded a clamp value. 	D	G	N
533	ILLEGAL GROOVE WIDTH	Red	1) During grooving, the relation between the width of the groove and the width of the tool specified is incorrect.		G	N
534	DESIGNETED FROM ERROR	Red	 During rough machining, there is no part to be machined. 	D	G	N
551	C-AXIS OPTION INADEQUATE	Red	 Linear machining occurs in the milling mode inspite of a 1° orientation having been specified. 		G	N
552	ILLEGAL MILLING TOOL DIA.	Red	1) While milling, the diameter of the tool to be used is not specified.	D	G	N
553	ILLEGAL DEPTH	Red	1) While milling, the depth of the hole for the point mahcining process is "0".	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
554	ILLEGAL SURF- VELOCITY	Red	1) While milling, the peripheral speed for the point machining process is "0".	D	G	N
555	ILLEGAL TOOL/HOLE DIA.	Red	1) While milling, the tool diameter or the hole diameter for the point machining process is "0".	. D	G	N .
556	ILLEGAL FEED	Red	While milling, the feed for the point machining process is "0".		G	N
557	ILLEGAL PITCH	Red	While milling, the milling tap (MTP) pitch for the point machining process is "0".		G	N
558	ILLEGAL DEPTH OF CUT	Red	1) While milling, the cutting depth data for the point machining process is not correct.	D	G	N
559	FEED OVER FLOW	Red	1) While milling, the feed for the point machining process deviates form that calculated.		G	N
560	ILLEGAL CORNER R	Red	Not used.			
561	ILLEGAL CIRCLE	Red	1) During linear machining in the milling mode, the distance between the starting point and the end point for the circular command sequence is too close or exceeds 2r.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
562	ILLEGAL FINISH ALLOW.	Red		D	G	N
563	ILLEGAL CUTTING POINT	Red	Not used.			
564	ILLEGAL C-AXIS GROVE	Red	1) During milling, the angle command for the groove (GRV) is not given in 1° units inspite of the specification of 1° orientation.	D	G	N
565	ILLEGAL STARTING R	Red	1) During milling, the radius R for linear machining (OUT, OUT) is set to zero.	D	G	N
566	ILLEGAL RADIUS R	Red	1) During milling, there is no radius value (R) for the circular command in the linear machining sequence data.	D	G	N
567	ILLEGAL SHAPE OF CIR.	Red	1) During milling, the structure of the sequential data for linear machining is not correct.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
568	ILLEGAL SHAPE OF TOOL OFF	Red	1) During milling, when an offset is made for the tool diameter, the offset shape requires more than 120 blocks.	D	G	N ·
569	IMPOS. SHAPE OF TOOL OFF	Red	1) The shape does not permit the offset for the tool diameter to be made in the milling mode.	D	G	N

Mazak -

No.	Message	Display color	1)	scription Status in which error has taken place. Action taken or to be taken.	Occur- rence		How to Release
601	FIRST CHR. OF BLOCK ERR.	Red	1)	First character in block is incorrect (sign, figure or decimal point).	ם	G	N
602	AFTER ADDRESS DATA NOTHING	Red	1)	There is no data after address.	D	G	N
603	ILLEGAL SIGN DATA	Red .	1)	Negative sign is put address which does not allow input of signs. More than two negative signs are put in one address.	D	G	N
604	ILLEGAL DATA FORMAT(.)	Red	1)	A decimal point is put in address which does not allow input of decimal points. More than two decimal prints are put in one address.	D	G	N
605	ILLEGAL ADDRESS CODE	Red	1)	Illegal address code is put between two significant data.	D	G ·	N
606	ILLEGAL G-ÇODE	Red	1)	Illegal G code-is used.	D	G	N
607	ILLEGAL INPUT DATA	Red	1)	<pre>Input data is illegal. (Maximum/minimum value error, R ≤ 0 in G2/G3, U < 21 in G90/G94, W < K in G92, etc.)</pre>	D	G	N
608	ILLEGAL OFFSET NO.	Red	1)	T command includes illegal tool No. or offset No.	D	G	N · · · · · ·



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	1	How to Release
609	ILLEGAL G10 OFFSET NO.	Red	l) GlO includes illegal offset No.	D	G	N
610	ILLEGAL G10 G10 OFFSET DATA	Red	1) G10 includes illegal offset X or Z or nose R.	D	G	N
611	1 BLOCK CHARACTERS >256	Red	1) No. of characters in one block has exceeded 256.	D .	G	N
612	PARITY V CHECK ERROR	Red	1) Vertical parity check has found that the number of characters in one block is not even.		G	N
620	INSUFF. FEED/THREAD	Red	l) Feedrate F or lead E data for thread is not specified.	. D	G	N
621	ILLEGAL NEXT BLOCK	Red	1) Block after chamfered corner R is not block for GO1.	י ס	G	N
622	ILLEGAL NEXT BLOCK	Red	1) Moving direction of amount of movement in block after chamfered corner R is illegal.	D .	· G	N
623	ILLEGAL GO1 DATA	Red	1) More than two among I, K and R are specified in one block for GO1.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
624	ILLEGAL G01 TAPER CHAMFERING	Red	1) Taper command (XZ) for GO1 specifies any of I, K and R.	D	G	N
625	ILLEGAL CORNER R BLOCK	Red	1) Amount of movement in block after chamfered corner R is smaller than the amount of chamfered corner R.	D	G	N
626	ILLEGAL AXIS DATA	Red	1) The command for cham- fering does not specify the combina- tion of X and L or Z and I.	D	G	N
627	ILLEGAL G34 LEAD DATA	Red		D	G	N
628	G30 START COND. ERROR	Red	1) G30 has been given although return to reference point has not been executed.	D	G	N
630	G31 START COND. ERROR	Red	1) G31 command is entered during offset of nose R.	. D	G	N
631	NOSE R OFFSET ERROR	Red	1) Arc command is present in the nose R start-up or nose R cancel command block.	D	G	N.
632	NOSE R OFFSET ERROR	Red	1) The amount of nose R larger than the arc radius is set.	D	G	N



_					· · · · · · · · · · · · · · · · · · ·	
No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
633	NOSE R OFFSET ERROR	Red	1) Offset mode varies in the command following the nose R start-up command.	D	G ·	N
634	NOSE R OFFSET ERROR	Red	1) Offset graphic will not appear in the first block during nose R computation.	D	G	N.
635	NOSE R OFFSET ERROR	Red	1) Offset graphic will not appear in the next block during nose R computation.	D	G	N
636	NOSE R OFFSET ERROR	Red	l) Nose R interference check has found more than two blocks interfered.	D	G	N
637	NO INTER- SECTION	Red	1) No intersection point is found in nose R computation.	D	G	N
638	NOSE R OFFSET ERROR	Red		D	G	N
639	NOSE R OFFSET ERROR	Red		D	G	N
640	INSUFF. G70 - G73 DATA	Red	1) P or Q is not specified by G70 through G73.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	l .	How to Release
641	ILLEGAL G71-G73, G76 DATA	Red	1) Required data in the blocks specified by G71, G72, G73 and G76 is illegal.	D	G	N
			2) Specify correct data.			
642	ILLEGAL FIRST BLOCK G71-G73	Red	1) The block specified by P in G71, G72 and G73 does not specify G00 or G01.	D	G	N
			 Specify G00 or G01 in the block specified by P. 			-
643	ILLEGAL G CODE G70-G73	Red	1) Illegal code is put between blocks speci- fied by P and Q in G70, G71, G72 and G73.	· D	G	N
			2) Delete illegal code.			
644	ILLEGAL LAST BLOCK G70-G73	Red	1) Illegal command is put in the last block specified by Q in G70 through G73. (Chamfering, corner R, subprogram)	D ·	G	N
645	G71-G73 NO. OF BLOCK > 120	Red	1) When shape has been developed with use of G71, G72 and G73, the number of sequence blocks exceeded 120.	D	G	N
646	REV. SHAPE CONTOUR G71-G73	Red	1) Tool path is reversed in cutting of contour according to G71, G72 and G73.	D	G	N
			2) Make correction so that tool path may not be reversed.			



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
- 647	G71, G72 LAP NO. OF POCKET 32	Red	1) The number of pockets has exceeded 32.	D -	G	N
648	G71, G71 LAP DISPOS. IMPOS.	Red	 Specified shape is improper. Correct the shape. 	D	G	N
649	INSUFF. G73-G76 DATA	Red	1) Block specified by G73 through G76 lacks necessary data.	D	G	N
			2) Set data correctly.			
650	G70-G73 ILLEGAL SEQ. DATA	Red	1) Sequence No. specified by P and Q in G70 through G73 is not found.	D	G	N
			2) Specify correct sequence No. For G70, there should be identical sequence No. within the work			
			program. For G71, G72 and G73, there should be identical sequence No. in the block following the current block.			
651	M98 PROGRAM NOT FOUND	Red	1) Workpiece No. specified by P in M98 is not found. Sequence No. specified by P in M99 is not found.	מ	G	N
652	PROGRAM SEARCH ERROR	Red .	1) Contents of workpiece No. searched are not EIA program.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence		How to Release
653	MEMORY AREA OVER READ	Red	 The quantity of data to be read exceeds the memory area. 	D	G	N
660	M98 P ORDER NOTHING	Red	1) P is not specified in M98.	D	G	N
661	SUB-PROG. NESTING > 16	Red	l) More than 16 sub- programs are called.	D	G	N



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
222		Red	 An attempt has been made to clamp a tool manually while the milling spindle at the milling pocket end is still turning. 	A	G	N
261		Red	l) The selected turning/ milling tool will not fit in the indexed magazine pocket.	A	Н	М
269		Red	1) The front and rear LSs of the magazine have been turned on at the same time or a confirm light has not come on after a certain interval.	A	I	М
275		Red	1) An attempt has been made to start the cycle when the ATC cover is open.	A	Н	0
276		Red	1) A nattempt has been made to start the cycle with the tool unclamped.	A	H	0
277		Red	l) The TURRET UNCLAMP menu has been selected while the milling spindle is still turning.	A	Н	O
278		Red	1) The CYCLE START button has been pressed with the measurement table at the forward end, causing the machine to stop without starting a cycle.	. A	Н	0



No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
284		Red	1) After the TOOL SET MEASURE menu has inverted and the measurement axis direction selected, an attempt has been made to select the RAPID FEED or ZERO POINT RETURN mode. It is not possible to switch to the RAPID FEED or ZERO POINT RETURN mode.	A	H	0
285		Red	1) After a tool has been replaced manually following a stop by an M00 (program stop) or M01 (optional stop) command, a restart has been attempted using a tool whose number differs from that of the replaced tool. No M00 or M01 end signal is given.	A	Н	O
286		Red	1) After the machine is first switched on or after an emergency stop, an attempt has been made to select a mode other than zero point return. The selection of the automatic operation mode is prevented.	A	Н	0



No.	Messag e	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
287		Red	1) A malfunction has occurred in a limit switch on the tool setter or tip measurement device. (More than one limit switch is turned on at once or no confirm limit switch signal is given after a certain interval following the operation command.		·H	0
288		Red	1) Although 15 seconds have passed after the machine sent an unchuck command to the robot, no unchucking end signal is issued by the robot. The tail spindle is prevented from moving.		I	N
289		Red	 The TOOL SETTER FORWARD command has been given without checking that the tail spindle is at the back end. 	A	н	P
291		Red	1) The TAIL SPINDLE FORWARD command (M code, manual switch) has been given, but the tool setter is not at the back end.	A	н	0
292		Red	1) After operating the tail spindle manually in the M00 or M01 optional stop mode, an attempt has been made to program-restart the machine when the tail spindle has not been returned to the same mode as before the optional stop. No M00 or M01 end signal is given.	A	Н	0 -

Mazak -

No.	Message	Display color	Description 1) Status in which error has taken place. 2) Action taken or to be taken.	Occur- rence	Status of stop	How to Release
293		Red	1) An attempt has been made to start the machine other than by issuing the TAIL SPINDLE FORWARD command or the TAIL SPINDLE BACKWARD command with the back end LS activated (coil energized).	A	Н	O

--

MAZATROL GAM T-2 MZ CLEAR O °7 8 9 O 60 BUSY O % P.HEAD TPS °6 <u></u> O - P.END O TURRET O PMC ALM O POLALM **5** 4 VFC **□**1 °0 °\$ ိဝ 2 3 O 🖾 COUNT UP w FEED CYCLE START HANDLE JOG Ţ) 回 | |**©**|| o WM °o. RESTART FEED HOLD TOOL SELECT BAR FEEDER **PROGRAM** HANDLE ° € **○** ENABLE ٠ چرت $^{\circ}$ 0 0 LOCK z X 040 0/2 POSITION × T **EMERGENCY STOP** SÉLECT Z °↓ ×

